
## Physical Infrastructure of Networks

Brendan Shea, PhD

Rochester Community and Technical College

# The Physical Network: Why Cables Still Matter

- Every like, text, and video depends on physical cables carrying electrical or light signals.
- Understanding the physical layer helps you troubleshoot problems and design reliable networks.
- We'll explore copper cables, fiber optics, and how to install them properly.
- By the end, you'll know how to choose the right cable for any networking situation.



#### How Networks Transmit Data

- Networks transmit data as **digital signals**, which are patterns of electrical voltages or light pulses representing 1s and 0s.
- Think of it like Morse code: just as dots and dashes can spell words, 1s and 0s can represent any information.
- A bit is a single binary digit (1 or 0), and 8 bits make a byte (enough to represent one letter).
- Bandwidth measures how many bits can be transmitted per second, like the width of a pipe determining water flow.

### Key Insight

Your computer turns everything—text, images, videos—into billions of 1s and 0s, then cables carry these as electrical or light signals at incredible speeds.

#### Introduction to Ethernet


- Ethernet is the standard set of rules (protocols) that computers use to communicate over wired networks.
- Invented in the 1970s at Xerox, Ethernet has evolved from thick coaxial cables to today's twisted pair cables.
- Ethernet became the dominant standard because it's reliable, affordable, and continuously improves without requiring complete replacement.
- When you plug a cable into your computer or router, you're almost certainly using Ethernet technology.

#### Why It Matters

Over 90% of wired networks worldwide use Ethernet standards, making it essential knowledge for any network technician.

## Copper Cables Overview

- Copper cables use copper wire to conduct electrical signals because copper is highly conductive, flexible, and cost-effective.
- The two main types are twisted pair (multiple wires twisted together) and coaxial (center wire surrounded by insulation and shield).
- Twisted pair cables connect most computers, phones, and network devices in homes, schools, and offices.
- Coaxial cables are commonly used for cable TV and internet connections from your Internet Service Provider.




Twisted pair cable showing the twisted wire pairs inside

# Unshielded Twisted Pair (UTP) Cable

- Unshielded Twisted Pair (UTP) is the most common type of network cable, found in homes, schools, and most businesses.
- UTP contains 8 copper wires arranged in 4 color-coded pairs, with each pair twisted together at specific rates.
- The twisting reduces electromagnetic interference (EMI) by canceling out electrical noise that could corrupt the signal.
- UTP is "unshielded" because it has no metal foil or braiding protecting the wires—it relies entirely on twisting for protection.

### **UTP**



Cross-section showing 4 twisted pairs inside the cable jacket

### Shielded and Screened Twisted Pair Cables

- Shielded Twisted Pair (STP) cables have metal foil or braided shielding around the wire pairs to provide extra protection from interference.
- These cables are necessary in environments with high electromagnetic interference, such as near motors, fluorescent lights, or heavy machinery.
- The trade-offs include higher cost (30-50% more expensive), reduced flexibility, and more difficult installation.
- Screened Twisted Pair (ScTP) uses an overall shield around all pairs, while STP may shield individual pairs as well.



Shielded Cat 7 cable showing individual pair shielding and overall shield

# Cable Categories (Cat Standards)

- The Category (Cat) rating system classifies twisted pair cables by their performance specifications—higher numbers mean better performance.
- Each category specifies maximum bandwidth, supported speeds, and maximum cable length (usually 100 meters).
- Choosing the right category depends on your current needs and future upgrade plans.

Category	Max Speed	Bandwidth	Common Use
Cat 5e	1 Gbps	100 MHz	Standard for homes/offices
Cat 6	1-10 Gbps	250 MHz	Business networks
Cat 6a	10 Gbps	500 MHz	High-performance networks
Cat 7	10 Gbps	600 MHz	Data centers (shielded)
Cat 8	25-40 Gbps	2000 MHz	Server connections


Note: All support 100 meter maximum distance for full specifications

#### RJ-45 Connectors

- The RJ-45 connector is the standard plastic connector with 8 pins that plugs into network devices.
- Each of the 8 pins corresponds to one of the 8 wires inside the twisted pair cable.
- Connectors can be crimped directly onto cable ends (requires special tool) or cables can terminate at keystone jacks in wall plates.
- The clear plastic housing lets you visually inspect the wire connections to verify correct installation.



RJ-45 connectors showing the 8 pins and wire arrangement




### Ethernet Speed Standards

- Ethernet standards use a naming convention: **speed-transmission type-media type** (e.g., 1000BASE-T means 1000 Mbps, baseband, twisted pair).
- 10BASE-T (10 Mbps) was the original standard, now obsolete but important historically.
- 100BASE-TX (Fast Ethernet) runs at 100 Mbps and uses only 2 of the 4 wire pairs in Cat 5e or better cable.
- 1000BASE-T (Gigabit Ethernet) runs at 1000 Mbps (1 Gbps), uses all 4 wire pairs, and requires Cat 5e minimum with Cat 6 recommended.

Standard	Speed	Wire Pairs	Min. Cable
100BASE-TX	100 Mbps	2 pairs	Cat 5e
1000BASE-T	1 Gbps	4 pairs	Cat 5e
10GBASE-T	10 Gbps	4 pairs	Cat 6a

### Coaxial and Twinaxial Cable

- Coaxial cable has a completely different design: a single center conductor surrounded by insulation, a braided shield, and an outer jacket.
- The shield protects the center conductor from interference and prevents signal leakage, making coax more resistant to EMI than unshielded twisted pair.
- Common connectors include F-type (cable TV/internet) and BNC (older networks and video equipment).
- Twinaxial cable (twinax) uses two inner conductors and is used for short, high-speed data center connections.





## Case Study: The Addams Family Network

#### The Scenario

Wednesday Addams is rewiring the mansion's network. She needs to connect 4 computers in the torture chamber (basement) to the family router located in Gomez's office on the second floor—a distance of 150 feet through the mansion's walls.

The basement has significant electrical interference from Fester's experimental equipment, which frequently generates electromagnetic pulses. The family wants fast, reliable connections for streaming horror movies and conducting paranormal research.

#### Your Task:

- What type and category of cable should Wednesday use?
- Justify your choice considering distance, interference, speed, and cost.
- Are there any alternatives she should consider?

### Case Study: Solution

Recommended Solution: Cat 6 or Cat 6a STP (Shielded Twisted Pair)

- Distance Check: 150 feet = 45.7 meters, well under the 100-meter (328 feet) limit for Ethernet √
- Speed: Cat 6 supports 1 Gbps (sufficient for streaming), Cat 6a supports 10 Gbps (future-proof) √
- Interference: Uncle Fester's equipment requires shielded cable; regular UTP would experience frequent dropouts ✓
- Cost Analysis: STP costs 30-50% more than UTP, but necessary for reliability in high-EMI environment

### Alternative Option

If the interference proves too severe even for STP, Wednesday might consider fiber optic cable, which is completely immune to electromagnetic interference—though it's more expensive and harder to terminate.

### MAC Addresses and Collision Domains

- Every network device has a unique Media Access Control (MAC) address, a 48-bit identifier burned into the network interface card at manufacturing.
- Think of a MAC address as your device's permanent physical "home address"—it never changes (e.g., 00:1A:2B:3C:4D:5E).
- A collision domain is a network segment where data packets can collide if two devices transmit simultaneously.
- Modern switches create separate collision domains for each port, preventing collisions and improving network performance dramatically compared to old hubs.

### Why This Matters

Understanding collision domains explains why switches are superior to hubs—each device gets dedicated bandwidth instead of sharing and competing for access.

#### 100BASE-TX Fast Ethernet

- 100BASE-TX (Fast Ethernet) operates at 100 Megabits per second, which is 10 times faster than the original 10BASE-T standard.
- This standard only uses 2 of the 4 wire pairs in the cable: one pair for transmitting and one pair for receiving data.
- Fast Ethernet requires Cat 5e or better cable and can reach distances up to 100 meters (328 feet).
- While Gigabit Ethernet is now more common, you'll still find 100BASE-TX in older networks and devices like IP cameras or printers.

### Legacy Technology

Many organizations still have 100BASE-TX equipment in use—knowing how to work with it is essential for technicians supporting existing infrastructure.

# Gigabit Ethernet (1000BASE-T)

- 1000BASE-T (Gigabit Ethernet) transmits data at 1000 Megabits per second (1 Gbps), providing 10 times the speed of Fast Ethernet.
- Unlike Fast Ethernet, Gigabit uses all 4 wire pairs simultaneously, with each pair both transmitting and receiving at the same time.
- This standard requires Cat 5e cable at minimum, though Cat 6 is strongly recommended for reliability and future-proofing.
- Gigabit Ethernet is currently the standard for most home and business networks, offering excellent performance at reasonable cost.

### Design Choice

When installing new networks today, always use Cat 6 or better cable even if current devices only need Fast Ethernet—this prepares for inevitable upgrades.



### Higher-Speed Ethernet Standards

- 10GBASE-T (10 Gigabit Ethernet) operates at 10,000 Mbps and requires Cat 6a cable or better to reach the full 100-meter distance.
- 25GBASE-T and 40GBASE-T are emerging standards primarily used for server-to-switch connections in data centers.
- These ultra-high-speed standards use more sophisticated encoding and require higher-quality cables to combat signal degradation.
- Most homes and small businesses don't need speeds beyond 1 Gbps currently, but large organizations use 10+ Gbps for backbone connections and server farms.


Standard	Speed	Typical Use
1000BASE-T	1 Gbps	Workstations, most networks
10GBASE-T	10 Gbps	Servers, backbone links
25/40GBASE-T	25-40 Gbps	Data center core

### Introduction to Structured Cabling Systems

- A **structured cabling system** is an organized, standardized approach to network cabling that provides a "blueprint" for how cables should be installed throughout a building.
- Without structure, cable installations become "spaghetti"—tangled, impossible to trace, and nearly impossible to troubleshoot or modify.
- The system divides the network into hierarchical subsystems: work areas (where users work), horizontal cabling (floor distribution), and backbone cabling (between floors/buildings).
- Following structured cabling standards ensures that any qualified technician can understand and work with your installation, even years later.
- Properly designed structured cabling can last 15-20 years, supporting multiple technology upgrades without rewiring.


## Structured Cabling Components

- Work Area Outlet: Wall jack where users plug in devices (maximum 3 meters of patch cable to device).
- Horizontal Cabling: Permanent cable running from work area to telecommunications room (maximum 90 meters).
- Telecommunications Room (TR): Central wiring closet on each floor with patch panels and switches.
- Backbone Cabling: Connects TRs across floors or between buildings.



## T568A and T568B Wiring Standards

- T568A and T568B are two different standards for arranging the 8 wires within an RJ-45 connector.
- The standards differ only in the positions of the orange and green pairs—all other wires are identical.
- A straight-through cable uses the same standard on both ends (most common), while a crossover cable uses different standards on each end
- Consistency matters more than which standard you choose—pick one and use it throughout your entire installation.



T568A (top) and T568B (bottom) pin assignments

## Patch Panels: The Organized Network

- A patch panel serves as the central connection point in a telecommunications room where all horizontal cables terminate.
- The front of the panel has RJ-45 ports labeled for each cable run; the back has punch-down blocks where wires are terminated.
- Patch panels make troubleshooting easier by providing a single, organized location to test and reroute connections without touching permanent wiring.
- Short patch cables connect from the patch panel to switches, allowing flexible network configuration changes.



24-port patch panel with labeled ports

### Pro Tip

Always label both ends of every cable and document which patch panel port goes to which room!

### Cable Installation Best Practices

- Plenum-rated cables (CMP) must be used in air handling spaces because they produce less toxic smoke in fires; riser-rated cables (CMR) are for vertical shafts between floors.
- Never exceed the cable's **minimum bend radius** (typically 4 times the cable diameter)—sharp bends damage internal wires and degrade performance.
- Maintain proper cable management with no kinks, avoid running parallel to electrical cables (maintain 12+ inches separation), and never exceed maximum pulling tension (25 lbs for Cat 6).
- Label everything immediately during installation: both cable ends, patch panel ports, wall jacks, and create detailed documentation showing cable routes.

### Critical Safety Rule

Building codes legally require specific cable ratings for different locations—using the wrong cable type can result in failed inspections, fines, and serious fire hazards.

### Cable Installation Tools

- Punch-down tools (with 110 blade) are used to terminate wires onto patch panels and keystone jacks by forcing the wire into the connector and cutting off excess.
- Cable strippers remove the outer jacket without damaging internal wires, while crimpers attach RJ-45 connectors to cable ends.
- Cable testers verify that all 8 wires are correctly connected and detect opens, shorts, and miswires.
- Tone generators send a signal through a cable while a probe traces the cable to identify which physical cable corresponds to which connection.







# Case Study: The Addams Family Crypt Network

#### The Scenario

Morticia wants to add network connectivity to the family crypt in the basement for livestreaming séances. The router is in Gomez's office on the second floor. The cable must run 65 meters through the mansion's ceiling plenum (the old ventilation system), then 20 meters down a vertical shaft behind the walls to reach the crypt.

Thing has found three boxes of cable in the attic:

- Cat 6 standard PVC jacket (CMG rated)
- Cat 6 Plenum rated (CMP)
- Cat 6 Riser rated (CMR)

#### Your Task:

- Which cable(s) should Morticia use for each part of the run?
- Will the total distance work for Gigabit Ethernet?
- What happens if she uses the wrong cable type?



## Case Study: Solution

Best Solution: Cat 6 Plenum-rated (CMP) cable for the entire run

**Alternative:** CMP for plenum section (65m) + CMR for riser section (20m)

- Distance Check: 85 meters total is under the 90-meter horizontal limit (100m with patch cables) ✓
- Plenum Section: MUST use CMP-rated cable—CMR or CMG would violate fire codes X
- Riser Section: Could use CMR or CMP (CMP works everywhere, CMR only in vertical shafts)
- Practical Choice: Using CMP throughout is simpler and ensures compliance everywhere

### What Goes Wrong?

Using CMG anywhere: Fails building inspection, expensive rewiring. Using CMR in the plenum: Fire hazard—toxic fumes could spread through ventilation. The mansion's insurance company would not be pleased!

# Why Fiber Optic Cables?


- Copper cables have fundamental limitations: maximum distance of 100 meters, susceptibility to electromagnetic interference, and speed limits around 10 Gbps for twisted pair.
- **Fiber optic cables** use pulses of light instead of electrical signals, completely eliminating electromagnetic interference problems.
- Fiber provides dramatically longer distances (up to 40+ kilometers for single-mode), much higher speeds (100+ Gbps), and improved security (difficult to tap).
- The trade-offs include higher initial cost, more fragile physical properties, and requirement for specialized tools and training for installation.

#### When to Choose Fiber

Use fiber for: connections between buildings, long runs within buildings ( $>100\,\mathrm{m}$ ), environments with heavy EMI, high-security applications, and backbone connections requiring 10+ Gbps speeds.

### How Fiber Optic Cables Work


- Light pulses represent digital data: light on = 1, light off = 0, transmitted billions of times per second.
- The light travels through a glass or plastic core using total internal reflection—light bounces off the walls at specific angles, staying contained within the fiber.
- Think of it like a slide at a water park: the walls keep water from spilling out as it travels down, just as the cladding keeps light inside the core.
- Light sources can be LEDs (cheaper, shorter distance) or lasers (expensive, longer distance, more precise).





#### Fiber Cable Construction

- The core is the ultra-thin glass center where light actually travels—only 9 to 62.5 micrometers ( $\mu$ m) in diameter (thinner than a human hair).
- The cladding surrounds the core with a different glass that has a lower refractive index, causing light to reflect back into the core.
- A **buffer coating** protects the fragile glass from moisture and physical damage.
- Strengthening fibers (often Kevlar) provide tensile strength, and the outer jacket protects everything.



Multi-fiber cable showing individual fibers, strengthening materials, and jacket

#### Handle with Care!

Fiber is glass—it can break if bent too sharply or pulled too hard!

## Single-Mode vs. Multimode Fiber

- Single-mode fiber (SMF) has a tiny 9-micrometer ( $\mu$ m) core that allows only one light path, using laser light sources for precise transmission.
- Multimode fiber (MMF) has a larger 50 or 62.5-micrometer ( $\mu$ m) core allowing multiple light paths, using cheaper LED light sources.
- Single-mode supports much longer distances (40+ km) but costs more for equipment; multimode is cheaper but limited to shorter distances (typically 550 meters or less).

Feature	Single-Mode (SMF)	Multimode (MMF)
Core Diameter	9 $\mu$ m	50 or 62.5 $\mu$ m
Light Source	Laser	LED
Max Distance	40+ km	550 m typical
Cost	Higher	Lower
Use Case	Long distance, WAN	Building/campus

### Fiber Optic Connector Types

- SC (Subscriber Connector) has a square shape with a push-pull mechanism, making it easy to connect and disconnect without twisting.
- LC (Lucent Connector) is a small form-factor connector with a latch mechanism, commonly used in high-density installations.
- ST (Straight Tip) features a round bayonet-style connector that twists to lock, common in older installations and multimode networks.
- MTRJ (Mechanical Transfer Registered Jack) combines two fibers in a single small connector body, similar in size to RJ-45.







#### Fiber Ethernet Standards

- Fiber Ethernet standards use naming similar to copper: speed-BASE-distance/type (e.g., 1000BASE-SX means 1000 Mbps, baseband, short wavelength).
- 1000BASE-SX uses short wavelength (850nm) lasers on multimode fiber for distances up to 550 meters.
- 1000BASE-LX uses long wavelength (1310nm) lasers and works on both single-mode (up to 5 km) and multimode (up to 550 m) fiber.
- 10GBASE-SR/LR provides 10 Gigabit speeds: SR (Short Reach) on multimode up to 400m, LR (Long Reach) on single-mode up to 10 km.

#### Understanding the Letters

S = Short wavelength, L = Long wavelength, R = Reach/Range. The letter tells you about distance capabilities and the type of fiber required.



#### Fiber Installation Considerations


- Never exceed the **minimum bend radius** (typically 10 times the cable diameter for fiber)—bending fiber too sharply causes the glass to crack or the light to escape.
- Fiber connections require absolute cleanliness because microscopic dust particles on the glass end can block light transmission completely.
- Fusion splicing permanently joins two fibers by melting them together (strongest, lowest loss), while mechanical splicing uses alignment fixtures (faster, easier, slightly higher loss).
- Never look directly into the end of an active fiber optic cable—the infrared laser light is invisible but can cause permanent eye damage.

#### Safety First!

Always use a fiber optic power meter to verify a fiber is not active before inspecting it. Treat every fiber as if it's carrying laser light.

#### Fiber Distribution Panels

- Fiber distribution panels serve the same role as patch panels for copper, providing organized termination points for fiber cables.
- Splice trays hold spliced fiber connections and protect them from damage, allowing for organized storage of excess fiber length.
- Adapter panels provide connector ports (SC, LC, etc.) for patch cable connections, allowing flexible reconfiguration.
- Proper cable management is even more critical with fiber because the cables are more delicate and bending restrictions are stricter.



## Advanced Fiber Technologies

- Wavelength Division Multiplexing (WDM) allows multiple signals to travel simultaneously on one fiber by using different colors (wavelengths) of light.
- CWDM (Coarse WDM) uses widely-spaced wavelengths (8-18 channels) for metro applications, while DWDM (Dense WDM) packs 40-80+ channels tightly for long-haul networks.
- MPO/MTP connectors are multi-fiber connectors that terminate 12 or 24 fibers in a single small connector, dramatically reducing installation time in data centers.
- These technologies are primarily used in telecommunications and large data centers where maximizing fiber capacity is critical.

#### Think of WDM Like This

WDM is like having multiple radio stations broadcasting simultaneously—each uses a different frequency so they don't interfere. With fiber, different colors of light act as separate "channels."

## Copper vs. Fiber: Making the Choice

Feature	Copper (UTP)	Fiber Optic
Maximum Distance	100 m	550 m - 40+ km
Maximum Speed	10 Gbps (Cat 6a)	100+ Gbps
EMI Immunity	Vulnerable	Completely immune
Installation Cost	Lower	Higher
Installation Difficulty	Easier	Requires training
Security	Can be tapped	Very difficult to tap
Weight	Heavier	Much lighter
Power Delivery	Yes (PoE)	No

#### Decision Guide

Use copper for: workstation connections, short runs, PoE devices. Use fiber for: building-to-building, long distances, high EMI environments, high-speed backbones.

### Case Study: The Addams Family Estate Network

#### The Scenario

The Addams family has purchased the abandoned estate next door to expand their property. Gomez wants to connect the network in the main mansion to the new guest house, which will serve as Pugsley's laboratory for explosive experiments.

#### Key facts:

- Distance between buildings: 800 meters
- The path runs near high-voltage power lines that feed Fester's electrical experiments
- Current network requirement: 1 Gbps minimum
- Future plans: Upgrade to 10 Gbps within 3 years
- Budget: Moderate (this is the Addams family, after all)

#### Your Task:

- What cable type should they use and why?
- If choosing fiber, should they use single-mode or multimode?



### Case Study: Solution

Correct Solution: Single-Mode Fiber (1000BASE-LX or 10GBASE-LR)

- Copper Eliminated: 800 meters far exceeds the 100-meter limit for copper Ethernet—copper is not an option
- **EMI Immunity:** High-voltage power lines would destroy copper signals; fiber is completely immune to electromagnetic interference
- Distance Capability: Single-mode fiber easily handles 800m (can go 10+ km); multimode limited to 550m maximum
- Future-Proofing: Single-mode supports both current 1 Gbps (1000BASE-LX) and future 10 Gbps (10GBASE-LR) requirements
- Why Not Multimode? At 800m, multimode won't work—it exceeds the 550m limit even for 1 Gbps

#### Final Recommendation

Install single-mode fiber with 1000BASE-LX equipment now, upgrade to 10GBASE-LR transceivers later without replacing cables. The higher upfront cable cost is offset by long-term flexibility.

### The Physical Environment Matters


- Network equipment needs more than just cables—servers, switches, and routers require carefully controlled physical environments to operate reliably.
- Equipment rooms and data centers must maintain specific temperature, humidity, and power conditions to prevent hardware failure.
- Environmental problems cause the majority of unexpected network downtime: overheating servers, power outages, water damage, and fire.
- Understanding physical infrastructure requirements is essential because even the best network design fails if equipment shuts down due to environmental issues.

### Real-World Impact

A single equipment room cooling failure can take down an entire building's network in minutes, affecting hundreds or thousands of users. Environmental monitoring is not optional.

# Rack Systems

- 19-inch equipment racks are the standard mounting system for network equipment, servers, and patch panels in professional installations.
- Rack height is measured in U units (rack units), where 1U equals 1.75 inches—a typical rack is 42U tall.
- Equipment includes mounting rails, cable management arms, vertical power strips, and proper airflow management (front-to-back or bottom-to-top).
- Cable management within racks prevents tangled "spaghetti" connections and ensures proper airflow around heat-generating



### Temperature and Humidity Control

- Network equipment should operate in temperatures between 68-77°F (20-25°C)—exceeding these ranges causes hardware to throttle performance or shut down completely.
- **Humidity** must stay between 40-60% because low humidity causes static discharge (which damages electronics) and high humidity causes condensation (which shorts circuits).
- Data centers use precision HVAC systems specifically designed for equipment cooling, not human comfort, with redundant cooling units.
- Hot aisle/cold aisle design arranges racks so equipment air intakes face one direction (cold aisle) and exhausts face the opposite direction (hot aisle), maximizing cooling efficiency.

### Warning Signs

If equipment rooms feel warm to touch, have high fan noise, or show temperature warnings, the cooling system is inadequate and equipment lifespan is being drastically reduced.

# Power Management

- An Uninterruptible Power Supply (UPS) provides battery backup that keeps equipment running during power outages and conditions power to prevent damage from surges and sags.
- UPS runtime typically ranges from 5-30 minutes—enough time for graceful shutdown or for backup generators to start.
- **Surge protectors** only block voltage spikes; true UPS systems also provide battery backup and clean, regulated power continuously.
- Critical facilities use **redundant power supplies** in servers (two power supplies, two circuits) and backup generators that automatically start within seconds of power loss.

#### Investment Priority

A quality UPS protecting \$50,000 of network equipment costs \$2,000-5,000—cheap insurance against power problems that could cause equipment failure or data loss.

# Fire Suppression in Equipment Rooms

- Traditional water sprinkler systems will destroy electronic equipment—water and electricity create short circuits that ruin servers, switches, and data.
- Clean agent systems (like FM-200) use gaseous chemicals that suppress fire without leaving residue or conducting electricity, allowing equipment to continue operating afterward.
- Inert gas systems displace oxygen in the room, suffocating the fire without using chemicals or water.
- Pre-action systems provide a warning (alarm and detection) before releasing suppressant, giving personnel time to verify it's a real fire and evacuate.
- These specialized systems cost significantly more than water sprinklers but are essential for protecting valuable equipment and irreplaceable data.

# Cable Troubleshooting Introduction

- "It was working yesterday!"—This is the most common phrase technicians hear, and now you need to figure out what changed.
- A systematic approach beats random guessing: gather information, form hypotheses, test methodically, and document your findings.
- Good **documentation** is your best friend during troubleshooting—cable labels, network diagrams, and installation records save hours of work.
- Most cable problems fall into a few common categories: physical damage, incorrect termination, exceeded specifications, or environmental interference.

### The Troubleshooting Mindset

Start with the simple, obvious causes (loose connection, wrong cable) before assuming complex problems. The solution is usually simpler than you think.

#### Common Cable Problems

Symptom	Possible Cause	Solution
No connectivity	Unplugged cable, bro-	Check connections, test
	ken wire, bad crimp	cable, re-terminate
Intermittent drops	Damaged cable, loose	Replace cable, secure
	connection, marginal	connections
	crimp	
Slow speeds	Wrong cable category,	Verify Cat rating, check
	excessive length, bad	distance, re-terminate
	termination	
Short max distance	Attenuation too high,	Test with certifier,
	cable too long, wrong	check length, upgrade
	category	cable
Errors/corruption	Interference (EMI/RFI),	Shield cable, reroute
	crosstalk, poor ground-	away from noise, check
	ing	grounds

Always test methodically—don't assume the cable is bad until you've verified it with proper tools

# Cable Testing Tools

- A cable certifier tests cables against industry standards (TIA/EIA), measuring
  attenuation, near-end crosstalk, return loss, and providing pass/fail certification (expensive
  but essential for professional installations).
- Wire map testers verify that all 8 wires are connected to the correct pins and detect opens, shorts, reversed pairs, and split pairs (inexpensive, basic testing).
- Tone generators and probes send an audible signal through a cable while you use the probe to trace which physical cable it is among many (essential for identifying unlabeled cables).
- Optical Time Domain Reflectometers (OTDR) test fiber optic cables by sending light pulses and measuring reflections to locate breaks and measure loss (advanced, expensive).

#### Tool Investment

Basic wire map tester: \$50-100. Professional cable certifier: \$2,000-5,000. Choose tools based on whether you're doing occasional fixes or professional installations requiring certification.

### Understanding Cable Issues

- Attenuation is signal loss over distance—the signal weakens as it travels, eventually becoming too weak to detect reliably (measured in decibels, dB).
- Electromagnetic Interference (EMI) and Radio Frequency Interference (RFI) are external electrical noise from motors, fluorescent lights, radio transmitters, and power lines that corrupts network signals.
- Near-End Crosstalk (NEXT) occurs when signal from one wire pair bleeds into adjacent pairs near the transmission end, causing interference.
- Far-End Crosstalk (FEXT) is similar bleeding between pairs but measured at the far end of the cable.
- **Return loss** measures signal reflection caused by impedance mismatches—like sound echoing back when you shout into a canyon.

#### The Bottom Line

Quality cables, proper termination, correct installation, and appropriate shielding prevent most of these issues. Cheap cables and sloppy work create expensive problems.

# Case Study: The Addams Family Network Mystery

#### The Scenario

Lurch reports that the network connection in the conservatory keeps dropping every few minutes. Other users on the same switch in the telecommunications room work perfectly. Wednesday investigates and finds:

- The cable from the wall jack to Morticia's computer works fine (tested with cable tester)
- The patch cable in the telecom room connecting patch panel to switch also tests good
- The conservatory is 85 meters from the telecom room
- The horizontal cable was installed last year and was working fine until this week
- The conservatory is next to Fester's workshop, where he recently installed several large Tesla coils for experiments

**Your Task:** What should Wednesday check next? What is the most likely cause? How would you troubleshoot this systematically?

# Case Study: Solution

Most Likely Cause: Electromagnetic interference from Fester's Tesla coils

#### **Troubleshooting Steps:**

- Use a cable certifier (not just a basic tester) to check the horizontal cable run for interference and crosstalk—basic testers won't detect EMI issues
- Test the connection when Fester's Tesla coils are powered off—if it works, you've confirmed the interference source
- Oheck if the cable runs parallel to power lines or near Fester's equipment
- Measure actual error rates and packet loss (not just "it drops sometimes")

#### Solutions (in order of preference):

- Reroute the cable away from Fester's workshop (maintain 12+ inches from interference sources)
- Replace with shielded twisted pair (STP) cable properly grounded
- Use fiber optic cable (completely immune to EMI, but most expensive)

# Conclusion: The Foundation of Every Network

#### Key Takeaways:

- The physical layer is the foundation—every network depends on properly installed, maintained cabling infrastructure.
- Choose the right cable for each situation: consider distance, speed requirements, environment, interference, and future needs.
- Standards exist for good reasons: they ensure safety, compatibility, performance, and long-term reliability.
- Proper installation prevents 90% of problems: correct termination, appropriate cable ratings, good documentation, and following specifications.
- Systematic troubleshooting beats random guessing: use the right tools, test methodically, and document everything.

#### Your Impact

As a network technician, your cabling work keeps businesses running, students learning, hospitals operating, and families connected. Quality work at the physical layer makes