





Mounting Holes










Zoxnoxious Engineering
Sheet: /
File: as3372.kicad\_sch

Title: Z3372 Signal Processing


 Size: B
 Date: 2023-04-02
 Rev: 0.3


 KiCad E.D.A. kicad (6.0.7-1)-1
 Id: 1/3




Control Voltage levels: Sig1 VCA CV: 0-5V Sig2 VCA CV: 0-5V VCA Mod Level CV: 0-5V Res CV: 0-5V VCF CV: -1 - +6V Pan VCA CV: -2.5 - +2.5V

The latter two use opamps to scale; everything else can be straight from DAC. These are slightly outside datasheet specs of 0:5 and -2:+2 to allow for some offset from modulation.








Zoxnoxious Engineering
Sheet: /DAC/


File: dac.kicad\_sch


Title: Z3372 Signal Processing

 Size: B
 Date:
 Rev: 0.3

 KiCad E.D.A. kicad (6.0.7-1)-1
 Id: 2/3







Zoxnoxious Engineering

Sheet: /filter\_as3372/ File: filter\_as3372.kicad\_sch

Title: Z3372 Signal Processing

 Size: B
 Date:
 Rev: 0.3

 KiCad E.D.A. kicad (6.0.7-1)-1
 Id: 3/3