





## Mounting Holes H1 3mm\_Mounting\_Hole 3mm\_Mounting\_Hole H2 3mm\_Mounting\_Hole 3mm\_Mounting\_Hole



oxnoxious Eng	ineering	
heet: / ile: vca_backp	lane.kicad_sch	
itle:-Zoxno	xious Backplane and VCA	
ize: B	Date: 2022-08-28	Rev: 0.2
iCad E.D.A. k	icad 6.0.7-f9a2dced07~116~ubuntu20.04.1	ld: 1/9








Zoxnoxious Engineering


Sheet: /Level Shifting/ File: level\_shifting.kicad\_sch


Title: Zoxnoxious Backplane and VCA


 Size: B
 Date: 2022-08-28
 Rev: 0.2


 KiCad E.D.A. kicad 6.0.7-f9a2dced07-116-ubuntu20.04.1
 Id: 2/9























Zoxnoxious Engineering			
Sheet: /Sheet624DD8BD/ File: output_select.kicad_sch			
Title: Zoxnoxious Backplane and VCA			
Size: B Date: 2022-08-28	Rev: 0.2		
KiCad E.D.A. kicad 6.0.7-f9a2dced07~116~ubuntu20.04.1	ld: 5/9		

