Lecture 06 Timers

CE346 – Microcontroller System Design Branden Ghena – Fall 2024

Some slides borrowed from: Josiah Hester (Northwestern), Prabal Dutta (UC Berkeley)

Administrivia

- Last chance for Lab1 checkoffs 5:00-6:00 today
 - Quite a few groups remaining, so it'll likely focus on checkoffs first
- Don't forget to answer the postlab questions on Gradescope
 - You and your partner can work on them together, but submit separately
- Lab2 tomorrow! Virtual Timer Lab

- Project proposals due next week Thursday!
 - Be sure to find a group. Fill out the survey if you want to find someone!

Next week Tuesday: online recording

Unfortunately, I'll be out-of-town on Tuesday next week

So, no in-person class on that day

- I will record the lecture in advance and put it out on Panopto
 - Lecture on Sensors
 - Moved the schedule around a little

Today's Goals

Understand the role of clocks in a microcontroller

Explore functionality of various timer peripherals on the Microbit

Outline

Clocks

Timers


Virtualizing Resources

Real-Time Counter

Watchdog

What are clocks?


 Clock signals, in the microcontroller context, are oscillating square wave signals used to switch transistors and latch inputs



- A clock MUST be running for (almost) anything on a microcontroller to function (processor and peripherals)
 - Exceptions:
 - Low-power input interrupts
 - GPIOTE port interrupt, Analog LPCOMP interrupt, NFC sense interrupt, USB power interrupt
 - Reset signal

Generating clocks

- External crystal oscillator
 - Creates clock signal
 - Chunk of quartz
 - Behaves like RLC circuit but uses less energy
- Internal mechanisms
 - RC oscillator
 - Creates clock signal
 - Less accurate and higher energy than crystal
 - Phase-Locked Loop (PLL)
 - Multiply input to create new higher frequency clocks




Microbit crystal for nRF52833



Clocks and energy

- Fundamental tradeoff
 - Faster clock gets things done faster but uses more energy
 - Slower clock uses less energy but gets things done slower
 - Which to use depends on the situation
 - CPU bound: faster clock, IO bound: slower clock



Example of clock selection for a mixed load (part IO, part CPU)


Energy consumed becomes a horizontal line when the task is completed

Chiang et al. "Power Clocks: Dynamic Multi-Clock Management for Embedded Systems" EWSN 2021

Controlling clocks

- Some microcontrollers provide extremely fine-grained control over clocks
 - Really complicated section of code to get working
 - Many combinations are invalid
 - Manually enable/disable clocks as needed
- nRF52 instead gives almost no control but is easier to use
 - One 64-MHz clock for processor
 - Multiple peripheral clocks, but (most) peripherals are hardwired to one
 - 16 MHz for almost all peripherals (PDM and I2S are 32 MHz)
 - Low-frequency 32 kHz clock for low-power peripherals
 - Automatically enables/disables clocks

nRF52833 clocks



Electrical characteristics

Active power of clocks

• 32 kHz crystal run current: 0.23 μA

• 32 kHz RC oscillator run current: 0.70 μA

• 32 MHz crystal average run current: 300-700.00 μA

• 32 MHz standby current: 110.00 μA

- Startup time for external crystals
 - 32 kHz crystal: 250-500 ms (milliseconds!!!)
 - 32 MHz crystal: 60-200 µs
 - Beware: switching can lead to delays and instability
 - nRF52 uses RC oscillator while crystal is not yet ready

Outline

Clocks

Timers

Virtualizing Resources

Real-Time Counter

Watchdog

Timer peripherals

- Common need for embedded systems: sense of time
 - Start this behavior after a certain amount of time
 - Stop this behavior after a certain amount of time
 - Measure how much time passed between two events
- Timer peripherals
 - Input is one of the system clocks
 - Counts up a register at each clock tick
 - Looking at register at start and end can give real-world duration
 - Compare to saved value and trigger interrupt on match
 - Allows interrupts to be scheduled in the future

Break + Discussion


- What is the finest granularity you might need from a timer?
 - Give an example of the use case
- What is the longest duration you might need from a timer?
 - Give an example of the use case

Break + Discussion

- What is the finest granularity you might need from a timer?
 - Give an example of the use case
- What is the longest duration you might need from a timer?
 - Give an example of the use case

- Concern: high granularity for long durations require MANY bits
 - We often optimize for one of the other

Timer peripheral on nRF52833



Input and Prescaler

$$f_{\text{TIMER}} = \frac{16 \text{ MHz}}{2^{PRESCALER}}$$


- Prescaler is a 4-bit number
 - Possible timer input clocks: 16 MHz 488 Hz
- Ticks counted with (up to) 32-bit internal Counter:
 - Minimum
 - 268 seconds until overflow
 - **62.5 ns** per tick
 - Maximum
 - 101 days until overflow
 - **2.04 ms** per tick

Alternate input source for counter mode

 Counter mode works with non-timer inputs

• E.g. GPIO input event

Count anything!



Capture/Compare registers (CC)

- 32-bit storage registers (each timer has multiple)
 - Uses: capturing or comparing
- On Capture[n] event
 - Internal Counter value copied to CC[n]
 - Then you can read the former Counter value from CC[n]
- Capture used to measure durations of events
 - Capture can be triggered by software or by Events from other peripherals
 - Multiple registers to measure multi-part events

Comparing with CC registers

- When internal Counter value equals a CC register
 - Corresponding Compare[n] event is triggered
 - Can trigger interrupts

- Usually written to in advance to start/stop behavior
 - Toggle LED every second
 - Sample sensor every five minutes
 - Refresh LED matrix every 1/60 seconds

The nRF52833 has multiple Timer instances

6.28.5 Registers


Base address	Peripheral	Instance	Description	Configuration
0x40008000	TIMER	TIMERO	Timer 0	This timer instance has 4 CC registers
				(CC[03])
0x40009000	TIMER	TIMER1	Timer 1	This timer instance has 4 CC registers
				(CC[03])
0x4000A000	TIMER	TIMER2	Timer 2	This timer instance has 4 CC registers
				(CC[03])
0x4001A000	TIMER	TIMER3	Timer 3	This timer instance has 6 CC registers
				(CC[05])
0x4001B000	TIMER	TIMER4	Timer 4	This timer instance has 6 CC registers
				(CC[05])

Bonus concept: shorts

- In a peripheral: Tasks are inputs and Events are outputs
- Shorts connect an Event to a Task within a peripheral

Tasks and Events idea is fairly nRF specific

- Timer shorts
 - Connect Compare[n] to Clear
 - Connect Compare[n] to Stop



Usage: how do we set a one second timer?

- Assume timer is already running
- 1. Get current time from timer
- 2. Add 1 second worth of ticks to it $\frac{16000000}{2^{PRESCALER}}$ is the number of ticks per second
- 3. Set an unused Compare register to value
- 4. Enable interrupts for that Compare event

Warning: what if you're setting a 1 us timer instead? Or a 100 ns timer?

Timer could expire before software writes it to the peripheral.

Break + Check your understanding

• Prescaler value is 4

$$f_{\text{TIMER}} = \frac{16 \text{ MHz}}{2^{PRESCALER}}$$

- Current internal Counter value is 0x1000
- Want a 0.5 second timer

What do you set the CC[0] register to? (32-bits)

Break + Check your understanding

• Prescaler value is 4

$$f_{\text{TIMER}} = \frac{16 \text{ MHz}}{2^{PRESCALER}}$$

- Current internal Counter value is 0x1000
- Want a 0.5 second timer

- What do you set the CC[0] register to? (32-bits)
 - 1 MHz Timer frequency -> 500,000 ticks in 0.5 seconds
 - 500000 -> 0x7A120
 - Plus initial value of counter = 0x7B120

Outline

Clocks

Timers

Virtualizing Resources

Real-Time Counter

Watchdog

Choosing resource amounts is a problem

- Problem: applications may require any number of resources
 - Particularly in this case: peripherals
 - For example, how many timers should there be?
- But hardware has to pick some number to provide
 - More is wasted cost
 - Too few and applications cannot succeed
- Solution: virtualize the resource


Virtualization pattern

- Create a queue of requests and a pool of resources
 - N requests to M resources
- Application requests are queued when they come in
 - Rather than serviced immediately
- When a resource is available
 - Pop request from queue (by some priority)
 - Service with hardware
 - Then wait until another resource is available


Example: sending serial messages

- Serial messages (such as printf() strings) are sent via UART
 - UARTE peripheral (we'll talk about this later)
- nRF52 has two UARTE peripherals
 - Can be attached to any output pins
 - Changing pins is a quick operation
- What if we want to talk to three serial devices?
 - Console (printf output)
 - GPS (NMEA)
 - WiFi radio (AT commands)


Virtualized UART




Virtualized UART: serves request with hardware




Virtualized UART: serves until resources are full




Virtualized UART: additional requests are queued



Virtualized UART: moves to next item when complete



Virtualized UART: moves to next item when complete



Challenges to making virtualization work


- How fast are requests coming in?
 - Requests more quickly than service are an unsatisfiable system
- How long does it take to reconfigure the resource?
 - Long delays could mean high latency
 - Might want to optimize for requests with same configuration first
- Need to ensure all of the configuration changes
 - Common bug: forget to modify part of one register and system works most of the time, but not in all cases
- Need ability to queue requests
 - Usually stored in a linked list structure
 - Dynamically... But we generally want to avoid dynamic memory

Dynamic resource allocation options

- 1. Create a queue with a maximum size in Virtual Driver
 - Some number larger than the hardware picked, based on app knowledge
 - Still either runs out or wastes memory
- 2. Just use malloc()
 - Is actually possible on the nRF52 with newlib (libc implementation)
 - Might run out, but then just wait for requests to complete
- 3. Create list nodes individually as global variables
 - Application decides how many it needs at compile time
 - Passes them into the Virtual Driver at first use
 - "Here's my request and a linked list node to store it in"

Another example: managing multiple timers

You often have tasks that look like this:



- Most easily thought about as three separate timers
 - But maybe the system doesn't have that many timers to spare!
 - Virtualization can help


- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register

CC Register: 10010

Others stay in linked list, sorted by expiration

Timer Requests

- 1. 10010, A
- 2. 10050, B
- 3. 10110, C
- 4. 20000, D



- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register
 - Others stay in linked list, sorted by expiration

Timer Requests	CC Register: 10010
1. 10010, A	_
2. 10050, B	Call timer handler A! Update CC register and list
3. 10110, C	
4. 20000, D	



time

- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register
 - Others stay in linked list, sorted by expiration

Timer Requests CC Register: 10050

- 1. 10050, B
- 2. 10110, C
- 3. 20000, D



- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register
 - Others stay in linked list, sorted by expiration

Timer Requests	CC Register: 10050
1. 10050, B 2. 10110, C 3. 20000, D	Call timer handler B! Update CC register and list




time

- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register
 - Others stay in linked list, sorted by expiration


Timer Requests CC Register: 10110

- 1. 10110, C
- 2. 20000, D



- Solution: keep a list of timer expiration times
 - Soonest expiration goes in the Capture/Compare register
 - Others stay in linked list, sorted by expiration

Timer Requests	CC Register: 10100
1. 10100, E	New request arrives for 10100
2. 10110, C	Enqueue and sort queue
3. 20000, D	Update CC if first request has changed



time

Enqueuing timer requests

- Timer requests come in the form: {N seconds from now}
 - timer_request(duration, handler);
- Requests are always relative to the current time
- Need to enqueue by expiration time
 - Duration + Current Time
 - Allows for a globally sortable list
 - Need to decide how to handle overflow logic in real world

Make sure not to miss timers

- Sorting list and modifying the CC register takes time
 - Might have skipped right past the soonest event
 - Check for this, and call handler manually if necessary

Timer Requests	CC Register: 10100
1. 10100, E 2. 10110, C 3. 20000, D	Handle 10100 event, Call E



Make sure not to miss timers

- Sorting list and modifying the CC register takes time
 - Might have skipped right past the soonest event

Timer Requests	CC Register: 10110
1. 10110, C 2. 20000, D	Update list Update CC register Oh no! That's in the past!!



Break + Question

- Sorting list and modifying the CC register takes time
 - Might have skipped right past the soonest event
- What do we do about the missed timer?
 - There are multiple "correct" answers here

Break + Question

- Sorting list and modifying the CC register takes time
 - Might have skipped right past the soonest event
- What do we do about the missed timer?
 - There are multiple "correct" answers here

Some options:

- Just call handle that timer event as soon as possible
 - Possibly telling it about the delay
- Crash the system! (Deadlines cannot be missed in some systems)
 - Or at least enter some fault recovery handler

Make sure not to miss timers

- Sorting list and modifying the CC register takes time
 - Might have skipped right past the soonest event
 - Check for this, and call handler manually if necessary

Timer Requests

CC Register: 20000

1. 20000, D

Call C manually
Update list and CC register again



Some timers are periodic

- Repeating timers are easy to add to this system
 - Include a Boolean for "repeating" and the duration in the request
- When timer expires
 - If not repeating, just call handler and then drop it
 - If repeating,
 - First reinsert based on duration and new current time
 - Then call the handler
 - Don't want the latency of the handler to slow us down

Concurrency safety

- Modifying the request structure in an interrupt context is dangerous
 - New request might be in the middle of getting added
 - Interrupt would run right in the middle of that
 - Literally an OS data race example
- Solution: disable interrupts during critical section
 - Whenever editing request structure
 - Enable interrupts after, which may result in an event
 - Note: Interrupt handler might now fire but have no work to do. Should always check if something should actually be handled first

Outline

Clocks

Timers


Virtualizing Resources

Real-Time Counter

Watchdog

Real-time Counter

- Low-power (32 kHz) version of Timer
 - Only a 24-bit internal Counter



Note: abbreviated RTC, but that already means something else (Real-Time Clock)

Differences between Real-Time Counter and Timer

- Runs off of LFCLK instead of HFCLK
 - With smaller prescaler value (4096 vs 32768)
- 24-bit counter vs 32-bit counter for Timer

- Can read the Counter value directly
 - No need for Capture task
- Otherwise extremely similar. Just a low-power version of Timer

Time resolution for Real-Time Counter

$$f_{\text{TIMER}} = \frac{32 \text{ KHz}}{Prescaler+1}$$

- Resolution
 - Minimum: 30.517 μs ticks, overflows in 512 seconds (24-bit Counter)
 - Maximum: 125 ms ticks, overflows in 582 hours
- Not as precise as the Timer (which has 62.5 ns best precision)
 - Possible design: use both
 - Real-Time Counter for most of the waiting
 - Chained into Timer for precise remaining amount of time

Comparing timer types

- Real-Time Counter
 - Low precision and duration
 - Low energy
- Timer
 - High precision or duration
 - High energy

nRF SDK Virtualized Timers: APP_TIMER

- Runs off the RTC
- APP_TIMER_DEF creates a node for the timer and initializes it
- app_timer_create inserts the node in an internal linked list
- app_timer_start actually starts running the timer
- SDK documentation

```
// Create a new timer instance
APP TIMER DEF(my timer);
int main(void) {
  // Initialize the timer library
  app timer init();
  // Initialize a timer instance
  // Mode: single or repeated
  // Callback function: called on expiration
  app timer create (&my timer,
                   APP TIMER MODE REPEATED,
                   callback function);
  // Start a timer
  // Duration: 32768 ticks per second
  app timer start(my timer, 32768, NULL);
```

For example code, in nu-microbit-base see: apps/app_timer_example/main.c

Outline

Clocks

Timers

Virtualizing Resources

Real-Time Counter

Watchdog

Reliable systems

- What's the most common way to solve computer problems?
 - Turn it off and turn it on again.

· Why?

Reliable systems

- What's the most common way to solve computer problems?
 - Turn it off and turn it on again.

• Why?

- Resets "state" to original values, which are likely good
 - Startup is often well-tested
 - It's long-running code interacting in unexpected ways that leaves systems in a broken state

Watchdog timer (WDT)

- Focused on failures where the system "hangs" forever
 - Maybe software, maybe hardware!

- Can't know for certain the system is hung, but can know practically
 - Select a timeout that is the maximum amount of time you expect the system to ever go without looping in main()
 - Multiply it by 2-10
 - Set a watchdog timer to that value
- If watchdog timer ever expires, it resets the system (in hardware)

Watchdog configuration

timeout (seconds) =
$$\frac{Counter\ Reload\ Value + 1}{32768}$$

- Configure watchdog
 - Can choose whether to count down during Sleep mode or Debug mode
- Set a Counter Reload Value (CRV, 32-bits)
- Start the watchdog timer
 - Loads internal Counter to CRV value
 - Starts counting down at 32 kHz

Running applications with a watchdog timer

- Need to periodically reset the watchdog to keep it from expiring
 - Known as "feeding" the watchdog or "kicking" the watchdog
- Reload Request register
 - Must write sequence 0x6E524635 to reload watchdog ("nRF5")
 - Incredibly unlikely to happen by accident
- While running, watchdog is protected from modification
 - Configure once, run forever (at least until a reboot)
 - Only option is to make periodic Reload Requests
- Default off on the nRF52833 (default on for the MSP430!)

Outline

Clocks

• Timers

Virtualizing Resources

Real-Time Counter

Watchdog