Lecture 10 Analog Output

CE346 – Microprocessor System Design Branden Ghena – Fall 2024

Some slides borrowed from: Josiah Hester (Northwestern), Prabal Dutta (UC Berkeley)

Administrivia

- Design presentations all next week!
 - Happy to discuss things before then via Piazza
 - I will provide individual group feedback as I get time to

- Drop deadline is Friday next week
 - I'm not worried about anyone in CE346
 - But if you're worried, I'm happy to talk about it.

Today's Goals

Explore common methods for generating analog signals

Understand the role of Digital-to-Analog converters

- Discuss the concepts of Pulse-Width Modulation
 - And the nRF52 implementation of it

Outline

Digital-to-Analog Converters


Pulse-Width Modulation

nRF52 PWM

Digital-to-Analog Converters

Generates an analog voltage

- DACs are conceptually the inverse of ADCs
 - Number of bits of resolution choose analog step size
 - Frequency determines step duration



High resolution versus high frequency

What role does each play in a DAC?
 Which is more important?

High resolution can accurately represent a voltage


High frequency can accurately represent a changing voltage


- In practice:
 - Need high enough resolution, then as high of frequency as possible

Infinite resolution is not sufficient

- DAC frequency corresponds to representable signal changes
 - Rise and fall times


 Even an infinite resolution DAC cannot represent a signal if it is not fast enough






Low-pass filter smooths output

- Low-pass filter delays changes in voltage and smoothly transitions between them
 - Low-frequency signals stay
 - High-frequency are smoothed
- Greatly improves quality of output but must be tuned to the desired signal frequency
 - Usually not included in microcontroller






Resistor string DAC

- Use series of voltage dividers and switches to set output voltage
 - Generates equally spaced voltages that can be selected between

 Needs output buffer to provide stable current


- Takes a lot of resistors
 - And resistors take a lot of silicon



Resistor string example

•
$$V_{out} = code * \frac{V_{ref}}{2^{resolution}}$$

- Input code is 101
 - Selects switches such that 5/8*V_{ref} is connected to output



Break + DAC applications

What do you use an analog output for?

Break + DAC applications

- What do you use an analog output for?
 - Audio output
 - But it needs to be high quality (resolution and speed)
 - Motors
 - But only with a controller that actually drives them with enough current
 - LED brightness
 - Not Much
 - And these last two can be done more easily with PWM

DACs are not in all microcontrollers

- Not rare, but not ubiquitous either
 - Every microcontroller has GPIO
 - Just about every microcontroller has an ADC
 - Some microcontrollers have DACs (the nRF52833 does not!)

Reasons

- Hardware is complicated (but we could fit it if we wanted)
- Use cases are uncommon (and might need very high quality)
 - Many devices can be controller digitally
- Pulse-Width Modulation (PWM) can emulate usably analog signals

Outline

Digital-to-Analog Converters


Pulse-Width Modulation


• nRF52 PWM

Pulse-Width Modulation


 Much easier to control high or low than an analog output

- Idea: modify how long a signal is high within some switching frequency, a.k.a duty cycle
 - On 50% of the time for half voltage
 - On 10% of the time for tenth voltage
- Duty cycle, not frequency!





PWM to Analog Signal example




- PWM period should be much faster than the desired analog signal
 - PWM duty cycle represents the voltage along the way
 - Multiple duty cycles per output point makes it more accurate


Low-pass approach works here too

Importantly, many devices are inherent low-pass filters

- Heaters, Motors
 - Low-pass by physical design
 - I.e., they can't start/stop quickly


- LEDs are not
 - But our eyes are!





Controlling PWM

- Vary duty cycle by selecting transition points
 - Time when set
 - Time when unset
- Repeat every cycle
 - Period much faster than signal if possible
 - Makes analog approximation more accurate
 - The faster you run it, the less likely it matters that it is not actually analog
 - Example: LED switching frequency
- Duty cycle could vary cycle-by-cycle if it must




PWM alignment

- Can select alignment as well
 - Equivalent to a phase delay

- Centering produces cleaner analog output
 - Less harmonics

Not relevant for most devices



Every microcontroller can do PWM

- Not every microcontroller has a PWM peripheral
- But every microcontroller has timers and digital outputs

- All that is needed is a GPIO and a Timer (or two)
 - Timer determines when to turn GPIO on and off
 - Often can be automated in hardware rather than using an interrupt
 - Connect timer expiration to GPIO toggling

PWM is an example of encoding data on a signal

PWM is a pulse-width modulated signal

- There are many other ways to "modulate" a signal to transmit data
 - Amplitude, Frequency, and Phase are common
 - Layers data on top of an existing "carrier signal"
- Used especially for high-speed communication
 - Wired (cable lines) or Wireless (basically everything)

PWM applications


- Servos
 - Duty cycle chooses angle or rotation speed
- Motor controllers
 - Duty cycle chooses current and therefore speed
- LED brightness
 - And "breathing" effect
- Audio
 - Can sound okay if frequency is high enough

Controlling LED Matrix brightness

- Option 1: PWM peripheral
 - Need to use multiple PWM peripherals to get 5 pins to control each LED
 - Alternatively, could only control brightness for the entire matrix
 - Then use a single PWM output to control the row
 - When timer fires, change which row pin is used for PWM
- Option 2: do it manually (instead of PWM peripheral)
 - Need to apply duty cycle on top of the existing stepping through rows
 - Add 5 new one-shot app timers, one for each column
 - Fire some percentage into the time the LED is active (within the 2 ms)
 - Use to toggle individual column LED back to off
 - Result: the LED is on for some portion of the time it should be active

Break + Open Question

- Imagine you want to represent the following signal with PWM
 - What should the PWM period be?




• What kinds of duty cycle values would you use? (3.3v is 100%)

Break + Open Question

- Imagine you want to represent the following signal with PWM
 - What should the PWM period be?
 - Signal period is ~10 μs
 - PWM period should be at least 2x that
 - 10x faster seems like a good start
 - Then if we want multiple PWM outputs per sample, that's ~20-40x faster



- 2/3.3 = 61% duty cycle max
- 0/3.3 = 0% duty cycle min



Outline

Digital-to-Analog Converters

Pulse-Width Modulation

nRF52 PWM

nRF52 PWM – theory of operation

- A clock continuously adds to a counter value
 - (just like the Timer peripheral does)


 When the counter value reaches COMP[n], the GPIO value on channel n changes from high to low (or vice-versa)

- When the counter value reaches COUNTERTOP, the GPIO value on channel n changes from low to high (or vice-versa)
 - AND the counter value resets to zero

nRF52 PWM peripheral

- Uses internal timer to create PWM output on up to 4 pins
 - 4 peripherals, so up to 16 pins total


 Loads compare values via DMA to rapidly vary "analog" signal



PWM example

 Counter increments up to COUNTERTOP, resets and continues

- Period/Frequency
 - Chosen by COUNTEROP and timer PRESCALER




PWM example

 Counter increments up to COUNTERTOP, resets and continues

- Duty Cycle
 - COMP0 chooses first toggle point for OUT[0]
 - Second toggle point is when the timer resets

(right-aligned) COMP =COUNTERTOP - (COUNTERTOP * DutyCycle)

(left-aligned) COMP =COUNTERTOP * DutyCycle




Center-aligned PWM

 Up-and-down mode enables center-aligned PWM


- Duty Cycle
 - Comp triggers toggle on rise
 - Comp triggers toggle again on fall

COMP = COUNTERTOP - (COUNTERTOP * 0.5 * DutyCycle)




Trading speed and accuracy

- How do you get the most accurate PWM values?
 - Select the largest COUNTERTOP possible
 - Most possible COMP values
 - Up to 15-bit resolution (32767 max)
- How do you get the fastest PWM frequency?
 - Select the smallest COUNTERTOP possible
 - PRESCALER also affects this
 - 16 MHz 128 kHz (8 possible values)
- Fastest PRESCALER + largest COUNTERTOP equals 488 Hz
 - Likely need to sacrifice resolution for speed



DMA with PWM

- Every N periods it loads a new configuration from RAM
 - N combined with PRESCALER and COUNTERTOP chooses "analog signal" period
- Configuration sets COMP values for each output channel
 - Also sets polarity (starting value: low or high)
- Application of memory loads to channels is configurable



Waveform mode

Also has the option to change COUNTERTOP every N PWM periods

- Allows arbitrary waveforms to be created
 - Frequency changes every period
 - Duty cycle can also change each period
- We don't normally need this, as a constant frequency with changing duty cycle should be fine

P COMPARE COMPARE COMP1 COMPARE COMP2

DECORER LOAD=WaveForm

TOP

COUNTERTOP

Other configurations

- How many times the entire DMA sequence repeats
 - 0 to large number, infinite with a configuration in SHORTS
- How long to delay between repeating sequence cycles
 - Repeats last PWM configuration
- Two DMA sequence configurations (0 and 1)
 - Can modify one while the other is playing "Double Buffering"
 - Allows continuous signal (for example, music)

nRF SDK PWM driver

https://infocenter.nordicsemi.com/index.jsp?topic=%2Fsdk_nrf5_v16.0.0%2Fgroup_nrfx_pwm.html

- Initialize PWM with base configuration
 - Output pins, Clock frequency, COUNTERTOP, DMA grouping mode
 - Handler for events from peripheral
- nrfx_pwm_simple_playback(instance, sequence, count, flags)
 - Instance: pointer to global variable with registers
 - Sequence: struct containing sequence to be played (see next slide)
 - Count: number of times (1 or more) to repeat sequence
 - Flags: stop peripheral when done, loop forever, various events

Sequence struct

Data Fields


- values: pointer to array of uint16_t values (union of types)
- length: length of array
- repeats: number of times to repeat each individual value
 - Sets period for "analog value" changing

Example, playing a note with a square wave


- Pick PWM frequency to match note frequency
 - Combination of PRESCALER, COUNTERTOP, and repeats
 - 440 Hz for the note A
 - PRESCALER 1 MHz, COUNTERTOP 2273 -> 440 Hz
- Set duty cycle of PWM to control volume
 - 50% duty cycle -> COMP value of 1137
- Set sequence with an array of length 1, content is {1137} (polarity 0)
 - Repeats 0, end_delay 0
- Set playback_count to 1 and flags to NRFX_PWM_FLAG_LOOP

Playing sine waves instead of square waves

- Sine waves sound different than square waves
 - Sine is more smooth
 - Square is more harsh and buzzy



For better sound quality, we can play sine waves via PWM



Steps to playing a note with a sine wave

- 1. Calculate sine wave values for some amount of duration
 - Reasonable to calculate one second of data at a time
 - sin() function might be too slow here
 - Instead calculate sine values in advance and interpolate into an array based on frequency
- 2. Translate sine wave values into duty cycle values
 - Fill an array with these duty cycle values
- 3. Play the array of duty cycle values
 - That gets one second of audio
 - For music, might change schedule a timer for when to stop current playback and play the next note instead

Outline

Digital-to-Analog Converters

Pulse-Width Modulation

• nRF52 PWM