Lecture 11 Analog Output

CE346 – Microprocessor System Design Branden Ghena – Spring 2021

Some slides borrowed from: Josiah Hester (Northwestern), Prabal Dutta (UC Berkeley)

Administrivia

- Bug in the breadboarding lab! See campuswire post
 - Analog input pins are specified with an enum type, not as GPIO pin numbers

Today's Goals

Explore common methods for generating analog signals

Understand the role of Digital-to-Analog converters

- Discuss the concepts of Pulse-Width Modulation
 - And the nRF52 implementation of it

Outline

Digital-to-Analog Converters


Pulse-Width Modulation

• nRF52 PWM

Digital-to-Analog Converters

Generates an analog voltage

- DACs are conceptually the inverse of ADCs
 - Number of bits of resolution choose analog step size
 - Frequency determines quality of waveform




Resistor string DAC

- Use series of voltage dividers and switches to set output voltage
 - Generates equally spaced voltages that can be selected between

 Needs output buffer to provide stable current


- Takes a lot of resistors
 - And resistors take a lot of silicon



Resistor string example

•
$$V_{out} = code * \frac{V_{ref}}{2^{resolution}}$$

- Input code is 101
 - Selects switches such that 5/8*V_{ref} is connected to output



High resolution versus high frequency

What role does each play in a DAC?
 Which is more important?

High resolution versus high frequency

What role does each play in a DAC?
 Which is more important?

High resolution can accurately represent a voltage


High frequency can accurately represent a changing voltage


- In practice:
 - Need high enough resolution, then as high of frequency as possible

Infinite resolution is not sufficient

- DAC frequency corresponds to representable signal changes
 - Rise and fall times


 Even an infinite resolution DAC cannot represent a signal if it is not fast enough






Low-pass filter smooths output

- Low-pass filter delays changes in voltage and smoothly transitions between them
 - Low-frequency signals stay
 - High-frequency are smoothed
- Greatly improves quality of output but must be tuned to the desired signal frequency
 - Usually not included in microcontroller





DAC applications

- What do you use an analog output for?
 - Audio output
 - But it needs to be high quality (resolution and speed)
 - Motors
 - But only with a controller that actually drives them with enough current
 - LED brightness
 - Not Much
 - And these last two can be done more easily

DACs are uncommon in microcontrollers

- Not rare, but not ubiquitous either
 - Every microcontroller has GPIO
 - Just about every microcontroller has an ADC
 - Some microcontrollers have DACs

Reasons

- Hardware is complicated (but we could fit it if we wanted)
- Use cases are uncommon (and might need very high quality)
 - Many devices can be controller digitally
- Pulse-Width Modulation (PWM) can emulate usably analog signals

Outline

Digital-to-Analog Converters


Pulse-Width Modulation


• nRF52 PWM

Pulse-Width Modulation


 Much easier to control high or low than an analog output

- Idea: modify how long a signal is high within some switching frequency, a.k.a duty cycle
 - On 50% of the time for half voltage
 - On 10% of the time for tenth voltage
- Duty cycle, not frequency!





Analog to PWM example





Low-pass approach works here too

Importantly, many devices are inherent low-pass filters

Heaters, Motors


- LEDs are not
 - But our eyes are!





Controlling PWM

- Vary duty cycle by selecting transition points
 - Time when set
 - Time when unset
- Repeat every cycle
 - Period much faster than signal if possible
 - Makes analog approximation more accurate
 - Example: LED switching frequency
- Duty cycle could vary cycle-by-cycle if it must




PWM alignment

- Can select alignment as well
 - Equivalent to a phase delay

- Centering produces cleaner analog output
 - Less harmonics

Not relevant for most devices



Every microcontroller can do PWM

- Not every microcontroller has a PWM peripheral
- But every microcontroller has timers and digital outputs

- But all that is need is a GPIO and a Timer (or two)
 - Timer determines when to turn GPIO on and off
 - Often can be automated in hardware rather than use interrupt handler

PWM is a method of encoding data

PWM is a pulse-width modulated signal

- There are many other ways to "modulate" a signal to transmit data
 - Amplitude, Frequency, and Phase are common
 - Layers data on top of an existing "carrier signal"
- Used especially for high-speed communication
 - Wired (cable lines) or Wireless (basically everything)

PWM applications

- Servos
 - Duty cycle chooses angle
- Motor controllers
 - Duty cycle chooses current and therefore speed
- LED brightness
 - And "breathing" effect
- Audio
 - Can sound okay if frequency is high enough

Outline

Digital-to-Analog Converters


Pulse-Width Modulation

nRF52 PWM

nRF52 PWM peripheral

 Uses internal timer to create PWM output on up to 4 pins


 Loads compare values via DMA to rapidly vary "analog" signal



PWM example

 Counter increments up to COUNTERTOP, resets and continues

- Frequency
 - Chosen by COUNTEROP and timer PRESCALER




PWM example

 Counter increments up to COUNTERTOP, resets and continues

- Duty Cycle
 - COMP0 chooses first toggle point for OUT[0]
 - Second toggle point is when the timer resets

(right-aligned) COMP =COUNTERTOP - (COUNTERTOP * DutyCycle)

(left-aligned) COMP =COUNTERTOP * DutyCycle




Center-aligned PWM

 Up-and-down mode enables center-aligned PWM


- Duty Cycle
 - Comp triggers toggle on rise
 - Comp triggers toggle again on fall

```
COMP =
COUNTERTOP - (COUNTERTOP * 0.5 * DutyCycle)
```




Trading speed and accuracy

- How do you get the most accurate PWM values?
 - Select the largest COUNTERTOP possible
 - Most possible COMP values
 - Up to 15-bit resolution (32767 max)
- How do you get the fastest PWM frequency?
 - Select the smallest COUNTERTOP possible
 - PRESCALER also affects this
 - 16 MHz 128 kHz (8 possible values)
- Fastest PRESCALER + largest COUNTERTOP equals 488 Hz
 - Likely need to sacrifice resolution for speed



DMA with PWM


- Every N periods it loads a new configuration from RAM
 - N combined with PRESCALER and COUNTERTOP chooses "analog signal" period
- Configuration sets COMP values for each output channel
 - Also sets polarity (starting value: low or high)
- Application of memory loads to channels is configurable



Waveform mode

Also has the option to change COUNTERTOP every N PWM periods

- Allows arbitrary waveforms to be created
 - Frequency changes every period
 - Duty cycle can also change each period



Other configurations

- How many times the entire DMA sequence repeats
 - 0 to large number, infinite with a configuration in SHORTS
- How long to delay between repeating sequence cycles
 - Repeats last PWM configuration
- Two DMA sequence configurations (0 and 1)
 - Can modify one while the other is playing
 - Allows continuous signal (for example, music)

nRF SDK PWM driver

https://infocenter.nordicsemi.com/index.jsp?topic=%2Fsdk_nrf5_v16.0.0%2Fgroup_nrfx_pwm.html

- Initialize PWM with base configuration
 - Output pins, Clock frequency, COUNTERTOP, DMA grouping mode
 - Handler for events from peripheral
- nrfx_pwm_simple_playback(instance, sequence, count, flags)
 - Instance: pointer to global variable with registers
 - Sequence: struct containing sequence to be played (see next slide)
 - Count: number of times (1 or more) to repeat sequence
 - Flags: stop peripheral when done, loop forever, various events

Sequence struct

Data Fields

```
nrf_pwm_values_t values
Pointer to an array with duty cycle values. This array must be in Data RAM. More...

uint16_t length
Number of 16-bit values in the array pointed by values.

uint32_t repeats
Number of times that each duty cycle is to be repeated (after being played once). Ignored in NRF_PWM_STEP_TRIGGERED mode.

uint32_t end_delay
Additional time (in PWM periods) that the last duty cycle is to be kept after the sequence is played. Ignored in NRF_PWM_STEP_TRIGGERED mode.
```

- values: pointer to array of uint16_t values (union of types)
- length: length of array
- repeats: number of times to repeat each individual value
 - Sets period for "analog value" changing

Example, playing a note

- Pick PWM frequency to match note frequency
 - Combination of PRESCALER, COUNTERTOP, and repeats
 - 440 Hz for the note A
 - PRESCALER 1 MHz, COUNTERTOP 227 -> 4.40 kHz
 - repeats = 10 -> 440 Hz (in case we're changing notes)
- Set duty cycle of PWM to control volume
 - 50% duty cycle -> COMP value of 113
- Set sequence with an array of length 1, content is {113} (polarity 0)
 - Repeats 10, end_delay 0
- Set playback_count to 1 and flags to NRFX_PWM_FLAG_LOOP

Controlling LED Matrix brightness

- Option 1: PWM peripheral
 - Only 4 output pins though
 - Could only allow brightness to be controlled for the entire matrix
 - Then use a single PWM output to control the row
 - When timer fires, change which row pin is used for PWM
- Option 2: do it manually (for individual control)
 - Can't determine duty cycle when the row is turned on
 - Each row already at 100 Hz, duty cycling would be slower and visible
 - Instead add 5 new one-shot app timers, one for each column
 - Fire at some time while the row is active (within that 2 ms)
 - Use to toggle column LED back to off

Outline

Digital-to-Analog Converters

Pulse-Width Modulation

• nRF52 PWM