# **■** NetApp

## Reference & Support

**Cloud Insights** 

NetApp May 05, 2022

This PDF was generated from https://docs.netapp.com/us-en/cloudinsights/concept\_requesting\_support.html on May 05, 2022. Always check docs.netapp.com for the latest.

## **Table of Contents**

R	Reference & Support	1
	Requesting Support	1
	Cloud Insights Data Collector Support Matrix	5
	Data Collector Reference - Infrastructure	6
	Data Collector Reference - Services	)5
	Object Icon Reference	35

## Reference & Support

## **Requesting Support**

You can access support options in Cloud Insights by clicking on **Help > Support**. The support options available to you depend on whether you are in Trial mode or Subscription mode.

Cloud Insights Support  NetApp Serial Number:	3-9883-918f1d703288 th NetApp through chat, ticket or phone.	Contact Us  Need help with Cloud Insights?  Technical Support: Open a Support Ticket   Phone (P1)	Sales: Have questions regarding your subscription? Contact Sales,
Knowledge Base  Search through the Cloud Insights Knowledge Base to find helpful articles.	Documentation Center  Visit the Cloud Insights Documentation Center to find step by step instructions to help you get the most out of Cloud Insights.	Communities  Join the Cloud Insights Community to foll ongoing discussions or create a new one.	

### **Activating support entitlement**

Cloud Insights offers self-service and email support when running in trial mode. Once you have subscribed to the service, it is strongly recommended that you activate support entitlement. Activating support entitlement enables you to access technical support over the online chat, the web ticketing system, and the phone. The default support mode is self-service until registration is completed. See details below.

During the initial subscription process, your Cloud Insights instance will generate a 20-digit NetApp serial number starting with "950". This NetApp serial number represents the Cloud Insights subscription associated with your account. You must register the NetApp serial number to activate support entitlement. We offer two options for support registration:

- 1. User with pre-existing NetApp Support Site (NSS) SSO account (e.g. current NetApp customer)
- 2. New NetApp customer with no pre-existing NetApp Support Site (NSS) SSO account

Option 1: Steps for a user with a pre-existing NetApp Support Site (NSS) SSO account

#### **Steps**

- 1. Navigate to the NetApp registration website https://register.netapp.com
- 2. Select "I am already registered as NetApp Customer" and choose Cloud Insights as the Product Line. Select your Billing Provider (NetApp or AWS) and provide your Serial Number and your NetApp Subscription Name or AWS Customer ID by referring to the "Help > Support" menu within the Cloud Insights user interface:

## **Cloud Insights Support**

NetApp Serial Number: NetApp Subscription Name:

95011122233344455512 A-000012345

Support activation is required to enable support with NetApp through chat, ticket or phone. Activate Support at register.netapp.com.

V

Check this box to allow NetApp access to your instance of Cloud Insights.

3. Complete the Existing Customer Registration form and click **Submit**.



- 4. If no errors occur, user will be directed to a "Registration Submitted Successfully" page. The email address associated with the NSS SSO username used for registration will receive an email within a couple minutes stating "your product is now eligible for support".
- 5. This is a onetime registration for the Cloud Insights NetApp serial number.

Option 2: Steps for a new NetApp customer with no pre-existing NetApp Support Site (NSS) SSO account

#### Steps

- 1. Navigate to the NetApp registration website https://register.netapp.com
- 2. Select "I am not a registered NetApp Customer" and complete the required information in example form below:

IMPORTANT: After submitting, a confirmation email will be sent to the email address filled-in the form. Please click the validation link in that email to complete the registration.			
ne fields marked with * are ma	ndatory		
rst Name*			
ast Name*			
ompany*			
mail Address*			
ffice Phone*			
ternate Phone			
ddress Line 1*			
ddress Line 2			
ostal Code / City*			
ate/Province / Country*		- Select -	•
etApp Reference SN			
	If you currently own a NetApp product, please provide the Serial Number for that product here in order to speed-up the validation process		
roduct Line*	Cloud Insights		▼
lling Provider *	NetApp		•
oud Insights Serial # * ①	e.g. 950122350213	03893918	
etApp Subscription Name * ①	e.g. A-S0000100		
	Add another Serial #		ther Serial #

 Select Cloud Insights as the Product Line. Select your Billing Provider (NetApp or AWS) and provide your Serial Number and your NetApp Subscription Name or AWS Customer ID by referring to the "Help > Support" menu within the Cloud Insights user interface:



- 2. If no errors occur, user will be directed to a "Registration Submitted Successfully" page. The email address associated with the NSS SSO username used for registration will receive an email within a few hours stating "your product is now eligible for support".
- 3. As a new NetApp customer, you will also need to create a NetApp Support Site (NSS) user account for future registrations and access to support portal for technical support chat and web ticketing. This link is located at https://mysupport.netapp.com/eservice/public/now.do. You can provide your newly registered Cloud Insights serial number to expedite the process.
- 4. This is a one-time registration for the Cloud Insights NetApp serial number.

#### **Obtaining Support Information**

NetApp provides support for Cloud Insights in a variety of ways. Extensive free self-support options are available 24x7, such as knowledgebase (KB) articles or the NetApp community. For users who are subscribed to any of the Cloud Insights Editions (Basic, Standard, Premium), technical support is available via phone or web ticketing. A NetApp Support Site (NSS) SSO account is required for web ticket along with case management.

#### **Self-Service Support:**

These support options are available in Trial mode and are available for free 24x7:

#### Knowledgebase

Clicking the links in this section takes you to the NetApp Knowledgebase, where you can search through relevant articles, how-to's, and more.

#### Documentation

Clicking on the Documentation link takes you to this documentation center.

#### Community

Clicking on the community link takes you to the NetApp Cloud Insights community, where you can connect with peers and experts.

There is also a link to provide xref:./Feedback to help us improve Cloud Insights.

#### **Subscription Support**

In addition to the self-support options above, if you have a Cloud Insights subscription or paid support for monitored NetApp products or services, you can work with a NetApp Support Engineer to resolve your problem.



You must register in order to activate support for NetApp Cloud products. To register, go to NetApp's Cloud Data Services Support Registration.

It is highly recommended that you check the box to allow a NetApp Support Engineer access to your Cloud Insights environment during your support session. This will allow the engineer to troubleshoot the problem and help you resolve it quickly. When your issue is resolved or your support session has ended, you can un-check the box.

You can request support by any of the following methods. You must have an active Cloud Insights subscription

to use these support options:


- Phone
- Support Ticket

You can also request sales support by clicking on the Contact Sales link.

Your Cloud Insights serial number is visible within the service from the **Help > Support** menu. If you are experiencing issues accessing the service and have registered a serial number with NetApp previously, you can also view your list of Cloud Insights serial numbers from the NetApp Support Site as follows:

- · Login to mysupport.netapp.com
- From the Products > My Products menu tab, use Product Family "SaaS Cloud Insights" to locate all your registered serial numbers:

### View Installed Systems



If you see any discrepancies or errors in the information shown below, please submit Feedback and be sure to include the serial nu

## **Cloud Insights Data Collector Support Matrix**

You can view or download information and details about supported Data Collectors in the Cloud Insights Data Collector Support Matrix.

## **Cloud Insights Data Collector Support Matrix**

The Data Collector Support Matrix provides reference for Data Collectors supported by cloud Insights, including vendor and model information.

The matrix is provided in .PDF format.

Click the link to open.

Right-click and choose Save as... to download a copy.

**Data Collector Support Matrix** 

## **Data Collector Reference - Infrastructure**

#### **Vendor-Specific Reference**

The topics in this section provide vendor-specific reference information. In most cases, configuring a data collector is straightforward. In some cases, you may need additional information or commands to properly configure the data collector.

Click on a **vendor** in the menu to the left to see information for their data collectors.

#### Configuring the Amazon EC2 data collector

Cloud Insights uses the Amazon EC2 data collector to acquire inventory and performance data from EC2 instances.

#### Requirements

In order to collect data from Amazon EC2 devices, you must have the following information:

- · You must have one of the following:
  - The IAM Role for your Amazon EC2 cloud account, if using IAM Role Authentication. IAM Role only
    applies if your acquisition unit is installed on an AWS instance.
  - The IAM Access Key ID and Secret Access Key for your Amazon EC2 cloud account, if using IAM Access Key authentication.
- · You must have the "list organization" privilege
- Port 443 HTTPS
- EC2 Instances can be reported as a Virtual Machine, or (less naturally) a Host. EBS Volumes can be reported as both a VirtualDisk used by the VM, as well as a DataStore providing the Capacity for the VirtualDisk.

Access keys consist of an access key ID (for example, AKIAIOSFODNN7EXAMPLE) and a secret access key (for example, wJalrXUtnFEMI/K7MDENG/bPxRfiCYEXAMPLEKEY). You use access keys to sign programmatic requests that you make to EC2 if you use the Amazon EC2 SDKs, REST, or Query API operations. These keys are provided with your contract from Amazon.

#### Configuration

Enter data into the data collector fields according to the table below:

Field	Description
AWS Region	Choose AWS region
IAM Role	For use only when acquired on an AU in AWS. See below for more information on IAM Roles.
AWS IAM Access Key ID	Enter AWS IAM Access Key ID. Required if you do not use IAM Role.
AWS IAM Secret Access Key	Enter AWS IAM Secret Access Key. Required if you do not use IAM Role.

Field	Description
I understand AWS bills me for API requests	Check this to verify your understanding that AWS bills you for API requests made by Cloud Insights polling.

#### **Advanced Configuration**

Field	Description
Include Extra Regions	Specify additional regions to include in polling.
Cross Account Role	Role for accessing resources in different AWS accounts.
Inventory Poll Interval (min)	The default is 60
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Tags	Specify whether to include or exclude VM's by Tags when collecting data. If 'Include' is selected, the Tag Key field can not be empty.
Tag Keys and Values on which to Filter VMs	Click + Filter Tag to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of tags on the VM. Tag Key is required, Tag Value is optional. When Tag Value is empty, the VM is filtered as long as it matches the Tag Key.
Performance Poll Interval (sec)	The default is 1800
CloudWatch Agent Metrics Namespace	Namespace in EC2/EBS from which to collect data. Note that if the names of the default metrics in this namespace are changed, Cloud Insights may not be able to collect that renamed data. It is recommended to leave the default metric names.

#### **IAM Access Key**

Access keys are long-term credentials for an IAM user or the AWS account root user. Access keys are used to sign programmatic requests to the AWS CLI or AWS API (directly or using the AWS SDK).

Access keys consist of two parts: an access key ID and a secret access key. When you use *IAM Access Key* authentication (as opposed to *IAM Role* authentication), you must use both the access key ID and secret access key together for authentication of requests. For more information, see the Amazon documentation on Access Keys.

#### **IAM Role**

When using *IAM Role* authentication (as opposed to IAM Access Key authentication), you must ensure that the role you create or specify has the appropriate permissions needed to access your resources.

For example, if you create an IAM role named *InstanceEc2ReadOnly*, you must set up the policy to grant EC2 read-only list access permission to all EC2 resources for this IAM role. Additionally, you must grant STS (Security Token Service) access so that this role is allowed to assume roles cross accounts.

After you create an IAM role, you can attach it when you create a new EC2 instance or any existing EC2 instance.

After you attach the IAM role *InstanceEc2ReadOnly* to an EC2 instance, you will be able to retrieve the temporary credential through instance metadata by IAM role name and use it to access AWS resources by any application running on this EC2 instance.

For more information see the Amazon documentaiton on IAM Roles.

Note: IAM role can be used only when the Acquisition Unit is running in an AWS instance.

#### **Mapping Amazon tags to Cloud Insights annotations**

The Amazon EC2 data collector includes an option that allows you to populate Cloud Insights annotations with tags configured on EC2. The annotations must be named exactly as the EC2 tags. Cloud Insights will always populate same-named text-type annotations, and will make a "best attempt" to populate annotations of other types (number, boolean, etc). If your annotation is of a different type and the data collector fails to populate it, it may be necessary to remove the annotation and re-create it as a text type.

Note that AWS is case-sensitive, while Cloud Insights is case-insensitive. So if you create an annotation named "OWNER" in Cloud Insights, and tags named "OWNER", "Owner", and "owner" in EC2, all of the EC2 variations of "owner" will map to Cloud Insight's "OWNER" annotation.

#### **Include Extra Regions**

In the AWS Data Collector **Advanced Configuration** section, you can set the **Include extra regions** field to include additional regions, separated by comma or semi-colon. By default, this field is set to **us-.\***, which collects on all US AWS regions. To collect on **all** regions, set this field to **.\***.

If the **Include extra regions** field is empty, the data collector will collect on assets specified in the **AWS Region** field as specified in the **Configuration** section.

#### **Collecting from AWS Child Accounts**

Cloud Insights supports collection of child accounts for AWS within a single AWS data collector. Configuration for this collection is performed in the AWS environment:

- You must configure each child account to have an AWS Role that allows the main account ID to access EC2 details from the children account.
- · Each child account must have the role name configured as the same string.
- Enter this role name string into the Cloud Insights AWS Data Collector Advanced Configuration section, in the Cross account role field.

Best Practice: It is highly recommended to assign the AWS predefined *AmazonEC2ReadOnlyAccess* policy to the EC2 main account. Also, the user configured in the data source should have at least the predefined *AWSOrganizationsReadOnlyAccess* policy assigned, in order to query AWS.

Please see the following for information on configuring your environment to allow Cloud Insights to collect from AWS child accounts:

Tutorial: Delegate Access Across AWS Accounts Using IAM Roles

AWS Setup: Providing Access to an IAM User in Another AWS Account That You Own

Creating a Role to Delegate Permissions to an IAM User

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### Configuring the Azure compute data collector

Cloud Insights uses the Azure compute data collector to acquire inventory and performance data from Azure compute instances.

#### Requirements

You need the following information to configure this data collector.

- Port requirement: 443 HTTPS
- Azure OAuth 2.0 Redirect URI (login.microsoftonline.com)
- Azure Management Rest IP (management.azure.com)
- Azure Resource Manager IP (management.core.windows.net)
- Azure Service Principal Application (Client) ID (Reader role required)
- Azure service principal authentication key (user password)
- You need to set up an Azure account for Cloud Insights discovery.

Once the account is properly configured and you register the application in Azure, you will have the credentials required to discover the Azure instance with Cloud Insights. The following link describes how to set up the account for discovery.

https://docs.microsoft.com/en-us/azure/active-directory/develop/howto-create-service-principal-portal

#### Configuration

Enter data into the data collector fields according to the table below:

Field	Description
Azure Service Principal Application (Client) ID (Reader role required)	Sign-in ID to Azure. Requires Reader Role access.
Azure tenant ID	Microsoft tenant ID
Azure Service Principal Authentication Key	Login authentication key
I understand Microsoft bills me for API requests	Check this to verify your understanding that Microsoft bills you for API requests made by Insight polling.

Field	Description
Inventory Poll Interval (min)	The default is 60
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Tags	Specify whether to include or exclude VM's by Tags when collecting data. If 'Include' is selected, the Tag Key field can not be empty.

Field	Description
Tag Keys and Values on which to Filter VMs	Click + Filter Tag to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of tags on the VM. Tag Key is required, Tag Value is optional. When Tag Value is empty, the VM is filtered as long as it matches the Tag Key.
Performance Poll Interval (sec)	The default is 300

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

#### **Broadcom**

#### **Brocade Network Advisor data collector**

Cloud Insights uses the Brocade Network Advisor data collector to acquire inventory and performance data from Brocade switches.

#### **Terminology**

Cloud Insights acquires the following inventory information from the Brocade Network Advisor data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Switch	Switch
Port	Port
Virtual Fabric, Physical Fabric	Fabric
Logical Switch	Logical Switch

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

The following are required to configure this data collector:

- The Cloud Insights Acquisition Unit will initate connections to TCP port 443 on the BNA server. BNA server must be running version 14.2.1 or higher.
- Brocade Network Advisor Server IP address
- · User name and password to an administrator account
- Port requirement: HTTP/HTTPS 443

#### Configuration

Field	Description
Brocade Network Advisor Server IP	IP address of the Network Advisor Server
User Name	User name for the switch
User Name	Administrator user name
Password	Administrator password

#### **Advanced configuration**

Field	Description
Connection Type	HTTPS (default port 443) or HTTP (default port 80)
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Password	Password for the switch
Inventory poll interval (min)	The default is 40
Report Access Gateway	Check to include devices in Access Gateway mode
Performance Poll Interval (sec)	The default is 1800

#### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
Receive a message that more than 1 node is logged into the Access Gateway port, or data collector fails to discover Access Gateway device.	Check that the NPV device is operating correctly and that all connected WWNs are expected. Do not directly acquire the NPV device. Instead, acquisition of the core fabric switch will collect the NPV device data.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### **Brocade FC Switch data collector**

Cloud Insights uses the Brocade FC Switch (SSH) data source to discover inventory for Brocade or rebranded switch devices running Factored Operating System (FOS) firmware 4.2 and later. Devices in both FC switch and Access Gateway modes are supported.

#### **Terminology**

Cloud Insights acquires the following inventory information from the Brocade FC Switch data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Switch	Switch
Port	Port
Virtual Fabric, Physical Fabric	Fabric
Zone	Zone
Logical Switch	Logical Switch
Virtual Volume	Volume
LSAN Zone	IVR Zone

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- The Cloud Insights Acquisition Unit (AU) will initiate connections to TCP Port 22 on Brocade switches to collect inventory data. The AU will also initiate connections to UDP port 161 for collection of performance data.
- There must be IP connectivity to all switches in the fabric. If you select the Discover all switches in the fabric check box, Cloud Insights identifies all the switches in the fabric; however, it needs IP connectivity to these additional switches to discover them.
- The same account is needed globally across all switches in the fabric. You can use PuTTY (open source terminal emulator) to confirm access.
- Ports 161 and 162 must be open to all switches in the fabric for SNMP performance polling.
- SNMP read-only Community String

#### Configuration

Field	Description
Switch IP	IP address or fully-qualified domain name of the EFC Server
User Name	User name for the switch
Password	Password for the switch
SNMP	SNMP version
SNMP Community String	SNMP read-only community string used to access the switch
SNMP User Name	SNMP user name
SNMP Password	SNMP password

Field	Description
Fabric name	Fabric name to be reported by the data collector. Leave blank to report the fabric name as WWN.
Inventory Poll Interval (min)	Interval between inventory polls. The default is 15.
Excluded Devices	Comma-separated list of device IDs to exclude from polling
Admin Domains Active	Select if using Admin Domains
Retrieve MPR Data	Select to acquire routing data from your multiprotocol router.
Enable Trapping	Select to enable acquisition upon receiving an SNMP trap from the device. If you select enable trapping, you must also activate SNMP.
Minimum Time Between Traps (sec)	Minimum time between acquisition attempts triggered by traps. The default is 10.
Discover all switches in the fabric	Select to discover all switches in the fabric
Choose Favoring HBA vs. Zone Aliases	Choose whether to favor HBA or zone aliases
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.
SNMP Auth Protocol	SNMP authentication protocol (SNMP v3 only)
SNMP Privacy Password	SNMP privacy password (SNMP v3 only)
SNMP Retries	Number of SNMP retry attempts

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
The inventory acquisition of the Brocade datasource fails with the error: <date> <time> ERROR [com.onaro.sanscreen.acquisition.framework.datasour ce.BaseDataSource] Error 2 out of 2: <datasource name=""> [Internal error] - Unable to generate the model for device <ip>. Error detecting prompt ([Device name <name>]: Unable to generate the model for device <ip>. Error detecting prompt)</ip></name></ip></datasource></time></date>	The issue may be caused when the Brocade switch takes too long to return with a prompt, exceeding the default timeout of 5 seconds.  In the data collector's Advanced Configuration settings in Cloud Insights, try increasing the SSH Banner Wait Timeout (sec) to a higher value.
Error: "Cloud Insights received Invalid Chassis Role"	Check that the user configured in this data source has been granted the chassis role permission.
Error: "Mismatched Chassis IP Address"	Change the data source configuration to use chassis IP address.

Problem:	Try this:
Receive a message that more than 1 node is logged into the Access Gateway port	Check that the NPV device is operating correctly and that all connected WWNs are expected. Do not directly acquire the NPV device. Instead, acquisition of the core fabric switch will collect the NPV device data.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### Cisco MDS Fabric Switches data collector

Cloud Insights uses the Cisco MDS Fabric Switches data collector to discover inventory for Cisco MDS Fabric Switches as well as a variety of Cisco Nexus FCoE switches on which the FC service is enabled.

Additionally, you can discover many models of Cisco devices running in NPV mode with this data collector.

#### Terminology

Cloud Insights acquires the following inventory information from the Cisco FC Switch data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Switch	Switch
Port	Port
VSAN	Fabric
Zone	Zone
Logical Switch	Logical Switch
Name Server Entry	Name Server Entry
Inter-VSAN Routing (IVR) Zone	IVR Zone

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- An IP address of one switch in the fabric or individual switches
- Chassis discovery, to enable fabric discovery
- If using SNMP V2, read-only community string
- · Port 161 is used to access the device

### Configuration

Field	Description
Cisco Switch IP	IP address or fully-qualified domain name of the switch
SNMP Version	Select V1, V2, or V3. V2 or later is required for performance acquisition.
SNMP Community String	SNMP read-only community string used to access the switch (not applicable for SNMP v3)
User Name	User name for the switch (SNMP v3 only)
Password	Password used for the switch (SNMPv3 only)

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls (default 40 minutes)
SNMP Auth Protocol	SNMP authentication protocol (SNMPv3 only)
SNMP Privacy Protocol	SNMP privacy protocol (SNMPv3 only)
SNMP Privacy Password	SNMP Privacy Password
SNMP Retries	Number of SNMP retry attempts
SNMP Timeout (ms)	SNMP timeout (default 5000 ms)
Enable Trapping	Select to enable trapping. If you enable trapping, you must also activate SNMP notifications.
Minimum Time Between Traps (sec)	Minimum time between acquisition attempts triggered by traps (default 10 seconds)
Discover All Fabric Switches	Select to discover all switches in the fabric
Excluded Devices	Comma-separated list of device IPs to exclude from polling
Included Devices	Comma-separated list of device IPs to include in polling
Check Device Type	Select to accept only those devices that explicitly advertise themselves as Cisco devices

Field	Description
First Alias Type	Provide a first preference for resolution of the alias. Choose from the following:  Device Alais This is a user-friendly name for a port WWN (pWWN) that can be used in all configuration commands, as required. All switches in the Cisco MDS 9000 Family support Distributed Device Alias Services (device aliases).  None Do not report any alias.  Port Description A description to help identify the port in a list of ports.  Zone Alias (all) A user-friendly name for a port that can be used only for the active configuration. This is the default.
Second Alias Type	Provide a second preference for resolution of the alias
Third Alias Type	Provide a third preference for resolution of the alias
Enable SANTap Proxy Mode Support	Select if your Cisco switch is using SANTap in proxy mode. If you are using EMC RecoverPoint, then you are probably using SANTap.
Performance Poll Interval (sec)	Interval between performance polls (default 300 seconds)

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: Failed to discover chassis - no switches have been discovered	<ul> <li>Ping the device with the IP configured</li> <li>Login to the device using Cisco Device Manager GUI</li> <li>Login to the device using CLI</li> <li>Try to run SNMP walk</li> </ul>
Error: Device is not a Cisco MDS switch	<ul> <li>Make sure the data source IP configured for the device is correct</li> <li>Login to the device using Cisco Device Manager GUI</li> <li>Login to the device using CLI</li> </ul>
Error: Cloud Insights is not able to obtain the switch's WWN.	This may not be a FC or FCoE switch, and as such may not be supported. Make sure the IP/FQDN configured in the datasource is truly a FC/FCoE switch.

Problem:	Try this:
Error: Found more than one nodes logged into NPV switch port	Disable direct acquisition of the NPV switch
Error: Could not connect to the switch	<ul> <li>Make sure the device is UP</li> <li>Check the IP address and listening port</li> <li>Ping the device</li> <li>Login to the device using Cisco Device Manager GUI</li> <li>Login to the device using CLI</li> <li>Run SNMP walk</li> </ul>

#### **Performance**

Problem:	Try this:
Error: Performance acquisition not supported by SNMP v1	<ul> <li>Edit Data Source and disable Switch Performance</li> <li>Modify Data Source and switch configuration to use SNMP v2 or higher</li> </ul>

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### Dell

#### **Dell EMC XC Series data collector**

Cloud Insights uses this data collector to discover inventory and performance information for the Dell EMC XC Series storage arrays.

#### Configuration

Field	Description
Prism External IP Address	IP address of the XC server
User Name	User name for the XC server
Password	Password used for the XC server

#### **Advanced configuration**

Field	Description
TCP Port	Port used for TCP communication with the XC server
Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance Poll Interval (min)	Interval between performance polls. The default is 300 seconds.

#### **Troubleshooting**

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### **Dell EMC**

#### **DELL EMC Data Domain data collector**

This data collector gathers inventory and performance information from DELL EMC Data Domain deduplication storage systems. To configure this data collector, there are specific configuration instructions and usage recommendations you must follow.

#### **Terminology**

Cloud Insights acquires the following inventory information from the Data Domain data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Array	Storage
FC Port	Port
File System	Internal Volume
Quota	Quota
NFS and CIFS share	FileShare

Note: These are common terminology mappings only and might not represent every case for this data colletor.

#### Requirements

You need the following information to configure this data collector:

- IP address of the Data Domain device
- · Read-only user name and password to the Data Domain storage
- SSH port 22

#### Configuration

Field	Description
IP address	The IP address or fully-qualified domain name of the Data Domain storage array
User name	The user name for the Data Domain storage array
Password	The password for the Data Domain storage array

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20.
SSH Port	SSH service port

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

#### Configuring the EMC ECS data collector

This data collector acquires inventory and performance data from EMC ECS storage systems. For configuration, the data collector requires an IP address of the ECS server and an administrative level domain account.

#### **Terminology**

Cloud Insights acquires the following inventory information from the ECS data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Cluster	Storage
Tenant	Storage Pool
Bucket	Internal Volume
Disk	Disk

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- · An IP address of the ECS Management Console
- · Administrative level domain account for the ECS system
- Port 443 (HTTPS). Requires outbound connectivity to TCP port 443 on the ECS system.
- For performance, read-only username and password for ssh/scp access.
- · For performance, port 22 is required.

#### Configuration

Field	Description
ECS Host	IP address or fully-qualified domain name of the ECS system
ECS Host Port	Port used for communication with ECS Host
ECS Vendor ID	Vendor ID for ECS
Password	Password used for ECS

Field	Description
Inventory Poll Interval (min)	The default is 360 minutes.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### **Dell EMC PowerScale data collector**

Cloud Insights uses the Dell EMC PowerScale (previously Isilon) SSH data collector to acquire inventory and performance data from PowerScale scale-out NAS storage.

#### **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive	Disk
Cluster	Storage
Node	Storage Node
File System	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

You need the following information to configure this data collector:

- · Administrator permissions to the PowerScale storage
- · IP address of the PowerScale cluster
- SSH access to port 22

#### Configuration

Field	Description
IP address	The IP address or fully-qualified domain name of the PowerScale cluster
User Name	User name for the PowerScale cluster
Password	Password used for the PowerScale cluster

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.
SSH Port	SSH service port. The default is 22.

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
"Invalid login credentials" with error messages "Commands not enabled for role-based administration require root user access"	* Verify that the user has permissions to run the following commands on the device: > isi version osrelease > isi status -q > isi status -n > isi devices -d %s > isi license * Verify credentials used in the wizard are matching device credentials
"Internal Error" with error messages "Command <your command=""> run failed with permission: <your current="" permission="">. Sudo command run permission issue"</your></your>	Verify that the user has sudo permissions to run the following command on the device

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### **Dell EMC PowerStore data collector**

The EMC PowerStore data collector gathers inventory information from EMC PowerStore storage. For configuration, the data collector requires the IP address of the storage processors and a read-only user name and password.

The EMC PowerStore data collector gathers the volume-to-volume replication relationships that PowerStore coordinates across other storage arrays. Cloud Insights shows a storage array for each PowerStore cluster, and collects inventory data for nodes and storage ports on that cluster. No storage pool or volume data is collected.

#### **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
host	host
host_volume_mapping	host_volume_mapping

Vendor/Model Term	Cloud Insights Term
hardware (it has Drives under "extra_details" object): Drives	Disk
Appliance	StoragePool
Cluster	Storage Array
Node	StorageNode
fc_port	Port
volume	Volume
InternalVolume	file_system

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

The following information is required to configure this data collector:

- IP address or fully-qualified domain name of storage processor
- Read-only user name and password

#### Configuration

Field	Description
PowerStore gateway(s)	IP addresses or fully-qualified domain names of PowerStore storage
User Name	User name for PowerStore
Password	Password used for PowerStore

#### **Advanced configuration**

Field	Description
HTTPS Port	Default is 443
Inventory Poll Interval (minutes)	Interval between inventory polls. The default is 60 minutes.

Cloud Insight's PowerStore performance collection makes use of PowerStore's 5-minute granularity source data. As such, Cloud Insights polls for that data every five minutes, and this is not configurable.

#### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

#### Dell EMC RecoverPoint data collector

The EMC RecoverPoint data collector's primary use case is to discover volume-to-volume replication relationships that the RecoverPoint storage appliance facilitates. This collector will also discover the Recoverpoint appliance itself. Please note that Dell/EMC sells a VMware backup solution for VMs--"RecoverPoint for VMs"--which is not supported by this collector

For configuration, the data collector requires the IP address of the storage processors and a read-only user name and password.

The EMC RecoverPoint data collector gathers the volume-to-volume replication relationships that RecoverPoint coordinates across other storage arrays. Cloud Insights shows a storage array for each RecoverPoint cluster, and collects inventory data for nodes and storage ports on that cluster. No storage pool or volume data is collected.

#### Requirements

The following information is required to configure this data collector:

- · IP address or fully-qualified domain name of storage processor
- · Read-only user name and password
- · REST API access via port 443

#### Configuration

Field	Description
Address of RecoverPoint	IP address or fully-qualified domain name of RecoverPoint cluster
User Name	User name for the RecoverPoint cluster
Password	Password used for the RecoverPoint cluster

#### **Advanced configuration**

Field	Description
TCP Port	TCP Port used to connect to Recoverpoint cluster
Inventory Poll Interval (minutes)	Interval between inventory polls. The default is 20 minutes.
Excluded Clusters	Comma-separated list of cluster IDs or names to exclude when polling.

#### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

#### **DELL EMC ScaleIO data collector**

The ScaleIO data collector collects inventory information from ScaleIO storage. For configuration, this data collector requires the ScaleIO gateway address and an admin user name and password.

#### **Terminology**

Cloud Insights acquires the following inventory information from the ScaleIO data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
MDM (Meta Data Manager) Cluster	Storage
SDS (ScaleIO Data Server)	Storage Node
Storage Pool	Storage Pool
Volume	Volume
Device	Disk

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- · Read-only access to the Admin user account
- Port requirement: HTTPS Port 443

#### Configuration

Field	Description
ScaleIO Gateway(s)	IP addresses or FQDNs of ScaleIO gateways, separated by comma (,) or semicolon (;)
User Name	Admin user name used to log in to the ScaleIO device
Password	Password used to log in to the ScaleIO device

#### **Advanced configuration**

Click the Inventory check box to enable inventory collection.

Field	Description
HTTPS port	443
Inventory poll interval (min)	The default is 60.
Connection Timeout (sec)	The default is 60.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### Configuring the EMC Unity data collector

The DELL EMC Unity (formerly VNXe) data collector provides inventory support for VNXe unified storage arrays. Cloud Insights currently supports iSCSI and NAS protocols.

#### Requirements

- The Unity data collector is CLI based; you must install the Unisphere for Unity CLI, (uemcli.exe) onto the acquisition unit where your VNXe data collector resides.
- uemcli.exe uses HTTPS as the transport protocol, so the acquisition unit will need to be able to initiate HTTPS connections to the Unity.
- · IP address or fully-qualified domain name of the Unity device
- You must have at least a read-only user for use by the data collector.
- · HTTPS on Port 443 is required
- The EMC Unity data collector provides NAS and iSCSI support for inventory; fibre channel volumes will be discovered, but Cloud Insights does not report on FC mapping, masking, or storage ports.

#### **Terminology**

Cloud Insights acquires the following inventory information from the Unity data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage Array	Storage
Processor	Storage Node
Storage Pool	Storage Pool
General iSCSI Block info, VMWare VMFS	Share
Replication Remote System	Synchronization
iSCSI Node	iSCSI Target Node
iSCSI Initiator	iSCSI Target Initiator

Note: These are common terminology mappings only and might not represent every case for this data source.

#### Configuration

Field	Description
Unity Storage	IP address or fully-qualified domain name of the Unity device
User Name	User name for the Unity device

Field	Description
Password	Password for the Unity device
Full Path to the Executable UEMCLI	Full path to the folder containing the <i>uemcli.exe</i> executable

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes
Unity CLI Port	Port used for the Unity CLI
Performance poll interval (sec)	The default is 300.

#### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
"Failed to execute external utility" with error messages "Failed to find Unisphere executable uemcli"	* Verify correct IP address, username, and password * Confirm that Unisphere CLI is installed on the Cloud Insights Acquisition Unit * Confirm that Unisphere CLI installation directory is correct in the datasource configuration * Confirm that the IP of the VNXe is correct in the configuration of the datasource. From the Cloud Insights Acquisition Unit, open a CMD and change to to the configured installation directory: \${INSTALLDIR.} Try to make a connection with the VNXe device by typing: uemcli -d <your ip=""> -u <your id=""> /sys/general show</your></your>

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### Dell EMC VMAX and PowerMax Family of Devices data collector

Cloud Insights discovers EMC VMAX and PowerMax storage arrays by using Solutions Enabler symcli commands in conjunction with an existing Solutions Enabler server in your environment. The existing Solutions Enabler server has connectivity to the VMAX/PowerMax storage array through access to gatekeeper volumes.

#### Requirements

Before configuring this data collector, you should ensure that Cloud Insights has TCP connectivity to port 2707 on the existing Solutions Enabler server. Cloud Insights discovers all the Symmetrix arrays that are "Local" to this server, as seen in "symcfg list" output from that server.

- The EMC Solutions Enabler (CLI) with SMI-S provider application must be installed on the Acquisition Unit server and the version must match or be earlier than the version running on the Solutions Enabler Server.
- A properly configured {installdir}\EMC\SYMAPI\config\netcnfg file is required. This file defines service names for Solutions Enabler servers, as well as the access method (SECURE / NOSECURE /ANY).
- If you require read/write latency at the storage node level, the SMI-S Provider must communicate with a running instance of the UNISPHERE for VMAX application.
- IP address of the managing Solutions Enabler server
- · Administrator permissions on the Solutions Enabler (SE) Server
- · Read-only user name and password to the SE software
- Solutions Enabler Server 6.5X requirements:
  - MI-S provider 3.3.1 for SMIS-S V1.2 installed
  - · After install, run \Program Files\EMC\SYMCLI\bin>stordaemon start storsrvd
- The UNISPHERE for VMAX application must be running and collecting statistics for the EMC VMAX and PowerMax sstorage arrays that are managed by the SMI-S Provider installation
- Access validation: Verify that the SMI-S provider is running: telnet <se server> 5988

#### **Terminology**

Cloud Insights acquires the following inventory information from the EMC VMAX/PowerMax data source. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Disk Group	Disk Group
Storage	Array Storage
Director	Storage Node
Device Pool, Storage Resource Pool (SRP)	Storage Pool
Device TDev	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Configuration

**Note:** If SMI-S user authentication is not enabled, the default values in the Cloud Insights data collector are ignored.

Field	Description
Service Name	Service name as specified in <i>netcnfg</i> file
Full path to CLI	Full path to the folder containing the Symmetrix CLI
SMI-S Host IP Address	IP address of the SMI-S host

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Inventory Filter Device List	Comma-separated list of device IDs to include or exclude
Connection Caching	* LOCAL means that the Cloud Insights Acquisition service is running on the Solutions Enabler server, which has Fibre Channel connectivity to the Symmetrix arrays you seek to discover, and has access to gatekeeper volumes. This might be seen in some Remote Acquisition Unit (RAU) configurations.  * REMOTE_CACHED is the default and should be used in most cases. This uses the NETCNFG file settings to connect using IP to the Solutions Enabler server, which must have Fibre Channel connectivity to the Symmetrix arrays you seek to discover, and has access to Gatekeeper volumes.  * In the event that REMOTE_CACHED options make CLI commands fail, use the REMOTE option. Keep in mind that it will slow down the acquisition process (possibly to hours or even days in extreme cases). The NETCNFG file settings are still used for an IP connection to the Solutions Enabler server that has Fibre Channel connectivity to the Symmetrix arrays being discovered.  Note: This setting does not change Cloud Insights behavior with respect to the arrays listed as REMOTE by the "symcfg list" output. Cloud Insights gathers data only on devices shown as LOCAL by this command.
SMI-S Protocol	Protocol used to connect to the SMI-S provider. Also displays the default port used.
Override SMIS-Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
SMI-S User Name	User name for the SMI-S Provider Host
SMI-S Password	User name for the SMI-S Provider Host
Performance Polling Interval (sec)	Interval between performance polls (default 1000 seconds)
hoose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting performance data

Field	Description
Performance Filter Device List	Comma-separated list of device IDs to include or exclude

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: The feature being requested is not currently licensed	Install the SYMAPI server license.
Error: No devices were found	Make sure Symmetrix devices are configured to be managed by the the Solutions Enabler server: - Run symcfg list -v to see the list of configured Symmetrix devices.
Error: A requested network service was not found in the service file	Make sure the Solutions Enabler Service Name is defined the netcnfg file for Solutions Enabler. This file is usually located under SYMAPI\config\ in the Solutions Enabler client installation.
Error: The remote client/server handshake failed	Check the most recent storsrvd.log* files on the Solutions Enabler host we are trying to discover.
Error: Common name in client certificate not valid	Edit the <i>hosts</i> file on the Solutions Enabler server so that the Acquisition Unit's hostname resolves to the IP address as reported in the storsrvd.log on the Solutions Enabler server.
Error: The function could not obtain memory	Make sure there is enough free memory available in the system to execute Solutions Enabler
Error: Solutions Enabler was unable to serve all data required.	Investigate the health status and load profile of Solutions Enabler
Error: • The "symcfg list -tdev" CLI command may return incorrect data when collected with Solutions Enabler 7.x from a Solutions Enabler server 8.x. • The "symcfg list -srp" CLI command may return incorrect data when collected with Solutions Enabler 8.1.0 or earlier from a Solutions Enabler server 8.3 or later.	Be sure you are using the same Solutions Enabler major release

Additional information may be found from the Support page or in the Data Collector Support Matrix.

### Dell EMC VNX Block Storage (NaviCLI) data collector

Cloud Insights uses the Dell EMC VNX Block Storage (NaviSec) data collector (formerly CLARiiON) to acquire inventory and performance data.

#### **Terminology**

Cloud Insights acquires the following inventory information from the EMC VNX Block Storage data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage	Storage
Storage Processor	Storage Node
This Pool, RAID Group	Storage Pool
LUN	Volume

Note: These are common terminology mappings only and might not represent every case for this data source.

#### Requirements

The following requirements must be met in order to collect data:

- An IP address of each VNX block storage processor
- Read-only Navisphere username and password to the VNX block storage arrays
- NaviSecCli must be installed on the Cloud Insights AU
- Access validation: Run NaviSecCLI from the Cloud Insights AU to each array using the username and password.
- Port requirements: 80, 443
- NaviSecCLI version should correspond with the newest FLARE code on your array
- For performance, statistics logging must be enabled.

#### NaviSphere command line interface syntax

naviseccli.exe -h <IP address> -user <user> -password <password> -scope <scope,use 0 for global scope> -port <use 443 by default> command

#### Configuration

Field	Description
VNX Block Storage IP Address	IP address or fully-qualified domain name of the VNX block storage
User Name	Name used to log into the VNX block storage device.
Password	Password used to log into the VNX block storage device.
CLI Path to naviseccli.exe	Full path to the folder containing the <i>naviseccli.exe</i> executable

## **Advanced Configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. Default is 40 minutes.
Scope	The secure client scope. The default is Global.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error:  • Agent Not Running  • Failed to find naviseccli  • Failed to execute any command	<ul> <li>Confirm that NaviSphere CLI is installed on the Cloud Insight Acquisition Unit</li> <li>You have not selected the "Use secure client" option in the data collector configuration wizard and do not have a non-secure version of Naviphere CLI installed.</li> <li>Confirm that NaviSphere CLI installation directory is correct in the data collector configuration</li> <li>Confirm that the IP of the VNX block storage is correct in the data collector configuration:</li> <li>From the Cloud Insights Acquisition Unit:</li> <li>Open a CMD.</li> <li>Change the directory to the configured installation directory</li> <li>Try to make a connection with the VNX block storage device by typing "navicli -h {ip} getagent" (replace the {ip} with the actual IP)</li> </ul>
Error: 4.29 emc235848 emc241018 getall Failed to parse host alias info	This is likely caused by a FLARE 29 corruption issue of the host initiator database on the array itself. See EMC knowledge base articles: emc235848, emc241018. You can also check https://now.netapp.com/Knowledgebase/solutionarea.asp?id=kb58128
Error: Unable to retrieve Meta LUNs. Error Executing java -jar navicli.jar	<ul> <li>Modify the data collector configuration to use the secure client (recommended)</li> <li>Install navicli.jar in the CLI path to navicli.exe OR naviseccli.exe</li> <li>Note: navicli.jar is deprecated as of EMC Navisphere version 6.26</li> <li>The navicli.jar may be available on <a href="http://powerlink.emc.com">http://powerlink.emc.com</a></li> </ul>
Error: Storage Pools not reporting disks on Service Processor at configured IP address	Configure the data collector with both Service Processor IPs, separated by a comma

Problem:	Try this:
Error: Revision mismatch error	<ul> <li>This is usually caused by updating the firmware on the VNX block storage device, but not updating the installation of NaviCLI.exe. This also might be caused by having different devices with different firmwares, but only one CLI installed (with a different firmware version).</li> <li>Verify that the device and the host are both running identical versions of the software: - From the Cloud Insights Acquisition Unit, open a command line window</li> <li>Change the directory to the configured installation directory</li> <li>Make a connection with the CLARiiON device by typing "navicli -h \${ip} getagent"</li> <li>Look for the version number on the first couple of lines. Example: "Agent Rev: 6.16.2 (0.1)"</li> <li>Look for and compare the version on the first line. Example: "Navisphere CLI Revision 6.07.00.04.07"</li> </ul>
Error: Unsupported Configuration - No Fibre Channel Ports	The device is not configured with any Fibre Channel ports. Currently, only FC configurations are supported. Verify this version/firmware is supported.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### DELL EMC VNX File (formerly Celerra Unified Storage System) data collector

This data collector acquires inventory information from the VNX File Storage System. For configuration, this data collector requires the IP address of the storage processors and a read-only user name and password.

#### Terminology

Cloud Insights acquires the following inventory information from the VNX File data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Celerra Network Server/Celerra Storage Pool	Storage Pool
File System	Internal Volume
Data Mover	Controller
File System mounted on a data mover	File Share
CIFS and NFS Exports	Share
Disk Volume	Backend LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

You need the following to configure this data collector:

- The IP address of the storage processor
- · Read-only user name and password
- SSH port 22

#### Configuration

Field	Description
VNX File IP Address	IP address or fully-qualified domain name of the VNX File device
User Name	Name used to log in to the VNX File device
Password	Password used to log in to the VNX File device

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (minutes)	Interval between inventory polls. The default is 20 minutes.

#### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

#### Inventory

Problem:	Try this:
Error: Unable to proceed while DART update in progress	Possible solution: Pause the data collector and wait for the DART upgrade to complete before attempting another acquisition request.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### Configuring the Dell EMC VNX Unified data collector

For configuration, the Dell EMC VNX Unified (SSH) data collector requires the IP address of the Control Station and a read-only username and password.

#### **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk

Vendor/Model Term	Cloud Insights Term
Disk Folder	Disk Group
File system	Internal Volume
Storage	Storage
Storage Processor	Storage Node
Storage Pool, RAID Group	Storage Pool
LUN	Volume
Data Mover	Controller
File System mounted on a data mover	File Share
CIFS and NFS Exports	Share
Disk Volume	Backend LUN

#### Requirements

You need the following to configure the VNX (SSH) data collector:

- VNX IP address & Credentials to the Celerra Control Station.
- Read-only username and password.
- The data collector is able to run NaviCLI/NaviSecCLI commands against the backend array utilizing the DART OS NAS heads

#### Configuration

Field	Description
VNX IP Address	IP address or fully-qualified domain name of the VNX Control Station
User Name	User name for the VNX Control Station
Password	Password for the VNX Control Station

#### **Advanced configiration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Performance Poll Interval (sec).	Interval between performance polls. The default is 300 seconds.

#### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### Configuring the EMC VPLEX data collector

This data collector acquires inventory and performance data from EMC VPLEX storage systems. For configuration, the data collector requires an IP address of the VPLEX server and an administrative level domain account.



Cloud Insights' performance collection from Vplex clusters requires that the performance archive service be operational, in order to populate the .CSV files and logs that Cloud Insights retrieves via SCP-based file copies. NetApp has observed that many Vplex firmware upgrade/management station updates will leave this functionality non-operational. Customers planning such upgrades may want to proactively ask Dell/EMC if their planned upgrade will leave this functionality inoperable, and if so, how can they re-enable it to minimize gaps in performance visibility? Cloud Insight's Vplex performance code will assess on each poll whether all the expected files exist, and if they are being properly updated; if they are missing or stale, Cloud Insights will log performance collection failures.

## **Terminology**

Cloud Insightst acquires the following inventory information from the VPLEX data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Cluster	Storage
Engine	Storage Node
Device, System Extent	Backend Storage Pool
Virtual Volume	Volume
Front-End Port, Back-End Port	Port
Distributed Device	Storage Synchronization
Storage View	Volume Map, Volume Mask
Storage Volume	Backend LUN
ITLs	Backend Path

Note: These are common terminology mappings only and might not represent every case for this data collector.

# Requirements

- An IP address of the VPLEX Management Console
- · Administrative level domain account for the VPLEX server
- Port 443 (HTTPS). Requires outbound connectivity to TCP port 443 on the VPLEX management station.
- For performance, read-only username and password for ssh/scp access.
- For performance, port 22 is required.

# Configuration

Field	Description
IP address of VPLEX Management Console	IP address or fully-qualified domain name of the VPLEX Management Console
User Name	User name for VPLEX CLI
Password	Password used for VPLEX CLI
Performance Remote IP Address	Performance Remote IP address of the VPLEX Management Console
Performance Remote User Name	Performance Remote user name of VPLEX Management Console
Performance Remote Password	Performance Remote Password of VPLEX Management Console

# Advanced configuration

Field	Description
Communication Port	Port used for VPLEX CLI. The default is 443.
Inventory Poll Interval (min)	The default is 20 minutes.
Number of connection retries	The default is 3.
Performance Poll Interval (sec)	Interval between performance polls. The default is 600 seconds.
Number of Retries	The default is 2.

# Troubleshooting

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
Error: User authentication failed.	Make sure your credentials for this device are correct.

# Performance

Problem:	Try this:
Error: VPLEX performance for version below 5.3 is not supported.	Upgrade VPLEX to 5.3 or above
Error: No enough data collected.	<ul> <li>Check collection timestamp in log file and modify polling interval accordingly</li> <li>Wait for longer time</li> </ul>
Error: Perpetual Log files not being updated.	Please contact EMC support to enable updating the perpetual log files

Problem:	Try this:
Error: Performance polling interval is too big.	Check collection timestamp in log file \${logfile} and modify polling interval accordingly
Error: Performance Remote IP address of VPLEX Management Console is not configured.	Edit the data source to set Performance Remote IP address of VPLEX Management Console.
Error: No performance data reported from director	<ul> <li>Check that the system performance monitors are running correctly</li> <li>Please contact EMC support to enable updating the system performance monitor log files</li> </ul>

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### **Dell EMC XtremelO data collector**

The EMC XtremIO data collector acquires inventory and performance data from the EMC XtremIO storage system.

### Requirements

To configure the EMC XtremIO (HTTP) data collector, you must have:

- The XtremIO Management Server (XMS) Host address
- · An account with administrator privileges
- Access to port 443 (HTTPS)

### **Terminology**

Cloud Insights acquires the following inventory information from the EMC XtremIO data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data source, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk (SSD)	Disk
Cluster	Storage
Controller	Storage Node
Volume	Volume
LUN Map	Volume Map
Target FC Initiator	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data source.

#### Requirements

- The XtremIO Management Server (XMS) Host IP address
- Administrator user name and password for the XtremIO

#### Configuration

Field	Description
XMS Host	IP address or fully-qualified domain name of the XtremIO Management Server
User name	User name for the XtremIO Management Server
Password	Password for the XtremIO Management Server

## **Advanced configuration**

Field	Description
TCP port	TCP Port used to connect to XTremIO Management Server. The default is 443.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval (sec)	Interval between performance polls. The default is 300 seconds.

### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

# Fujitsu Eternus data collector

The Fujitsu Eternus data collector acquires inventory data using administration-level access to the storage system.

## **Terminology**

Cloud Insights acquires the following inventory information from the Fujitsu Eternus storage. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage	Storage
Thin Pool, Flexible Tier Pool, Raid Group	Storage Pool
Standard Volume, Snap Data Volume (SDV), Snap Data Pool Volume (SDPV), Thin Provisioning Volume (TPV), Flexible Tier Volume (FTV), Wide Striping Volume (WSV)	Volume
Channel adapter	Controller

Note: These are common terminology mappings only and might not represent every case for this data collectior.

# Requirements

The following are required to configure this data collector:

- An IP address of the Eternus storage, which cannot be comma delimited
- · SSH Administration-level user name and password
- Port 22
- Ensure that the page scroll is disabled (clienv-show-more-scroll disable)

# Configuration

Field	Description
IP Address of Eternus Storage	IP address of the Eternus storage
User Name	User name for Eternus storage
Password	Password for the Eternus storage

# **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	The default is 20 minutes.

# **Troubleshooting**

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
"Error retrieving data" with error messages "Error Finding Prompt CLI" or "Error finding prompt at the end of shell results"	Likely caused by: Storage system has page scrolling enabled. Possible solution: * Try to disable page scrolling by running the following command: set clienv-show-more -scroll disable
"Connecting error" with error messages "Failed to instantiate an SSH connection to storage" or "Failed to instantiate a connection to VirtualCenter"	Likely causes:  * Incorrect credentials.  * Incorrect IP address.  * Network problem.  * Storage may be down or unresponsive.  Possible solutions:  * Verify credentials and IP address entered.  * Try to communicate with storage using SSH Client.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

# **NetApp Google Compute data collector**

This data collector supports inventory and performance collection from Google Compute cloud platform configurations. This collector will seek to discover all the Compute resources within all the Projects within one Google organization. If you have multiple Google organizations you want to discover with Cloud Insights, you will want to deploy one Cloud Insights collector per organization.

## Configuration

Field	Description
Organization ID	The organization ID you want to discover with this collector. This field is required if your service account is able to see more than one organization
Choose 'Exclude' or 'Include' to filter GCP Projects by IDs	If you want to limit what projects' resources are brought into Cloud Insights.
Project IDs	The list of Project IDs that you want to filter in, or out from discovery, depending on the value of the "Choose 'Exclude"" value. The default list is empty
Client ID	Client ID for the Google Cloud Platform configuration
Copy and paste the contents of your Google Credential File here	Copy your Google credentials for the Cloud Platform account to this field

## **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes
Choose 'Exclude' or 'Include' to Apply to Filter VMs by Labels	Specify whether to include or exclude VM's by Labels when collecting data. If 'Include' is selected, the Label Key field can not be empty.
Label Keys and Values on which to Filter VMs	Click + Filter Label to choose which VMs (and associated disks) to include/exclude by filtering for keys and values that match keys and values of labels on the VM. Label Key is required, Label Value is optional. When Label Value is empty, the VM is filtered as long as it matches the Label Key.
Performance Poll Interval (sec)	Default is 1800 seconds

## **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

# **HP Enterprise**

## HP Enterprise Alletra 9000 / Primera Storage data collector

Cloud Insights uses the HP Enterprise Alletra 9000 / HP Enterprise Primera (previously 3PAR) data collector to discover inventory and performance.

## **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Field	Description
Physical Disk	Disk
Storage System	Storage
Controller Node	Storage Node
Common Provisioning Group	Storage Pool
Virtual Volume	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

The following are required to configure this data colletor:

- IP address or FQDN of the InServ cluster
- · For inventory, read-only user name and password to the StoreServ Server
- For performance, read-write user name and password to the StoreServ Server
- Port requirements: 22 (inventory collection), 5988 or 5989 (performance collection) [Note: Performance is supported for StoreServ OS 3.x+]
- For performance collection confirm that SMI-S is enabled by logging into the array via SSH.

## Configuration

Field	Description
Storage IP address	Storage IP address or fully-qualified domain name of the StoreServ cluster
User Name	User name for the StoreServ Server
Password	Password used for the StoreServ Server
SMI-S User Name	User name for the SMI-S Provider Host
SMI-S Password	Password used for the SMI-S Provider Host

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
SMI-S Connectivity	Protocol used to connect to the SMI-S provider
Override SMI-S Default Port	If blank, use the default port from SMI-S Connectivity, otherwise enter the connection port to use
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
"showsys" command doesn't return any result.	Run "showsys" and "showversion -a" from the command line and check if the version is supported by the array.

## Performance

Problem:	Try this:
Failed to connect or login. Provider initialization failed.	An all-numeric array name can cause problems with SMI-S server. Try changing the array name.
SMI-S user configured does not have any domain	Grant appropriate domain privileges to the configured SMI-S user
Cloud Insights states that it cannot connect/login to SMI-S service.	Confirm there is no firewall between the CI AU and the array that would block the CI AU from making TCP connections to 5988 or 5989.  Once that is done, and if you have confirmed there is no firewall, you should SSH to the array, and use the "showcim" command to confirm.
	Verify that:
	* Service is enabled * HTTPS is enabled * HTTPS port should be 5989
	If those all are so, you can try to "stopcim" and then a "startcim" to restart the CIM (i.e. SMI-S service).

Additional information may be found from the Support page or in the Data Collector Support Matrix.

# **HP Enterprise Command View data collector**

The HP Enterprise Command View Advanced Edition data collector supports discovering

XP and P9500 arrays via Command View Advanced Edition (CVAE) server. Cloud Insights communicates with CVAE using the standard Command View API to collect inventory and performance data.

#### **Terminology**

Cloud Insights acquires the following inventory information from the HP Enterprise Command View data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
PDEV	Disk
Journal Pool	Disk Group
Storage Array	Storage
Port Controller	Storage Node
Array Group, DP Pool	Storage Pool
Logical Unit, LDEV	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### **Inventory requirements**

You must have the following in order to collect inventory data:

- IP address of the CVAE server
- Read-only user name and password for the CVAE software and peer privileges
- Port requirement: 2001

### Performance requirements

The following requirements must be met in order to collect performance data:

- · HDS USP, USP V, and VSP performance
  - Performance Monitor must be licensed.
  - Monitoring switch must be enabled.
  - The Export Tool (Export.exe) must be copied to the Cloud Insights AU and extracted to a location. On CI Linux AUs, ensure "cisys" has read and execute permissions.
  - The Export Tool version must match the microcode version of the target array.
- AMS performance:
  - Performance Monitor must be licensed.
  - The Storage Navigator Modular 2 (SNM2) CLI utility be installed on the Cloud Insights AU.
- Network requirements
  - The Export Tools are Java based, and use RMI to speak to the array. These tools may not be firewall-friendly as they may dynamically negotiate source and destination TCP ports on each invocation. Also,

different model array's Export Tools may behave differently across the network - consult HPE for your model's requirements

# Configuration

Field	Description
Command View Server	IP address or fully-qualified domain name of the Command View server
User Name	User name for the Command View server.
Password	Password used for the Command View server.
Devices - VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages	Device list for VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages. Each storage requires:  * Array's IP: IP address of the storage  * User Name: User name for the storage  * Password: Password for the storage  * Folder Containing Export Utility JAR Files
SNM2Devices - WMS/SMS/AMS Storages	Device list for WMS/SMS/AMS storages. Each storage requires:  * Array's IP: IP address of the storage  * Storage Navigator CLI Path: SNM2 CLI path  * Account Authentication Valid: Select to choose valid account authentication  * User Name: User name for the storage  * Password: Password for the storage
Choose Tuning Manager for Performance	Override other performance options
Tuning Manager Host	IP address or fully-qualified domain name of tuning manager
Tuning Manager Port	Port used for Tuning Manager
Tuning Manager Username	User name for Tuning Manager
Tuning Manager Password	Password for Tuning Manager

Note: In HDS USP, USP V, and VSP, any disk can belong to more than one array group.

# Advanced configuration

Field	Description
Command View Server Port	Port used for the Command View Server
HTTPs Enabled	Select to enable HTTPs
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.

Exclude or Include Devices	Comma-separated list of device ID's or array names to include or exclude
Query Host Manager	Select to query host manager
Performance Polling Interval (sec)	Interval between performance polls. The default is 300.

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
Error: User does not have enough permission	Use a different user account that has more privilege or increase the privilege of user account configured in the data collector
Error: Storages list is empty. Either devices are not configured or the user does not have enough permission	* Use DeviceManager to check if the devices are configured.  * Use a different user account that has more privilege, or increase the privilege of the user account
Error: HDS storage array was not refreshed for some days	Investigate why this array is not being refreshed in HP CommandView AE.

# Performance

Problem:	Try this:
Error:  * Error executing export utility  * Error executing external command	* Confirm that Export Utility is installed on the Cloud Insights Acquisition Unit  * Confirm that Export Utility location is correct in the data collector configuration  * Confirm that the IP of the USP/R600 array is correct in the configuration of the data collector  * Confirm that the User name and password are correct in the configuration of the data collector  * Confirm that Export Utility version is compatible with storage array micro code version  * From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following:  - Change the directory to the configured installation directory  - Try to make a connection with the configured storage array by executing batch file runWin.bat
Error: Export tool login failed for target IP	* Confirm that username/password is correct * Create a user ID mainly for this HDS data collector * Confirm that no other data collectors are configured to acquire this array

Problem:	Try this:
Error: Export tools logged "Unable to get time range for monitoring".	* Confirm performance monitoring is enabled on the array. * Try invoking the export tools outside of Cloud Insights to confirm the problem lies outside of Cloud Insights.
Error:  * Configuration error: Storage Array not supported by Export Utility  * Configuration error: Storage Array not supported by Storage Navigator Modular CLI	* Configure only supported storage arrays.  * Use "Filter Device List" to exclude unsupported storage arrays.
Error:  * Error executing external command  * Configuration error: Storage Array not reported by Inventory  * Configuration error:export folder does not contains jar files	* Check Export utility location.  * Check if Storage Array in question is configured in Command View server  * Set Performance poll interval as multiple of 60 seconds.
Error:  * Error Storage navigator CLI  * Error executing auperform command  * Error executing external command	* Confirm that Storage Navigator Modular CLI is installed on the Cloud Insights Acquisition Unit * Confirm that Storage Navigator Modular CLI location is correct in the data collector configuration * Confirm that the IP of the WMS/SMS/SMS array is correct in the configuration of the data collector * Confirm that Storage Navigator Modular CLI version is compatible with micro code version of storage array configured in the data collector * From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following: - Change the directory to the configured installation directory - Try to make a connection with the configured storage array by executing following command "auunitref.exe"
Error: Configuration error: Storage Array not reported by Inventory	Check if Storage Array in question is configured in Command View server
Error:  * No Array is registered with the Storage Navigator Modular 2 CLI  * Array is not registered with the Storage Navigator Modular 2 CLI  * Configuration error: Storage Array not registered with StorageNavigator Modular CLI	* Open Command prompt and change directory to the configured path  * Run the command "set=STONAVM_HOME=."  * Run the command "auunitref"  * Confirm that the command output contains details of the array with IP  * If the output does not contain the array details then register the array with Storage Navigator CLI:  - Open Command prompt and change directory to the configured path  - Run the command "set=STONAVM_HOME=."  - Run command "auunitaddauto -ip \${ip}". Replace  \${ip} with real IP

Additional information may be found from the Support page or in the Data Collector Support Matrix.

#### HPE Alletra 6000 data collector

The HP Enterprise Alletra 6000 (previously Nimble) data collector supports inventory and performance data for Alletra 6000 storage arrays.

## **Terminology**

Cloud Insights acquires the following inventory information from this collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Array	Storage
Disk	Disk
Volume	Volume
Pool	Storage Pool
Initiator	Storage Host Alias
Controller	Storage Node
Fibre Channel Interface	Controller

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

You must have the following in order to collect inventory and configuration data from the storage array:

- The array must be installed and configured, and reachable from the client through its fully qualified domain name (FQDN) or array management IP address.
- The array must be running NimbleOS 2.3.x or later.
- You must have a valid user name and password to the array with at least "Operator" level role. The "Guest" role does not have sufficient access to understand initiator configurations.
- · Port 5392 must be open on the array.

You must have the following in order to collect performance data from the storage array:

- The array must be running NimbleOS 4.0.0 or later
- The array must have volumes configured. The only performance API NimbleOS has is for volumes, and any statistics Cloud Insights reports are derived from the statistics on volumes

#### Configuration

Field	Description
Array Management IP Address	Fully qualified domain name (FQDN) or array management IP address.
User Name	User name for the array

Field	Description
Password	Password for the array

#### **Advanced configuration**

Field	Description
Port	Port used by Nimble REST API. The default is 5392.
Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.

Note: The default performance poll interval is 300 seconds and can not be changed. This is the only interval supported by HPE Alletra 6000.

# **Hitachi Data Systems**

#### Hitachi Vantara Command Suite data collector

The Hitachi Vantara Command Suite data collector supports the HiCommand Device Manager server. Cloud Insights communicates with the HiCommand Device Manager server using the standard HiCommand API.

### **Terminology**

Cloud Insights acquires the following inventory information from the Hitachi Vantara Command Suite data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
PDEV	Disk
Journal Pool	Disk Group
Storage Array	Storage
Port Controller	Storage Node
Array Group, HDS Pool	Storage Pool
Logical Unit, LDEV	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

### **Storage**

The following terms apply to objects or references that you might find on HDS storage asset landing pages. Many of these terms apply to other data collectors as well.

- Name comes directly from HDS HiCommand Device Manager's "name" attribute via the GetStorageArray XML API call
- Model comes directly from HDS HiCommand Device Manager's "arrayType" attribute via the

GetStorageArray XML API call

- Vendor HDS
- Family comes directly from HDS HiCommand Device Manager's "arrayFamily" attribute via the GetStorageArray XML API call
- IP this is the management IP address of the array, not an exhaustive list of all IP addresses on the array
- Raw Capacity a base2 value representing the sum of the total capacity of all disks in this system, regardless of disk role.

## **Storage Pool**

The following terms apply to objects or references that you might find on HDS storage pool asset landing pages. Many of these terms apply to other data collectors as well.

- Type: The value here will be one of:
  - RESERVED if this pool is dedicated for purposes other than data volumes, i.e, journaling, snapshots
  - Thin Provisioning if this is a HDP pool
  - Raid Group you will not likely see these for a few reasons:

Cloud Insights takes a strong stance to avoid double counting capacity at all costs. On HDS, one typically needs to build Raid Groups from disks, create pool volumes on those Raid Groups, and construct pools (often HDP, but could be special purpose) from those pool volumes. If Cloud Insights reported both the underlying Raid Groups as is, as well as the Pools, the sum of their raw capacity would vastly exceed the sum of the disks.

Instead, Cloud Insights' HDS Command Suite data collector arbitrarily shrinks the size of Raid Groups by the capacity of pool volumes. This may result in Cloud Insights not reporting the Raid Group at all. Additionally, any resulting Raid Groups are flagged in a way such that they are not visible in the Cloud Insights WebUI, but they do flow into the Cloud Insights Data Warehouse (DWH). The purpose of these decisions is to avoid UI clutter for things that most users do not care about – if your HDS array has Raid Groups with 50MB free, you probably cannot use that free space for any meaningful outcome.

- Node N/A, as HDS pools are not tied to any one specific node
- Redundancy the RAID level of the pool. Possibly multiple values for a HDP pool comprised of multiple RAID types
- Capacity % the percent used of the pool for data usage, with the used GB and total logical GB size of the pool
- Over-committed Capacity a derived value, stating "the logical capacity of this pool is oversubscribed by this percentage by virtue of the sum of the logical volumes exceeding the logical capacity of the pool by this percentage"
- Snapshot shows the capacity reserved for snapshot usage on this pool

## **Storage Node**

The following terms apply to objects or references that you might find on HDS storage node asset landing pages. Many of these terms apply to other data collectors as well.

- Name The name of the Front-end director (FED) or Channel Adapter on monolithic arrays, or the name of the controller on a modular array. A given HDS array will have 2 or more Storage Nodes
- Volumes The Volume table will show any volume mapped to any port owned by this storage node

#### **Inventory Requirements**

You must have the following in order to collect inventory data:

- IP address of the HiCommand Device Manager server
- Read-only user name and password for the HiCommand Device Manager software and peer privileges
- Port requirements: 2001 (http) or 2443 (https)
- · Log into HiCommand Device Manager software using username and password
- Verify access to HiCommand Device Manager http://<HiCommand\_Device\_Manager\_IP>:2001/service/ StorageManager

#### **Performance requirements**

The following requirements must be met in order to collect performance data:

- · HDS USP, USP V, and VSP performance
  - Performance Monitor must be licensed.
  - Monitoring switch must be enabled.
  - The Export Tool (Export.exe) must be copied to the Cloud Insights AU.
  - The Export Tool version must match the microcode version of the target array.
- AMS performance:
  - NetApp strongly recommends creating a dedicated service account on AMS arrays for Cloud Insights
    to use to retrieve performance data. Storage Navigator only allows a user account one concurrent login
    to the array. Having Cloud Insights use the same user account as management scripts or HiCommand
    may result in Cloud Insights, management scripts, or HiCommand being unable to communicate to the
    array due to the one concurrent user account login limit
  - Performance Monitor must be licensed.
  - The Storage Navigator Modular 2 (SNM2) CLI utility needs to be installed on the Cloud Insights AU.

#### Configuration

Field	Description
HiCommand Server	IP address or fully-qualified domain name of the HiCommand Device Manager server
User Name	User name for the HiCommand Device Manager server.
Password	Password used for the HiCommand Device Manager server.
Devices - VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages	Device list for VSP G1000 (R800), VSP (R700), HUS VM (HM700) and USP storages. Each storage requires:  * Array's IP: IP address of the storage  * User Name: User name for the storage  * Password: Password for the storage
	* Folder Containing Export Utility JAR Files

Field	Description
SNM2Devices - WMS/SMS/AMS Storages	Device list for WMS/SMS/AMS storages. Each storage requires:  * Array's IP: IP address of the storage  * Storage Navigator CLI Path: SNM2 CLI path  * Account Authentication Valid: Select to choose valid account authentication  * User Name: User name for the storage  * Password: Password for the storage
Choose Tuning Manager for Performance	Override other performance options
Tuning Manager Host	IP address or fully-qualified domain name of tuning manager
Override Tuning Manager Port	If blank, use the default port in the Choose Tuning Manager for Performance field, otherwise enter the port to use
Tuning Manager Username	User name for Tuning Manager
Tuning Manager Password	Password for Tuning Manager

Note: In HDS USP, USP V, and VSP, any disk can belong to more than one array group.

# Advanced configuration

Field	Description
Connection Type	HTTPS or HTTP, also displays the default port
HiCommand Server Port	Port used for the HiCommand Device Manager
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Filter device List	Comma-separated list of device serial numbers to include or exclude
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.
Export timeout in seconds	Export utility timeout. The default is 300.

# Troubleshooting

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
Error: User does not have enough permission	Use a different user account that has more privilege or increase the privilege of user account configured in the data collector

Problem:	Try this:
Error: Storages list is empty. Either devices are not configured or the user does not have enough permission	* Use DeviceManager to check if the devices are configured.  * Use a different user account that has more privilege, or increase the privilege of the user account
Error: HDS storage array was not refreshed for some days	Investigate why this array is not being refreshed in HDS HiCommand.

# Performance

Problem:	Try this:
Error: * Error executing export utility * Error executing external command	* Confirm that Export Utility is installed on the Cloud Insights Acquisition Unit  * Confirm that Export Utility location is correct in the data collector configuration  * Confirm that the IP of the USP/R600 array is correct in the configuration of the data collector  * Confirm that the User name and password are correct in the configuration of the data collector  * Confirm that Export Utility version is compatible with storage array micro code version  * From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following:  - Change the directory to the configured installation directory  - Try to make a connection with the configured storage array by executing batch file runWin.bat
Error: Export tool login failed for target IP	* Confirm that username/password is correct * Create a user ID mainly for this HDS data collector * Confirm that no other data collectors are configured to acquire this array
Error: Export tools logged "Unable to get time range for monitoring".	* Confirm performance monitoring is enabled on the array.  * Try invoking the export tools outside of Cloud Insights to confirm the problem lies outside of Cloud Insights.
Error:  * Configuration error: Storage Array not supported by Export Utility  * Configuration error: Storage Array not supported by Storage Navigator Modular CLI	* Configure only supported storage arrays.  * Use "Filter Device List" to exclude unsupported storage arrays.
Error:  * Error executing external command  * Configuration error: Storage Array not reported by Inventory  * Configuration error:export folder does not contains jar files	* Check Export utility location.  * Check if Storage Array in question is configured in HiCommand server  * Set Performance poll interval as multiple of 60 seconds.

Problem:	Try this:
Error:  * Error Storage navigator CLI  * Error executing auperform command  * Error executing external command	* Confirm that Storage Navigator Modular CLI is installed on the Cloud Insights Acquisition Unit  * Confirm that Storage Navigator Modular CLI location is correct in the data collector configuration  * Confirm that the IP of the WMS/SMS/SMS array is correct in the configuration of the data collector  * Confirm that Storage Navigator Modular CLI version is compatible with micro code version of storage array configured in the data collector  * From the Cloud Insights Acquisition Unit, open a CMD prompt and do the following:  - Change the directory to the configured installation directory  - Try to make a connection with the configured storage array by executing following command "auunitref.exe"
Error: Configuration error: Storage Array not reported by Inventory	Check if Storage Array in question is configured in HiCommand server
Error:  * No Array is registered with the Storage Navigator Modular 2 CLI  * Array is not registered with the Storage Navigator Modular 2 CLI  * Configuration error: Storage Array not registered with StorageNavigator Modular CLI	* Open Command prompt and change directory to the configured path  * Run the command "set=STONAVM_HOME=."  * Run the command "auunitref"  * Confirm that the command output contains details of the array with IP  * If the output does not contain the array details then register the array with Storage Navigator CLI:  - Open Command prompt and change directory to the configured path  - Run the command "set=STONAVM_HOME=."  - Run command "auunitaddauto -ip \${ip}". Replace  \${ip} with real IP

Additional information may be found from the Support page or in the Data Collector Support Matrix.

# Configuring the Hitachi Vantara NAS data collector

The Hitachi Vantara NAS data collector is an inventory and configuration data collector that supports discovery of HDS NAS clusters. Cloud Insights supports discovering NFS and CIFS shares, file systems (Internal Volumes), and spans (Storage Pools).

### Terminology

Cloud Insights acquires the following inventory information from the HNAS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Tier	Disk Group
Cluster	Storage

Vendor/Model Term	Cloud Insights Term
Node	Storage Node
Span	Storage Pool
System Drive	Backend Lun
Files System	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- · Device IP address
- Port 22, SSH protocol
- Username and password privilege level: Supervisor
- Note: This data collector is SSH based, so the AU that hosts it must be able to initiate SSH sessions to TCP 22 on the HNAS itself, or the Systems Management Unit (SMU) that the cluster is connected to.

## Configuration

Field	Description
HNAS Host	IP address or fully-qualified domain name of HNAS Management Host
User Name	User name for HNAS CLI
Password	Password used for HNAS CLI

## **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 30 minutes.

### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
"Error connecting" with error messages "Error setting up shell channel: "or "Error opening shell channel"	Likely caused by network connectivity issues or SSH is misconfigured. Confirm connection with alternate SSH client
"Timeout" or "Error retrieving data" with error messages "Command: XXX has timed out."	* Try the command with alternate SSH client * Increase timeout

Problem:	Try this:
"Error connecting " or "Invalid login credentials" with error messages "Could not communicate with the device:"	* Check IP address  * Check user name and password  * Confirm connection with alternate SSH client

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## Hitachi Ops Center data collector

This data collector uses Hitachi Ops Center's integrated suite of applications to access inventory and performance data of multiple storage devices. For inventory and capacity discovery, your Ops Center installation must include both the "Common Services" and "Administrator" components. For performance collection, you must additionally have "Analyzer" deployed.

### **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Systems	Storage
Volume	Volume
Parity Groups	Storage Pool(RAID), Disk Groups
Disk	Disk
Storage Pool	Storage Pool(Thin, SNAP)
External Parity Groups	Storage Pool(Backend), Disk Groups
Port	Storage Node $\rightarrow$ Controller Node $\rightarrow$ Port
Host Groups	Volume Mapping and Masking
Volume Pairs	Storage Synchronization

Note: These are common terminology mappings only and might not represent every case for this data collector.

# **Inventory Requirements**

You must have the following in order to collect inventory data:

- IP address of the Ops Center server
- Read-only user name and password for the Ops Center software and peer privileges

## Configuration

Field	Description
Hitachi Ops Center IP Address	IP address or fully-qualified domain name of the Ops Center server hosting the "Common Services" component
User Name	User name for the Ops Center server.
Password	Password used for the Ops Center server.

## **Advanced configuration**

Field	Description
Connection Type	HTTPS (port 443) is the default
Override TCP Port	Specify the port to use if not the default
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40.
Choose 'Exclude' or 'Include' to specify a list	Specify whether to include or exclude the array list below when collecting data.
Filter device List	Comma-separated list of device ID's or array names to include or exclude
Performance Poll Interval (sec)	Interval between performance polls. The default is 300.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## Infinidat InfiniBox data collector

The Infinidat InfiniBox (HTTP) data collector is used to collect inventory information from the Infinidat InfiniBox storage system.

# **Terminology**

Cloud Insights acquires the following inventory information from the Infinidat InfiniBox data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Node	Controller
Filesystem	Internal Volume
Filesystem	File Share
Filesystem Exports	Share

## Requirements

The following are requirements when configuring this data collector.

- IP address or FQDN of InfiniBox management Node
- · Admin userid and password
- Port 443 via REST API

## Configuration

Field	Description
InfiniBox Host	IP address or fully-qualified domain name of the InfiniBox Management Node
User Name	User name for InfiniBox Management Node
Password	Password for the InfiniBox Management Node

## **Advanced configuration**

Field	Description
TCP Port	TCP Port used to connect to InfiniBox Server. The default is 443.
Inventory Poll Interval	Interval between inventory polls. The default is 60 minutes.

## **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## Huawei OceanStor data collector

Cloud Insights uses the Huawei OceanStor (REST/HTTPS) data collector to discover inventory and performance for Huawei OceanStor and OceanStor Dorado storage.

## **Terminology**

Cloud Insights acquires the following inventory and performance information from the Huawei OceanStor. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
File System	Internal Volume
Controller	Storage Node
FC Port (Mapped)	Volume Map
Host FC Initiator (Mapped)	Volume Mask
NFS/CIFS Share	Share
iSCSI Link Target	iSCSI Target Node

Vendor/Model Term	Cloud Insights Term
iSCSI Link Initiator	iSCSI Initiator Node
Disk	Disk
LUN	Volume

## Requirements

The following requirements are required to configure this data collector:

- Device IP address
- · Credentials to access OceanStor device manager
- Port 8088 must be available

# Configuration

Field	Description
OceanStor Host IP Address	IP address or fully-qualified domain name of the OceanStor Device Manager
User Name	Name used to log into the OceanStor Device Manager
Password	Password used to log into the OceanStor Device Manager

# **Advanced Configuration**

Field	Description
TCP Port	TCP Port used to connect to OceanStor Device Manager. The default is 8088.
Inventory Poll Interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval (sec).	The default is 300 seconds.

# **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## **IBM**

## **IBM Cleversafe data collector**

Cloud Insights uses this data collector to discover inventory and performance data for IBM Cleversafe storage systems.

#### **Terminology**

Cloud Insights acquires the following inventory information from the IBM Cleversafe data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Container	Internal Volume
Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- The external data services IP address for the cluster
- · Administrator user name and password
- Port 9440

## Configuration

Field	Description
Manager IP or host name	IP address or hostname of management node
User name	Username for the user account with super user or system administrator role
Password	Password for the user account with super user or system administrator role

#### **Advanced configuration**

Field	Description
Inventory poll interval (min)	Interval between inventory polls.
HTTP Connection Timeout (sec)	HTTP timeout in seconds.

### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## IBM CS data collector

Cloud Insights uses this data collector to discover inventory and performance data for IBM CS storage systems.

#### **Terminology**

Cloud Insights acquires the following inventory information from the IBM CS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Container	Internal Volume
Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

- The external data services IP address for the cluster
- · Administrator user name and password
- Port 9440

## Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

#### **Advanced configuration**

Field	Description
TCP port	TCP Port used to connect to the IBM CS array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval(sec)	Interval between performance polls. The default is 300 seconds.

### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## IBM System Storage DS8000 Series data collector

The IBM DS (CLI) data collector supports inventory and performance data acquisition for

### DS6xxx and DS8xxx devices.

DS3xxx, DS4xxx, and DS5xxx devices are supported by the NetApp E-Series data collector. You should refer to the Cloud Insights support matrix for supported models and firmware versions.

#### **Terminology**

Cloud Insights acquires the following inventory information from the IBM DS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk Drive Module	Disk
Storage Image	Storage
Extent Pool	Storage Node
Fixed Block Volume	Volume
Host FC Initiator (Mapped)	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collecor.

### Requirements

You need the following to configure this data collector:

- · IP address of each DS array
- Read-only username and password on each DS array
- Third-party software installed on the Cloud Insights AU: IBM dscli
- · Access validation: Run dscli commands using the username and password
- Port requirements: 80, 443, & 1750

## Configuration

Field	Description
DS Storage	IP address or fully-qualified domain name of the DS device
User Name	User name for the DS CLI
Password	Password for the DS CLI
dscli executable path	Full path to the <i>dscli</i> executable

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls (min). The default is 40.
Storage Display Name	Name of the IBM DS storage array

Field	Description
Inventory Exclude Devices	Comma-separated list of device serial numbers to exclude from inventory collection
Performance Poll Interval (sec)	The default is 300.
Performance Filter Type	Include: Data collected only from devices on list. Exclude: No data from these devices is collected
Performance Filter Device List	Comma-separated list of device IDs to include or exclude from performance collection

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error containing: CMUC00192E, CMUC00191E or CMUC00190E	* Verify credentials and IP address entered.  * Try to communicate with the array through web management console https://\${ip}:8452/D\$8000/Console. Replace the \${ip} with data collector configured IP.
Error:  * Cannot run program  * Error executing command	* From Cloud Insights Acquisition Unit Open a CMD  * Open CLI.CFG file in CLI's home dir/lib and check property JAVA_INSTALL, edit the value to match your environment  * Display Java version installed on this machine, typing: "java -version"  * Ping the IP address of the IBM Storage device specified in CLI command issued.  * If all the above worked fine then manually run a CLI command

Additional information may be found from the Support page or in the Data Collector Support Matrix.

# Configuring the IBM PowerVM data collector

The IBM PowerVM (SSH) data collector is used to collect information about virtual partitions running on IBM POWER hardware instances managed by a hardware management console (HMC).

### **Terminology**

Cloud Insights acquires inventory information from the virtual partitions running on IBM POWER hardware instances. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
hdisk	Virtual Disk

Vendor/Model Term	Cloud Insights Term
Managed System	Host
LPAR, VIO Server	Virtual Machine
Volume Group	Data Store
Physical Volume	LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

The following requirements must be met to configure and use this data collector:

- IP address of the Hardware Management Console (HMC)
- User name and password that provide access to Hardware Management Console (HMC) through SSH
- Port requirement SSH-22
- View permission on all management systems and logical partition security domains

The user must also have View permission on HMC configurations and the ability to collect VPD information for the HMC console security grouping. The user must also be allowed Virtual IO Server Command access under the Logical Partition security grouping. It is a best practice to start from a role of an operator and then remove all roles. Read-only users on the HMC do not have privileges to run proxied commands on AIX hosts.

• IBM best practice is to have the devices monitored by two or more HMCs. Be aware that this may cause OnCommand Insight to report duplicated devices, therefore it is highly recommended to add redundant devices to the "Exclude Devices" list in the Advanced Configuration for this data collector.

## Configuration

Field	Description
Hardware Management Console (HMC) IP Address	IP address or fully-qualified domain name of the PowerVM Hardware Management Console
HMC User	User name for the Hardware Management Console
Password	Password used for the Hardware Management Console

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.
SSH Port	Port used for SSH to the PowerVM
Password	Password used for the Hardware Management Console

Field	Description
Number of Retries	Number of inventory retry attempts
Exclude Devices	Comma-separated list of device IDs or display names to exclude

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## Configuring the IBM SAN Volume Controller data collector

The IBM SAN Volume Controller (SVC) data collector collects inventory and performance data using SSH, supporting a variety of devices that run the SVC operating system.

The list of supported devices includes models such as the SVC, the v7000, the v5000, and the v3700. Refer to the Cloud Insights support matrix for supported models and firmware versions.

#### **Terminology**

Cloud Insights acquires the following inventory information from the IBM SVC data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive	Disk
Cluster	Storage
Node	Storage Node
Mdisk Group	Storage Pool
Vdisk	Volume
Mdisk	Backend LUNs and paths

Note: These are common terminology mappings only and might not represent every case for this data collector.

# **Inventory Requirements**

- · IP address of each SVC cluster
- · Port 22 available
- · Read-only user name and password

## **Performance Requirements**

- SVC Console, which is mandatory for any SVC cluster and required for the SVC discovery foundation package.
- Credentials will require administrative access level only for copying performance files from cluster nodes to the config node.

Enable data collection by connecting to the SVC cluster by SSH and running: svctask startstats -interval 1
 Note: Alternatively, enable data collection using the SVC management user interface.

## Configuration

Field	Description
Cluster IP Addresses	IP addresses or fully-qualified domain names of the SVC storage
Inventory User Name	User name for the SVC CLI
Inventory Password	Password for the SVC CLI

## **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.
To clean up dumped stats files	Select this checkbox to clean up dumped stats files

### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

Problem:	Try this:
Error: "The command cannot be initiated because it was not run on the configuration node."	The command must be executed on the configuration node.

Some things to try if you encounter problems with this data collector:

Problem:	Try this:
Error: "The command cannot be initiated because it was not run on the configuration node."	The command must be executed on the configuration node.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## Configuring the IBM XIV/A9000 data collector

IBM XIV and A9000 (CLI) data collector uses the XIV command-line interface to collect inventory data while performance collection is accomplished by making SMI-S calls to the XIV/A9000 array, which runs a SMI-S provider on port 7778.

#### **Terminology**

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Storage System	Storage
Storage Pool	Storage Pool
Volume	Volume

### Requirements

The following requirements must be met to configure and use this data collector:

- Port requirement: TCP port 7778
- · Read-only user name and password
- The XIV CLI must be installed on the AU

### Performance requirements

The following are requirements for performance collection:

- · SMI-S Agent 1.4 or higher
- SMI-S compatible CIMService running on array. Most XIV arrays have a CIMServer installed by default.
- User login must be provided for the CIMServer. The login must have full read access to the array configuration and properties.
- SMI-S namespace. Default is root/ibm. This is configurable in the CIMServer.
- Port Requirements: 5988 for HTTP, 5989 for HTTPS.
- Refer to the following link on how to create an account for SMI-S performance collection: http://publib.boulder.ibm.com/infocenter/tivihelp/v4r1/index.jsp? topic=%2Fcom.ibm.tpc V41.doc%2Ffqz0 t adding cim agent.html

#### Configuration

Field	Description
XIV IP address	IP address or fully-qualified domain name of the XIV storage
User Name	User name for the XIV storage
Password	Password for the XIV storage
Full Path to XIV CLI Directory	Full path to the folder containing the XIV CLI
SMI-S Host IP Address	IP address of the SMI-S host

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 40 minutes.
SMI-S Protocol	Protocol used to connect to the SMI-S provider. Also displays the default port.
Override SMI-S Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Username	User name for the SMI-S Provider Host
Password	Password for the SMI-S Provider Host
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

# Lenovo data collector

Cloud Insights uses the Lenovo data collector to discover inventory and performance data for Lenovo HX storage systems.

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- Prism External IP Address
- · Administrator user name and password
- TCP Port requirement: 9440

# Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

# **Advanced configuration**

Field	Description
TCP port	TCP Port used to connect to array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.

Field	Description
Performance poll interval (sec)	Interval between performance polls. The default is 300 seconds.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### **Microsoft**

## Configuring the Azure NetApp Files data collector

Cloud Insights uses the Azure NetApp Files data collector to acquire inventory and performance data.

#### Requirements

You need the following information to configure this data collector.

- Port requirement: 443 HTTPS
- Azure Management Rest IP (management.azure.com)
- Azure service principal client ID (user account)
- Azure service principal authentication key (user password)
- · You need to set up an Azure account for Cloud Insights discovery.

Once the account is properly configured and you register the application in Azure, you will have the credentials required to discover the Azure instance with Cloud Insights. The following link describes how to set up the account for discovery:

https://docs.microsoft.com/en-us/azure/active-directory/develop/howto-create-service-principal-portal

### Configuration

Enter data into the data collector fields according to the table below:

Field	Description
Azure Service Principal Client ID	Sign-in ID to Azure
Azure Tenant ID	Azure Tenant ID
Azure Service Principal Authentication Key	Login authentication key
I understand Microsoft bills me for API requests	Check this to verify your understanding that Microsoft bills you for API requests made by Insight polling.

## **Advanced Configuration**

Field	Description
Inventory Poll Interval (min)	The default is 60

- The credentials used by your ANF data collector must not have access to any Azure subscriptions that contain ANF volumes.
- If Reader access causes performance collection to fail, try granting contributor access on a resource group level.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### Microsoft Hyper-V data collector

The Microsoft Hyper-V data collector acquires inventory and performance data from the virtualized server computing environment.

#### **Terminology**

Cloud Insights acquires the following inventory information from the Microsoft Hyper-V (WMI). For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Virtual Hard Disk	Virtual Disk
Host	Host
Virtual Machine	Virtual Machine
Cluster Shared Volumes (CSV), Partition Volume	Data Store
Internet SCSI Device, Multi Path SCSI LUN	LUN
Fiber Channel Port	Port

Note: These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

The following are required to configure this data collector:

- The Hyper-V requires port 5985 opened for data collection and remote access/management.
- · IP address of Clustering group node
- · Local Administrator user & password on the hypervisor
- · Administrative-level user account
- Windows Management Instrumentation (WMI) command, which is the default that is installed by Windows.
- Port requirements: Port 135 via WMI & Dynamic TCP ports assigned 1024-65535 for Windows 2003 and older and 49152-65535 for Windows 2008.

- DNS resolution must succeed, even if the data collector is pointed at only an IP address
- Each Hyper-V hypervisor must have "Resource Metering" turned on for every VM, on every host. This allows each hypervisor to have more data available for Cloud Insights on each guest. If this is not set, fewer performance metrics are acquired for each guest. More information on Resource metering can be found in the microsoft documentation:

Hyper-V Resource Metering Overview

**Enable-VMResourceMetering** 



The Hyper-V data collector requires a Windows Acquisition Unit.

#### Configuration

Field	Description
Physical Host IP Address	The IP address or fully-qualified domain name for the physical host (hypervisor)
User Name	Administrator user name for the hypervisor
Password	Password for the hypervisor
NT Domain	The DNS name used by the nodes in the cluster

### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	The default is 20 minutes.

#### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

# **NetApp**

#### NetApp Astra Data Store data collector

This data collector acquires inventory and performance data for a single Astra Data Store cluster. In addition to the data collector, the Monitoring Operator will configure *Telegraf* to collect advanced metrics and *Fluent Bit* to collect logs.



These installation instructions and additional information can also be found in the Astra Data Store documentation:

Monitor metrics with Cloud Insights
Quick start for Astra Data Store

#### **Terminology**

Cloud Insights acquires inventory and performance data from this data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data

collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
AstraDSVolume	Internal Volume
AstraDSNodeInfo.status.drives	Disk
AstraDSNodeInfo	Storage Node
AstraDSExportPolicy	Share / Share Initiator
AstraDSCluster	Storage

#### Requirements

- The NetApp Monitoring Operator must be installed in the Kubernetes cluster with Astra Data Store. If this was not installed during the Astra Data Store installation, please install the monitoring operator following the Astra Data Store installation instructions.
- The *kubectl-astrads* kubectl plugin must be installed. If it is not installed, please install the *kubectl-astrads* binary following the Astra Data Store installation instructions.
- The following commands must be available: awk, curl, grep and jq.

#### Installation

The installation script will walk you through installation of the Astra Data Store data collector. Follow the instructions on-screen. Installation will take several minutes to complete. Once complete, it may take a few more minutes before data is shown in Cloud Insights.

The script will walk you through the following steps:

- 1. Choose an API Access Token.
- 2. Copy the installer script from the installation dialog and save it as as a file named *cloudinsights-ads-monitoring.sh*. You can click the clipboard icon to quickly copy the script to the clipboard.
- 3. Open a Bash window, change directory to the location of the cloudinsights-ads-monitoring.sh script.
- 4. Copy the permissions command block from the installation dialog. You can click the clipboard icon to quickly copy the command to the clipboard.
- 5. Paste the permissions command into the Bash window and press Enter.
- 6. Copy the install command from the installation dialog. You can click the clipboard icon to quickly copy the command to the clipboard.
- 7. Paste the install command into the Bash window.
- 8. Replace <KUBERNETES IP> with the IP address of the Kubernetes API server.
- 9. Replace <KUBERNETES\_TOKEN> with your Kubernetes API token.
- 10. Press Enter.

The installer script will:

- \* Verify the Monitoring Operator is installed and configured.
- \* Configure Fluent Bit.
- \* Configure Telegraf.
- \* Install the Acquisition Unit.
- \* Install the Astra Data Store collector once the Acquisition Unit is running.

### 11. Click Complete Setup.

If the installer script exits due to an error, you can rerun it again once the error is resolved. The installer script supports additional parameters such as the Monitoring Operator namespace and Kubernetes API server port if your environment does not use the default settings. A full list of available options is listed below.

### **Installer script options:**

Note that the Cloud Insights domain name and selected API Access Key will be embedded in the installer script when it is downloaded.

```
$ ./cloudinsights-ads-monitoring.sh -h
USAGE: cloudinsights-ads-monitoring.sh [OPTIONS]
Configure monitoring of Astra Data Store by Cloud Insights.
OPTIONS:
 -h
                         Display this help message.
 -d ci domain name
                         Cloud Insights tenant domain name.
 -i kubernetes ip
                         Kubernetes API server IP address.
 -k ci api key
                         Cloud Insights API Access Key.
                         Namespace for monitoring components. (default:
 -n namespace
netapp-monitoring)
 -p kubernetes port
                        Kubernetes API server port. (default: 6443)
                         Create 3 Persistent Volumes in this directory for
 -r root pv dir
the Acquisition Unit.
                         Only specify this option if there is no Storage
Provisioner installed and the PVs do not already exist.
                         Storage Class name for provisioning Acquisition
 -s storage class
Unit PVs. If not specified, the default storage class will be used.
 -t kubernetes token
                         Kubernetes API server token.
```

### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

### Astra Data Store data collector

Problem:	Try this:
You see an "Unauthorized" message	Check that the Kubernetes API Token has permission to call APIs in the <i>astrads.netapp.io</i> apiGroup
"Unknown host: astrads-metrics-service.astrads- system.svc.cluster.local: Name or service not known"	Verify the collector is installed in an Acquisition Unit pod running inside the ADS Kubernetes cluster. Verify the astrads-metrics-service is running the astrads-system namespace.

### **Installation Script**

Problem:	Try this:
The monitoring operator is not running in <namespace> namespace.</namespace>	Follow the Astra Data Store installation instructions to install it
Acquisition Unit pod <pod> did not start successfully after 300 seconds.</pod>	Get the name of the acquisition unit pod: kubectl get podsnamespace netapp-monitoring   grep "au-pod" Check the pod events for errors: kubectl describe podnamespace netapp-monitoring <pod_name></pod_name>
Acquisition Unit installation has not finished after 900 seconds	Get the name of the acquisition unit pod: kubectl get podsnamespace netapp-monitoring   grep "au-pod" Check the pod logs for errors: kubectl logsnamespace netapp-monitoring <pod_name> If there are no errors and the logs end with the message "Main - Acquisition is up and running!", the install succeeded but too longer than expected. Rerun the installation script.</pod_name>
Failed to retrieve Acquisition Unit id from Cloud Insights	Verify the Acquisition Unit appears in Cloud Insights. Go to Admin > Data Collectors and click on the Acquisition Units tab. Verify the Cloud Insights API key has permission for Acquisition Unit.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## NetApp Cloud Connection for ONTAP 9.9+ data collector

This data collector creates a cloud connection to support data collection from ONTAP 9.9+ CVO, AFF, and FAS systems.

## Configuration

Cloud Insights collects data from ONTAP 9.9+ using a **cloud connection**, eliminating the need to install an external acquisition unit, simplifying troubleshooting, maintenance, and initial deployment. Configuration of the cloud connection for the ONTAP 9.9+ data collector requires you to copy a **Pairing Code** to the ONTAP System Manager, which will then establish a connection to your Cloud Insights environment. After the connection is established, the data collected is the same as it would be if it was collected through an acquisition unit.

This data collector supports ONTAP 9.9+ CVO, AFF, and FAS systems.



## **Configure Collector**

Quickly add a cloud connection in your environment and immediately start monitoring data

#### Connect to ONTAP 9.9+ via a Cloud Connection

Need Help?





- In a new tab, login to ONTAP System Manager (SM) for the cluster you would like to monitor and navigate to Cluster > Settings > Cloud Connections.
- Click on Add Cloud Connection and paste the Pairing Code from step 2.
- 5 The connection will be established automatically with no additional user interaction. Check System Manager for error messages if connection is not established after a few minutes.

Follow these steps to configure the connection:

- Generate a unique token which will be used to establish the connection to the ONTAP system.
- Copy the Pairing Code, which includes the token. You can view the pairing code by clicking on [+] Reveal Code Snippet.

Once you copy the pairing code, the data collector configuration screen will reveal a step 6, prompting you to wait for the connection to be established. Nothing more needs to be done on this screen until the connection is established.



- In a new browser tab, log into the ONTAP System Manager and navigate to Cluster > Settings > Cloud Connections.
- · Click Add Cloud Connection and paste the pairing code.
- Return to the Cloud Insights browser tab and wait for the connection to be established. Once it is established, a *Complete* button is revealed.
- · Click Complete.

#### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

Problem:	Try this:
I'm seeing the following error while trying to connect to Azure CVO: "The certificate signing request to broker/manager CA service was not completed."	Verify that your Cloud manager proxy settings are set to the Cloud Manager private IP. Cloud Manager installation may set a different proxy. Once the proxy is set to the correct IP and you reference the proxy in the Cloud Connector dialog, the connection to Cloud Insights should connect successfully.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## NetApp Cloud Volumes ONTAP data collector

This data collector supports inventory collection from Cloud Volumes ONTAP configurations.

## Configuration

Field	Description
NetApp Management IP Address	IP address for Cloud Volumens ONTAP
User Name	User name for Cloud Volumes ONTAP
Password	Password for the above user

## Advanced configuration

Field	Description
Connection Type	HTTPS recommended. Also shows default port.
Override Communication Port	Port to use if not default.
Inventory Poll Interval (min)	Default is 60 minutes.
Inventory Concurrent Thread Count	Number of concurrent threads.
Force TLS for HTTPS	Force TLS over HTTPS
Automatically Lookup Netgroups	Automatically Lookup Netgroups
Netgroup Expansion	Select Shell or File
HTTP read timeout seconds	Default is 30 seconds
Force responses as UTF-8	Force responses as UTF-8
Performance Poll Interval (min)	Default is 900 seconds.
Performance Concurrent Thread Count	Number of concurrent threads.
Advanced Counter Data Collection	Check this to have Cloud Insights collect the advanced metrics from the list below.

## **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector

### Support Matrix.

### NetApp Cloud Volumes Services for AWS data collector

This data collector supports inventory collection from NetApp Cloud Volumes Services for AWS configurations.

## Configuration

Field	Description
Cloud Volumes Region	Region of the NetApp Cloud Volumes Services for AWS
API Key	Cloud Volumes API key
Secret Key	Cloud Volumes secret key

#### **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes

### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### NetApp Config Advisor data collector

This data collector acquires configuration data from storage systems running ONTAP and connected switches using read-only calls. This data collector also runs configuration validation and health checks on the whole stack of ONTAP cluster configuration to identify cabling, configuration, resiliency, availability and security issues.



Config Advisor is considered a *Preview* feature and is therefore subject to change. During Preview, no MU cost is incurred.

### **Terminology**

Cloud Insights acquires configuration data from ONTAP and switches with the Config Advisor data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Switch	Switch
Cluster	Storage
Node	Storage Node

Vendor/Model Term	Cloud Insights Term
Aggregate	Storage Pool
LUN	Volume
Volume	Internal Volume

In addition, note that Config Advisor metrics will be available in dashboard and other queries with the *netapp\_ontap.configadvisor* tag.



### **Config Advisor Terminology**

The following terms apply to objects or references that you might find on Config Advisor dashboards.

### **Device Summary**

- Model A comma-delimited list of the unique, discrete node model names within this cluster. If all the nodes in the clusters are the same model type, just one model name will appear.
- Device Type/Type type of the device in data source Storage Controller/Switch
- Vendor/Subtype same Vendor name you would see if you were configuring a new data source.
- Serial number The array serial number. On cluster architecture storage systems like ONTAP Data Management, this serial number may be less useful than the individual "Storage Nodes" serial numbers.
- Hostname –hostname(s) as configured in the data source.
- Version OS or firmware version.

#### **Rule Results**

- Rule A check that is run against the system analysing deviation in configuration from recommended practices or identifying known issues.
- Rule Name short name for the rule or check that is run.
- Rule ID identifier for the rule.
- Target component on which the rule is applied. It would be cluster name, node name or switch name.
- Impact Impact of the risk on the system. Impact levels are categorized as below
  - · High Impact: Potential loss of data access or prolonged loss of node redundancy
  - Medium Impact: Performance degradation or short-term loss of node redundancy.
  - Low Impact: Low impact scenarios
  - Best Practice: Deviations from documented Best Practices
- Description Brief description of the error.
- Details detailed description of the error listing the components impacted
  - Recommendations Links to KB articles or NetApp documentation providing additional details on the

risk or remediation.

### Requirements

The following are requirements to configure and use this data collector:

- You must have access to an administrator account configured for read-only access for SSH and ONTAPi calls on ONTAP.
- You must have access to an administrator account configured for read-only access for SSH calls on switches if they are part of collection
- Account details include username and password. Optionally can pass the SSH private key if ONTAP is configured for SSH key based authentication or Multi Factor Authentication (MFA)
- Port requirements: 22, 80 or 443
- Account permissions:
  - Read only role name to ssh or/and ontapi application to the default Vserver
  - · Admin account with at least read-only permission on switches

### Configuration

Field	Description
NetApp Management IP	IP address or fully-qualified domain name of the NetApp cluster
User Name	User name for NetApp cluster
Password	Password for NetApp cluster

### **Advanced configuration**

Field	Description
Enable MFA for ONTAP	Check this to enable Multi-Factor Authentication on ONTAP
SSH Private Key	Paste the SSH private key content if ONTAP is using SSH key authentication or MFA
Connection type	Choose HTTP (default port 80) or HTTPS (default port 443). The default is HTTPS
ONTAP SSH Port	Allows to specify custom SSH port for ONTAP connection
Switch SSH Port	Allows to specify custom SSH port for Switch connection
Poll Interval (min)	Default is 1440 minutes or 24 hours. Can set minimum up to 60 min

## **Supported Operating Systems**

Config Advisor can run on following operating systems. If collector is installed on an Acquisition Unit with Operating System not in this list, collections would fail.

- Windows 10 (64-bit)
- Windows 2012 R2 Server (64-bit)
- Windows 2016 Server (64-bit)
- Windows 2019 Server (64-bit)
- Red Hat Enterprise Linux (RHEL) 7.7 and later (64-bit)
- Ubuntu 14.0 and later

### Support

For questions associated with Config Advisor, open a ticket from the Config Advisor Tool by clicking on Help  $\rightarrow$  Open Support Ticket.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

### NetApp ONTAP Data Management Software data collector

This data collector acquires inventory and performance data from storage systems running ONTAP using read-only API calls from an ONTAP account. This data collector also creates a record in the cluster application registry to accelerate support.

### **Terminology**

Cloud Insights acquires inventory and performance data from the ONTAP data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Raid Group	Disk Group
Cluster	Storage
Node	Storage Node
Aggregate	Storage Pool
LUN	Volume
Volume	Internal Volume

### **ONTAP Data Management Terminology**

The following terms apply to objects or references that you might find on ONTAP Data Management storage asset landing pages. Many of these terms apply to other data collectors as well.

### **Storage**

- Model A comma-delimited list of the unique, discrete node model names within this cluster. If all the nodes in the clusters are the same model type, just one model name will appear.
- Vendor same Vendor name you would see if you were configuring a new data source.
- Serial number The array serial number. On cluster architecture storage systems like ONTAP Data

Management, this serial number may be less useful than the individual "Storage Nodes" serial numbers.

- IP generally will be the IP(s) or hostname(s) as configured in the data source.
- Microcode version firmware.
- Raw Capacity base 2 summation of all the physical disks in the system, regardless of their role.
- Latency a representation of what the host facing workloads are experiencing, across both reads and
  writes. Ideally, Cloud Insights is sourcing this value directly, but this is often not the case. In lieu of the array
  offering this up, Cloud Insights is generally performing an IOPs-weighted calculation derived from the
  individual internal volumes' statistics.
- Throughput aggregated from internal volumes.
   Management this may contain a hyperlink for the management interface of the device. Created programmatically by the Cloud Insights data source as part of inventory reporting.

## Storage Pool

- Storage what storage array this pool lives on. Mandatory.
- Type a descriptive value from a list of an enumerated list of possibilities. Most commonly will be "Aggregate" or "RAID Group"".
- Node if this storage array's architecture is such that pools belong to a specific storage node, its name will be seen here as a hyperlink to its own landing page.
- Uses Flash Pool Yes/No value does this SATA/SAS based pool have SSDs used for caching acceleration?
- Redundancy RAID level or protection scheme. RAID DP is dual parity, RAID TP is triple parity.
- Capacity the values here are the logical used, usable capacity and the logical total capacity, and the percentage used across these.
- Over-committed capacity If by using efficiency technologies you have allocated a sum total of volume or internal volume capacities larger than the logical capacity of the storage pool, the percentage value here will be greater than 0%.
- Snapshot snapshot capacities used and total, if your storage pool architecture dedicates part of its capacity to segments areas exclusively for snapshots. ONTAP in MetroCluster configurations are likely to exhibit this, while other ONTAP configurations are less so.
- Utilization a percentage value showing the highest disk busy percentage of any disk contributing capacity
  to this storage pool. Disk utilization does not necessarily have a strong correlation with array performance –
  utilization may be high due to disk rebuilds, deduplication activities, etc in the absence of host driven
  workloads. Also, many arrays' replication implementations may drive disk utilization while not showing as
  internal volume or volume workload.
- IOPS the sum IOPs of all the disks contributing capacity to this storage pool.

  Throughput the sum throughput of all the disks contributing capacity to this storage pool.

### **Storage Node**

- Storage what storage array this node is part of. Mandatory.
- HA Partner on platforms where a node will fail over to one and only one other node, it will generally be seen here.
- State health of the node. Only available when the array is healthy enough to be inventoried by a data source
- Model model name of the node.

- Version version name of the device.
- Serial number The node serial number.
- Memory base 2 memory if available.
- Utilization On ONTAP, this is a controller stress index from a proprietary algorithm. With every
  performance poll, a number between 0 and 100% will be reported that is the higher of either WAFL disk
  contention, or average CPU utilization. If you observe sustained values > 50%, that is indicative of
  undersizing potentially a controller/node not large enough or not enough spinning disks to absorb the
  write workload.
- IOPS Derived directly from ONTAP ZAPI calls on the node object.
- · Latency Derived directly from ONTAP ZAPI calls on the node object.
- Throughput Derived directly from ONTAP ZAPI calls on the node object.
- Processors CPU count.

### Requirements

The following are requirements to configure and use this data collector:

- You must have access to an Administrator account configured for read-only API calls.
- · Account details include username and password.
- Port requirements: 80 or 443
- Account permissions:
  - Read only role name to ontapi application to the default Vserver
  - You may require additional optional write permissions. See the Note About Permissions below.
- ONTAP License requirements:
  - FCP license and mapped/masked volumes required for fibre-channel discovery

### Configuration

Field	Description
NetApp Management IP	IP address or fully-qualified domain name of the NetApp cluster
User Name	User name for NetApp cluster
Password	Password for NetApp cluster

## Advanced configuration

Field	Description
Connection type	Choose HTTP (default port 80) or HTTPS (default port 443). The default is HTTPS
Override Communication Port	Specify a different port if you do not want to use the default
Inventory Poll Interval (min)	Default is 60 minutes.
For TLS for HTTPS	Only allow TLS as protocol when using HTTPS

Field	Description
Automatically Lookup Netgroups	Enable the automatic netgroup lookups for export policy rules
Netgroup Expansion	Netgroup Expansion Strategy. Choose <i>file</i> or <i>shell</i> . The default is <i>shell</i> .
HTTP read timeout seconds	Default is 30
Force responses as UTF-8	Forces data collector code to interpret responses from the CLI as being in UTF-8
Performance Poll Interval (sec)	Default is 900 seconds.
Advanced Counter Data Collection	Enable ONTAP integration. Select this to include ONTAP Advanced Counter data in polls. Choose the desired counters from the list.

#### A Note About Permissions

Since a number of Cloud Insights' ONTAP dashboards rely on advanced ONTAP counters, you must enable **Advanced Counter Data Collection** in the data collector Advanced Configuration section.

You should also ensure that write permission to the ONTAP API is enabled. This typically requires an account at the cluster level with the necessary permissions.

To create a local account for Cloud Insights at the cluster level, log in to ONTAP with the Cluster management Administrator username/password, and execute the following commands on the ONTAP server:

- 1. Before you begin, you must be signed in to ONTAP with an *Administrator* account, and *diagnostic-level commands* must be enabled.
- 2. Create a read-only role using the following commands.

```
security login role create -role ci_readonly -cmddirname DEFAULT -access readonly security login role create -role ci_readonly -cmddirname security -access readonly security login role create -role ci_readonly -access all -cmddirname "cluster application-record create"
```

3. Create the read-only user using the following command. Once you have executed the create command, you will be prompted to enter a password for this user.

```
security login create -username ci_user -application ontapi -authentication-method password -role ci_readonly
```

If AD/LDAP account is used, the command should be

```
security login create -user-or-group-name DOMAIN\aduser/adgroup -application ontapi -authentication-method domain -role ci_readonly
```

The resulting role and user login will look something like the following. Your actual output may vary:

## **Troubleshooting**

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Receive 401 HTTP response or 13003 ZAPI error code and ZAPI returns "Insufficient privileges" or "not authorized for this command"	Check username and password, and user privileges/permissions.
Cluster version is < 8.1	Cluster minimum supported version is 8.1. Upgrade to minimum supported version.
ZAPI returns "cluster role is not cluster_mgmt LIF"	AU needs to talk to cluster management IP. Check the IP and change to a different IP if necessary
Error: "7 Mode filers are not supported"	This can happen if you use this data collector to discover 7 mode filer. Change IP to point to cdot cluster instead.
ZAPI command fails after retry	AU has communication problem with the cluster. Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.
AU failed to connect to ZAPI via HTTP	Check whether ZAPI port accepts plaintext. If AU tries to send plaintext to an SSL socket, the communication fails.

Problem:	Try this:
Communication fails with SSLException	AU is attempting to send SSL to a plaintext port on a filer. Check whether the ZAPI port accepts SSL, or use a different port.
Additional Connection errors:  ZAPI response has error code 13001, "database is not open"	Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.
ZAPI error code is 60 and response contains "API did not finish on time"	
ZAPI response contains "initialize_session() returned NULL environment"	
ZAPI error code is 14007 and response contains "Node is not healthy"	

### **Performance**

Problem:	Try this:
"Failed to collect performance from ZAPI" error	This is usually due to perf stat not running. Try the following command on each node:
	> system node systemshell -node * -command "spmctl -h cmd -stop; spmctl -h cmd -exec"

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## NetApp Data ONTAP operating in 7-Mode data collector

For storage systems using Data ONTAP software operating in 7-Mode, you use the 7-mode data collector, which uses the CLI to obtain capacity and performance data.

### **Terminology**

Cloud Insights acquires the following inventory information from the NetApp 7-mode data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Raid Group	Disk Group
Filer	Storage
Filer	Storage Node
Aggregate	Storage Pool
LUN	Volume

Vendor/Model Term	Cloud Insights Term
Volume	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

You need the following to configure and use this data collector:

- IP addresses of the FAS storage controller and partner.
- Port 443
- A custom admin level username and password for controller and partner controller with the following role capabilities for 7-Mode:
  - "api-\*": Use this to allow OnCommand Insight to execute all NetApp storage API commands.
  - "login-http-admin": Use this to allow OnCommand Insight to connect to the NetApp storage via HTTP.
  - "security-api-vfiler": Use this to allow OnCommand Insight to execute NetApp storage API commands to retrieve vFiler unit information.
  - "cli-options": Use this to read storage system options.
  - "cli-lun": Access these commands for managing LUNs. Displays the status (LUN path, size, online/offline state, and shared state) of the given LUN or class of LUNs.
  - "cli-df": Use this to display free disk space.
  - "cli-ifconfig": Use this to display interfaces and IP addresses.

### Configuration

Field	Description
Address of storage system	IP address or fully-qualified domain name for the NetApp storage system
User Name	User name for the NetApp storage system
Password	Password for the NetApp storage system
Address of HA Partner in Cluster	IP address or fully-qualified domain name for the HA Partner
User Name of HA Partner in Cluster	User name for the HA partner
Password of HA Partner Filer in Cluster	Password for the HA Partner

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.
Connection Type	HTTPS or HTTP, also displays the default port

Field	Description
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Performance Poll Interval (sec)	Interval between performance polls. The default is 300 seconds.

#### Storage systems connection

As an alternative to using the default administrative user for this data collector, you can configure a user with administrative rights directly on the NetApp storage systems so that this data collector can acquire data from NetApp storage systems.

Connecting to NetApp storage systems requires that the user, who is specified when acquiring the main pfiler (on which the storage system exist), meet the following conditions:

• The user must be on vfiler0 (root filer/pfiler).

Storage systems are acquired when acquiring the main pfiler.

- The following commands define the user role capabilities:
  - "api-\*": Use this to allow Cloud Insights to execute all NetApp storage API commands.

This command is required to use the ZAPI.

- "login-http-admin": Use this to allow Cloud Insights to connect to the NetApp storage via HTTP. This command is required to use the ZAPI.
- "security-api-vfiler": Use this to allow Cloud Insights to execute NetApp storage API commands to retrieve vFiler unit information.
- "cli-options": For "options" command and used for partner IP and enabled licenses.
- "cli-lun": Access these command for managing LUNs. Displays the status (LUN path, size, online/offline state, and shared state) of the given LUN or class of LUNs.
- "cli-df": For "df -s", "df -r", "df -A -r" commands and used to display free space.
- "cli-ifconfig": For "ifconfig -a" command and used for getting filer IP address.
- "cli-rdfile": For "rdfile /etc/netgroup" command and used for getting netgroups.
- "cli-date": For "date" command and used to get full date for getting Snapshot copies.
- "cli-snap": For "snap list" command and used for getting Snapshot copies.

If cli-date or cli-snap permissions are not provided, acquisition can finish, but Snapshot copies are not reported.

To acquire a 7-Mode data source successfully and generate no warnings on the storage system, you should use one of the following command strings to define your user roles. The second string listed here is a streamlined version of the first:

- login-http-admin,api-\*,security-api-vfile,cli-rdfile,cli-options,cli-df,cli-lun,cli-ifconfig,cli-date,cli-snap,
- login-http-admin,api-\* ,security-api-vfile,cli-

## Troubleshooting

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
Receive 401 HTTP response or 13003 ZAPI error code and ZAPI returns "Insufficient privileges" or "not authorized for this command"	Check username and password, and user privileges/permissions.
"Failed to execute command" error	Check whether the user has the following permission on the device:  • api-*  • cli-date  • cli-df  • cli-ifconfig  • cli-lun  • cli-operations  • cli-rdfile  • cli-snap  • login-http-admin  • security-api-vfiler  Also check if the ONTAP version is supported by Cloud Insights and verify if the credentials used match device credentials
Cluster version is < 8.1	Cluster minimum supported version is 8.1. Upgrade to minimum supported version.
ZAPI returns "cluster role is not cluster_mgmt LIF"	AU needs to talk to cluster management IP. Check the IP and change to a different IP if necessary
Error: "7 Mode filers are not supported"	This can happen if you use this data collector to discover 7 mode filer. Change IP to point to cdot filer instead.
ZAPI command fails after retry	AU has communication problem with the cluster. Check network, port number, and IP address. User should also try to run a command from command line from the AU machine.
AU failed to connect to ZAPI	Check IP/port connectivity and assert ZAPI configuration.
AU failed to connect to ZAPI via HTTP	Check whether ZAPI port accepts plaintext. If AU tries to send plaintext to an SSL socket, the communication fails.
Communication fails with SSLException	AU is attempting to send SSL to a plaintext port on a filer. Check whether the ZAPI port accepts SSL, or use a different port.

Problem:	Try this:
Additional Connection errors:	Check network, port number, and IP address. User should also try to run a command from command line
ZAPI response has error code 13001, "database is not open"	from the AU machine.
ZAPI error code is 60 and response contains "API did not finish on time"	
ZAPI response contains "initialize_session() returned NULL environment"	
ZAPI error code is 14007 and response contains "Node is not healthy"	
Socket timeout error with ZAPI	Check filer connectivity and/or increase timeout.
"C Mode clusters are not supported by the 7 Mode data source" error	Check IP and change the IP to a 7 Mode cluster.
"Failed to connect to vFiler" error	Check that the acquiring user capabilities include the following at a minimum:  api-* security-api-vfiler login-http-admin Confirm that filer is running minimum ONTAPI version 1.7.

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## **NetApp E-Series data collector**

The NetApp E-Series data collector gathers inventory and performance data. The collector supports firmware 7.x+ using the same configurations and reporting the same data.

## Terminology

Cloud insight acquires the following inventory information from the NetApp E-Series data collector. For each asset type acquired, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Disk
Volume Group	Disk Group
Storage Array	Storage
Controller	Storage Node
Volume Group	Storage Pool
Volume	Volume

Note: These are common terminology mappings only and might not represent every case for this data collector.

### E-Series Terminology (Landing Page)

The following terms apply to objects or references that you might find on NetApp E-Series asset landing pages. Many of these terms apply to other data collectors as well.

### **Storage**

- Model model name of the device.
- · Vendor same Vendor name you would see if you were configuring a new datasource
- Serial number The array serial number. On cluster architecture storage systems like NetApp Clustered Data Ontap, this serial number may be less useful than the individual "Storage Nodes" serial numbers
- IP generally will be the IP(s) or hostname(s) as configured in the data source
- Microcode version firmware
- Raw Capacity base 2 summation of all the physical disks in the system, regardless of their role
- Latency a representation of what the host facing workloads are experiencing, across both reads and
  writes. Ideally, Cloud Insights is sourcing this value directly, but this is often not the case. In lieu of the array
  offering this up, Cloud Insights is generally performing an IOPs-weighted calculation derived from the
  individual volumes' statistics.
- Throughput the array's total host facing throughput. Ideally sourced directly from the array, if unavailable, Cloud Insights is summing the volumes' throughput to derive this value
- Management this may contain a hyperlink for the management interface of the device. Created programmatically by the Cloud Insights datasource as part of inventory reporting

### Storage Pool

- Storage what storage array this pool lives on. Mandatory
- Type a descriptive value from a list of an enumerated list of possibilities. Most commonly will be "Thin Provisioning" or "RAID Group"
- Node if this storage array's architecture is such that pools belong to a specific storage node, its name will be seen here as a hyperlink to its own landing page
- Uses Flash Pool Yes/No value
- Redundancy RAID level or protection scheme. E-Series reports "RAID 7" for DDP pools
- Capacity the values here are the logical used, usable capacity and the logical total capacity, and the
  percentage used across these. These value both include E-Series "preservation" capacity, resulting both in
  numbers and the percentage being higher than what the E-Series own user interface may show
- Over-committed capacity If via efficiency technologies you have allocated a sum total of volume or internal volume capacities larger than the logical capacity of the storage pool, the percentage value here will be greater than 0%.
- Snapshot snapshot capacities used and total, if your storage pool architecture dedicates part of its capacity to segments areas exclusively for snapshots
- Utilization a percentage value showing the highest disk busy percentage of any disk contributing capacity to this storage pool. Disk utilization does not necessarily have a strong correlation with array performance utilization may be high due to disk rebuilds, deduplication activities, etc in the absence of host driven

workloads. Also, many arrays' replication implementations may drive disk utilization while not showing as volume workload.

- IOPS the sum IOPs of all the disks contributing capacity to this storage pool. If disk IOPs is not available
  on a given platform, this value will be sourced from the sum of volume IOPs for all the volumes sitting on
  this storage pool
- Throughput the sum throughput of all the disks contributing capacity to this storage pool. If disk
  throughput is not available on a given platform, this value will be sourced from the sum of volume
  throughout for all the volumes sitting on this storage pool

### Storage Node

- Storage what storage array this node is part of. Mandatory
- HA Partner on platforms where a node will fail over to one and only one other node, it will generally be seen here
- State health of the node. Only available when the array is healthy enough to be inventoried by a data source
- Model model name of the node
- Version version name of the device.
- Serial number The node serial number
- Memory base 2 memory if available
- Utilization Generally a CPU utilization number, or in the case of NetApp Ontap, a controller stress index. Utilization is not currently available for NetApp E-Series
- IOPS a number representing the host driven IOPs on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by summing all the IOPs for volumes that belong exclusively to this node.
- Latency a number representing the typical host latency or response time on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by performing an IOPs weighted calculation from volumes that belong exclusively to this node.
- Throughput a number representing the host driven throughput on this controller. Ideally sourced directly from the array, if unavailable, it will be calculated by summing all the throughput for volumes that belong exclusively to this node.
- Processors CPU count

### Requirements

- The IP address of each controller on the array
- Port requirement 2463

### Configuration

Field	Description
Comma-separated list of Array SANtricity Controller IPs	IP addresses and/or fully-qualified domain names for the array controllers

### Advanced configuration

Field	Description
Inventory Poll Interval (min)	Default is 30 minutes
Performance Poll Interval up to 3600 seconds	Default is 300 seconds

### **Troubleshooting**

Additional information on this data collector may be found from the Support page or in the Data Collector Support Matrix.

### Configuring the NetApp HCI Management server data collector

The NetApp HCI Management server data collector collects NetApp HCI Host information and requires read-only privileges on all objects within the Management server.

This data collector acquires from the **NetApp HCI Management server only**. To collect data from the storage system, you must also configure the NetApp SolidFire data collector.

### **Terminology**

Cloud Insights acquires the following inventory information from this data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Virtual disk	Disk
Host	Host
Virtual machine	Virtual machine
Data store	Data store
LUN	Volume
Fibre channel port	Port

These are common terminology mappings only and might not represent every case for this data collector.

#### Requirements

The following information is required to configure this data collector:

- IP address of the NetApp HCl Management server
- Read-only username and password for the NetApp HCI Management server
- Read only privileges on all objects in the NetApp HCI Management server.
- SDK access on the NetApp HCI Management server normally already set up.
- Port requirements: http-80 https-443
- Validate access:
  - Log into the NetApp HCI Management server using above username and password
  - Verify SDK enabled: telnet <vc ip> 443

## **Setup and connection**

Field	Description
Name	Unique name for the data collector
Acquisition unit	Name of acquisition unit

## Configuration

Field	Description
NetApp HCI Storage Cluster MVIP	Management Virtual IP Address
SolidFire Management Node (mNode)	Management Node IP Address
User name	User name used to access the NetApp HCI Management server
Password	Password used to access the NetApp HCI Management server
VCenter User Name	User name for VCenter
VCenter Password	Password for VCenter

## Advanced configuration

In the advanced configuration screen, check the **VM Performance** box to collect performance data. Inventory collection is enabled by default.

The following fields can be configured:

Field	Description
Inventory poll interval (min)	Deafult is 20
Filter VMs by	Select CLUSTER, DATACENTER, or ESX HOST
Choose 'Exclude' or 'Include' to Specify a List	Specify Whether to Include or Exclude VMs
Filter Device List	List of VMs to filter (comma separated, or semicolon separated if comma is used in the value) for for Filtering by ESX_HOST, CLUSTER, and DATACENTER Only
Performance poll interval (sec)	Default is 300

## Troubleshooting

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
Error: Include list to filter VMs cannot be empty	If Include List is selected, please list valid DataCenter, Cluster, or Host names to filter VMs

Problem:	Try this:
Error: Failed to instantiate a connection to VirtualCenter at IP	* Verify credentials and IP address entered.  * Try to communicate with Virtual Center using Infrastructure Client.  * Try to communicate with Virtual Center using Managed Object Browser (e.g MOB).
Error: VirtualCenter at IP has non-conform certificate that JVM requires	* Recommended: Re-generate certificate for Virtual Center by using stronger (e.g. 1024-bit) RSA key.  * Not Recommended: Modify the JVM java.security configuration to leverage the constraint jdk.certpath.disabledAlgorithms to allow 512-bit RSA key. See JDK 7 update 40 release notes at "http://www.oracle.com/technetwork/java/javase/7u40-relnotes-2004172.html"

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## NetApp SolidFire All-Flash Array data collector

The NetApp SolidFire All-Flash Array data collector supports inventory and performance collection from both iSCSI and Fibre Channel SolidFire configurations.

The SolidFire data collector utilizes the SolidFire REST API. The acquisition unit where the data collector resides needs to be able to initiate HTTPS connections to TCP port 443 on the SolidFire cluster management IP address. The data collector needs credentials capable of making REST API queries on the SolidFire cluster.

## **Terminology**

Cloud Insights acquires the following inventory information from the NetApp SolidFire All-Flash Array data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive	Disk
Cluster	Storage
Node	Storage Node
Volume	Volume
Fibre channel port	Port
Volume Access Group, LUN Assignment	Volume Map
iSCSI Session	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

The following are requirements for configuring this data collector:

- · Management Virtual IP Address
- · Read-only username and credentials
- Port 443

### Configuration

Field	Description
Management Virtual IP Address (MVIP)	Management Virtual IP address of the SolidFire Cluster
User Name	Name used to log into the SolidFire cluster
Password	Password used to log into the SolidFire cluster

### **Advanced configuration**

Field	Description
Connection Type	Choose connection type
Communication Port	Port used for NetApp API
Inventory Poll Interval (min)	Default is 20 minutes
Performance Poll Interval (sec)	Default is 300 seconds

### **Troubleshooting**

When SolidFire reports an error it is displayed in Cloud Insights as follows:

An error message was received from a SolidFire device while trying to retrieve data. The call was <method> (<parameterString> ). The error message from the device was (check the device manual): <message>

### Where:

- The <method> is an HTTP method, such as GET or PUT.
- The <parameterString> is a comma separated list of parameters that were included in the REST call.
- The <message> is whatever the device returned as the error message.

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### NetApp StorageGRID data collector

The NetApp StorageGRID data collector supports inventory and performance collection from StorageGRID configurations.



StorageGRID is metered at a different Raw TB to Managed Unit rate. Every 40 TB of unformatted StorageGRID capacity is charged as 1 Managed Unit (MU).

#### Requirements

The following are requirements for configuring this data source:

- StorageGRID Host IP Address
- · A username and password for a user that has had the Metric Query and Tenant Access roles assigned
- Port 443

### Configuration

Field	Description
StorageGRID Host IP Address	Management Virtual IP address of the StorageGRID appliance
User Name	Name used to log into the StorageGRID appliance
Password	Password used to log into the StorageGRID appliance

## **Advanced configuration**

Field	Description
Inventory Poll Interval (min)	Default is 60 minutes
performance Poll Interval (sec)	Default is 900 seconds

### Single Sign-On (SSO)

The StorageGRID firmware versions have corresponding API versions; 3.0 API and newer versions support single sign-on (SSO) login.

Firmware version	API version	Support single sign on (SSO)
11.1	2	No
11.2	3.0	Yes
11.5	3.3	Yes

#### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

### Nutanix NX data collector

Cloud Insights uses the Nutanix data collector to discover inventory and performance data for Nutanix NX storage systems.

### **Terminology**

Cloud Insights acquires the following inventory information from the Nutanix data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Storage Pool	Storage Pool
Nutanix Container	Internal Volume
Nutanix Container	File Share
NFS Share	Share

Note: These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

- The external data services IP address for the cluster
- Read-only user name and password, unless volume\_groups are in use, in which case, Admin user name and password are required
- Port requirement: HTTPS 443

## Configuration

Field	Description
Prism External IP Address	The external data services IP address for the cluster
User name	User name for the Admin account
Password	Password for the Admin account

## **Advanced configuration**

Field	Description
TCP port	TCP Port used to connect to Nutanix array. The default is 9440.
Inventory poll interval (min)	Interval between inventory polls. The default is 60 minutes.
Performance poll interval(sec)	Interval between performance polls. The default is 300 seconds.

## **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## OpenStack data collector

The OpenStack (REST API / KVM) data collector acquires inventory data for all OpenStack instances, and optionally, VM performance data.

### Requirements

- IP address of the OpenStack controller
- OpenStack admin role credential and sudo access to the Linux KVM hypervisor. If you are not using the
  admin account or admin equivalent privileges, you will need to use trial and error to identify the default
  policies to relax for your data collector userid.
- The OpenStack Ceilometer module must be installed and configured for performance collection.

  Configuring the Ceilometer is done by editing the nova.conf file for each hypervisor and then restarting the Nova Compute service on each hypervisor. The option name changes for different releases of OpenStack:
  - Icehouse
  - Juno
  - Kilo
  - Liberty
  - Mitaka
  - Newton
  - Ocata
- For CPU stats, "compute\_monitors=ComputeDriverCPUMonitor" needs to be turned on in /etc/nova/nova.conf on compute nodes.
- Port requirements:
  - 5000 for http and 13000 for https, for the Keystone service
  - 22 for KVM SSH
  - 8774 for Nova Compute Service
  - 8776 for Cinder Block Service
  - 8777 for Ceilometer Performance Service
  - 9292 for Glance Image Service
     Note The port binds to the specific service, and the service may run on the controller or another host in larger environments.

## Configuration

Field	Description
OpenStack Controller IP Address	IP address or fully-qualified domain name of the OpenStack Controller
OpenStack Administrator	User name for an OpenStack Admin
OpenStack Password	Password used for the OpenStack Admin
OpenStack Administrator Tenant	OpenStack Administrator Tenant name
KVM Sudo User	KVM Sudo User name
Choose 'Password' or 'OpenSSH Key File' to specify credential type	Credential type used to connect to the device via SSH
Full Path to Inventory Private Key	Full Path to Inventory Private Key
KVM Sudo Password	KVM Sudo Password

### Advanced configuration

Field	Description
Enable hypervisor inventory discovery through SSH	Check this to enable hypervisor inventory discovery through SSH
OpenStack Admin URL port	OpenStack Admin URL port
Use HTTPS	Check to use secure HTTP
SSH Port	Port used for SSH
SSH Process Retries	Number of inventory retry attempts
Inventory Poll Interval (min)	Interval between inventory polls. The default is 20 minutes.

### **Troubleshooting**

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
"Configuration error" with error messages start with "Policy doesn't allow" or "You are not authorized"	* Check ip address * Check User name and password

Additional information may be found from the Support page or in the Data Collector Support Matrix.

# **Oracle ZFS Storage Appliance data collector**

Cloud Insights uses the Oracle ZFS Storage Appliance data collector to gather inventory and performance data.

## **Terminology**

Cloud Insights acquires inventory information with the Oracle ZFS data collector. For each asset type acquired by Cloud Insights, the most common terminology used for this asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk (SSD)	Disk
Cluster	Storage
Controller	Storage Node
LUN	Volume
LUN Map	Volume Map
Initiator, Target	Volume Mask
Share	Internal Volume

Note: These are common terminology mappings only and might not represent every case for this data source.

## Requirements

- Host names for the ZFS Controller-1 and the ZFS Controller-2
- · Administrator user name and password
- Port requirement: 215 HTTP/HTTPS

## Configuration

Field	Description
ZFS Controller-1 Hostname	Host name for storage controller 1
ZFS Controller-2 Hostname	Host name for storage controller 2
User name	User name for the storage system administrator user account
Password	Password for the administrator user account

## **Advanced configuration**

Field	Description
Connection Type	HTTPS or HTTP, also displays the default port
Override Connection Port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Inventory poll interval	The default is 60 seconds
Performance Poll Interval (sec)	The default is 300.

## **Troubleshooting**

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
"Invalid login credentials"	validate Zfs user account and password
"Configuration error" with error message "REST Service is disabled"	Verify REST service is enabled on this device.

Problem:	Try this:
"Configuration error " with error message "User unauthorized for command"	Likely due to certain roles (for example, 'advanced_analytics') are not included for the configured user <username>. Possible Solution: * Correct the Analytics (statistic) scope for the user \${user} with the read only role: - From the Configuration → Users screen, put your mouse over the role and double click to allow editing - Select "Analytics" from the Scope drop down menu. A list of the possible properties appears Click the top most check box and it will select all three properties Click the Add button on the right side Click the Apply button at the top right of the pop-up window. The pop-up window will close.</username>

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## Pure Storage FlashArray data collector

Cloud Insights uses the Pure Storage FlashArray data collector to gather inventory and performance data.

## Terminology

For each asset type acquired by Cloud Insights, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Drive (SSD)	Disk
Array	Storage
Controller	Storage Node
Volume	Volume
LUN Map	Volume Map
Initiator, Target	Volume Mask

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

- · Storage system IP address
- User name and password for the Administrator account of the Pure storage system.
- Port requirement: HTTP/HTTPS 80/443

## Configuration

Field	Description
FlashArray Host IP Address	IP address of the storage system
User name	User name with admin privileges
Password for the admin privileged account	Password

## **Advanced configuration**

Field	Description
Connection type	Choose HTTP or HTTPS. Also displays the default port.
Override TCP port	If blank, use the default port in the Connection Type field, otherwise enter the connection port to use
Inventory poll interval (min)	The default is 60 minutes
Performance Poll Interval (sec)	The default is 300

## **Troubleshooting**

Some things to try if you encounter problems with this data collector:

## Inventory

Problem:	Try this:
"Invalid login credentials" with error messages "Policy doesn't allow" or "You are not authorized"	Validate Pure user account and password via Pure http interface

Additional information may be found from the Support page or in the Data Collector Support Matrix.

## **Red Hat Virtualization data collector**

Cloud Insights uses the Red Hat Virtualization data collector to gather inventory data from virtualized Linux and Microsoft Windows workloads.

## **Terminology**

For each asset type acquired by Cloud Insights, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term
Disk	Virtual Disk
Host	Host
Virtual Machine	Virtual Machine
Storage Domain	Data Store

Vendor/Model Term	Cloud Insights Term
Logical Unit	LUN

Note: These are common terminology mappings only and might not represent every case for this data collector.

### Requirements

- IP address of the RHEV server over port 443 via REST API
- · Read-only username and password
- RHEV Version 3.0+

## Configuration

Field	Description
RHEV Server IP Address	IP address of the storage system
User name	User name with admin privileges
Password for the admin privileged account	Password

## **Advanced configuration**

Field	Description
HTTPS Communication Port	Port used for HTTPS communication to RHEV
Inventory poll interval (min)	The default is 20 minutes.

### **Troubleshooting**

Additional information on this Data Collector may be found from the Support page or in the Data Collector Support Matrix.

## Configuring the VMware VSphere data collector

The data collector for VMware vSphere collects ESX Host information and requires readonly privileges on all objects within the Virtual Center.

## **Terminology**

Cloud Insights acquires the following inventory information from the VMware vSphere data collector. For each asset type acquired, the most common terminology used for the asset is shown. When viewing or troubleshooting this data collector, keep the following terminology in mind:

Vendor/Model Term	Cloud Insights Term	
Virtual disk	Disk	
Host	Host	
Virtual machine	Virtual machine	

Vendor/Model Term	Cloud Insights Term
Data store	Data store
LUN	Volume
Fibre channel port	Port

These are common terminology mappings only and might not represent every case for this data collector.

## Requirements

The following information is required to configure this data collector:

- IP address of the Virtual Center server
- Read-only username and password in Virtual Center
- We require read only privileges on all objects within Virtual Center.
- SDK access on the Virtual Center server normally already setup.
- Port requirements: http-80 https-443
- · Validate access:
  - · Log into Virtual Center Client using above username and password
  - Verify SDK enabled: telnet <vc\_ip> 443

## **Setup and connection**

Field	Description	
Name	Unique name for the data collector	
Acquisition unit	Name of acquisition unit	

## Configuration

Field	Description
Virtual center IP Address	IP address of the Virtual Center
User name	User name used to access the Virtual Center
Password	Password used to access the Virtual Center

### **Advanced configuration**

In the advanced configuration screen, check the **VM Performance** box to collect performance data. Inventory collection is enabled by default.

The following fields can be configured:

Field	Description
Inventory poll interval (min)	Default is 20
Filter VMs	Select CLUSTER, DATACENTER, or ESX HOST

Choose 'Exclude' or 'Include' to Specify a List	Create a filter list (CLUSTER, DATACENTER, and/o ESX_HOST)	
Number of retries	Default is 3	
Communication port	Default is 443	
Filter Device List	This list must consist of exact string matches - if you intend to filter by ESX_HOST, you must build a comma delimited list of the exact "names" of your ESX hosts as reported in both Cloud Insights and vSphere. These "names" may be either IP addresses, simple hostnames, or fully qualified domain names (FQDNs) - this is determined by how these hosts were named when they were originally added to vSphere.  When filtering by CLUSTER, use the Cloud Insights-style cluster names as reported by CI on hypervisors - Cloud Insights prepends the vSphere cluster name with the vSphere datacenter name and a backslash - "DC1\clusterA" is the cluster name Cloud Insights would report on a hypervisor in clusterA within data center DC1	
Performance poll interval (sec)	Default is 300	

# Troubleshooting

Some things to try if you encounter problems with this data collector:

# Inventory

Problem:	Try this:
Error: Include list to filter VMs cannot be empty	If Include List is selected, please list valid DataCenter, Cluster, or Host names to filter VMs
Error: Failed to instantiate a connection to VirtualCenter at IP	* Verify credentials and IP address entered.  * Try to communicate with Virtual Center using VMware Infrastructure Client.  * Try to communicate with Virtual Center using Managed Object Browser (e.g MOB).
Error: VirtualCenter at IP has non-conform certificate that JVM requires	* Recommended: Re-generate certificate for Virtual Center by using stronger (e.g. 1024-bit) RSA key.  * Not Recommended: Modify the JVM java.security configuration to leverage the constraint jdk.certpath.disabledAlgorithms to allow 512-bit RSA key. See JDK 7 update 40 release notes at "http://www.oracle.com/technetwork/java/javase/7u40-relnotes-2004172.html"

# **Data Collector Reference - Services**

## **Node Data Collection**

Cloud Insights gathers metrics from the node on which you install an agent.

### Installation

- 1. From **Admin > Data Collectors**, choose an operating system/platform. Note that installing any integration data collector (Kubernetes, Docker, Apache, etc.) will also configure node data collection.
- 2. Follow the instructions to configure the agent. The instructions vary depending on the type of Operating System or Platform you are using to collect data.

## **Objects and Counters**

The following objects and their counters are collected as Node metrics:

Object:	Identifiers:	Attributes:	Datapoints:
Node Filesystem	Node UUID Device Path Type	Node IP Node Name Node OS Mode	Free Inodes Free Inodes Total Inodes Used Total Used Total Used
Node Disk	Node UUID Disk	Node IP Node Name Node OS	IO Time Total IOPS In Progress Read Bytes (per sec) Read Time Total Reads (per sec) Weighted IO Time Total Write Bytes (per sec) Write Time Total Writes (per sec) Current Disk Queue Length Write Time Read Time IO Time
Node CPU	Node UUID CPU	Node IP Node Name Node OS	System CPU Usage User CPU Usage Idle CPU Usage Processor CPU Usage Interrupt CPU Usage DPC CPU Usage

Object:	Identifiers:	Attributes:	Datapoints:
Node	Node UUID	Node IP Node Name Node OS	Kernel Boot Time Kernel Context Switches (per sec) Kernel Entropy Available Kernel Interrupts (per sec) Kernel Processes Forked (per sec) Memory Active Memory Available Total Memory Available Memory Buffered Memory Cached Memory Commit Limit Memory Committed As Memory Dirty Memory Free Memory High Free Memory High Total Memory Huge Page Size Memory Huge Pages Total Memory Low Free Memory Low Total Memory Shared Memory Shared Memory Swap Cached Memory Swap Free Memory Used Total Memory Used Total Memory Used Memory Vmalloc Chunk Memory Writeback Total Memory Writeback Total Memory Writeback Total Memory Writeback Total Memory Demand Zero Faults Memory Pages Memory Paged Memory Cache Core Memory Standby Cache Normal Memory Standby Cache Reserve Memory Transition Faults Processes Blocked Processes Dead

Object:	Identifiers:	Attributes:	<b>Datapoints:</b>
Node Network	Network Interface Node UUID	Node Name Node IP Node OS	Bytes Received Bytes Sent Packets Outboud Discarded Packets Outboud Errors Packets Received Discarded Packets Received Errors Packets Received Packets Received Packets Sent

Setup and Troubleshooting information can be found on the Configuring an Agent page.

# **MacOS Memory Usage**

Cloud Insights (via Telegraf) and macOS report different numbers for memory usage. Both Telegraf and the Mac activity monitor use metrics gathered from *vm\_stat*, however the total memory usage is calculated differently for each.

Telegraf calculates Memory Used Total as follows:

```
Memory Used Total = Memory Total - Memory Available Total
```

Where Memory Available Total is derived from the sum of "Pages free" and "Pages inactive" in vm\_stat.

The Mac activity monitor, on the other hand, calculates Memory Used as follows:

```
Memory Used = App Memory + Wired Memory + Compressed
```

## Where:

- App Memory is derived from the difference between "Anonymous pages" and "Pages purgeable" in vm\_stat,
- Wired Memory is derived from "Pages wired down" in vm stat, and
- Compressed is derived from "Pages occupied by compressor" in vm stat.

# ActiveMQ Data Collector

Cloud Insights uses this data collector to gather metrics from ActiveMQ.

#### Installation

From Admin > Data Collectors, click +Data Collector. Under Services, choose ActiveMQ.

Select the Operating System or Platform on which the Telegraf agent is installed.

- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the ActiveMQ documentation

## **Objects and Counters**

The following objects and their counters are collected:

Object:	Identifiers:	Attributes:	Datapoints:
ActiveMQ Queue	Namespace Queue Port Server	Node Name Node IP Node UUID	Consumer Count Dequeue Count Enqueue Count Queue Size
ActiveMQ Subscriber	Client ID Connection ID Port Server Namespace	Is Active Destination Node Name Node IP Node UUID Node OS Selector Subscription	Dequeue Count Dispatched Count Dispatched Queue Size Enqueue Count Pending Queue Size
ActiveMQ Topic	Topic Port Server Namespace	Node Name Node IP Node UUID Node OS	Consumer Count Dequeue Count Enqueue Count Size

# **Troubleshooting**

Additional information may be found from the Support page.

# **Apache Data Collector**

This data collector allows collection of data from Apache servers in your environment.

#### **Pre-requisites**

- You must have your Apache HTTP Server set up and properly running
- You must have sudo or administrator permissions on your agent host/VM
- Typically, the Apache *mod\_status* module is configured to expose a page at the '/server-status?auto' location of the Apache server. The *ExtendedStatus* option must be enabled in order to collect all available fields. For information about how to configure your server, see the Apache module documentation: <a href="https://httpd.apache.org/docs/2.4/mod/mod\_status.html#enable">https://httpd.apache.org/docs/2.4/mod/mod\_status.html#enable</a>

#### Installation

1. From **Admin > Data Collectors**, click **+Data Collector**. Under **Services**, choose Apache.

Select the Operating System or Platform on which the Telegraf agent is installed.

- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.

4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



#### Setup

Telegraf's plugin for Apache's HTTP Server relies on the 'mod\_status' module to be enabled. When this is enabled, Apache's HTTP Server will expose an HTML endpoint that can be viewed on your browser or scraped for extraction of status of all Apache's HTTP Server configuration.

## Compatibility:

Configuration was developed against Apache's HTTP Server version 2.4.38.

#### **Enabling mod\_status:**

Enabling and exposing the 'mod\_status' modules involves two steps:

- · Enabling module
- · Exposing stats from module

# **Enabling module:**

The loading of modules is controlled by the config file under '/usr/local/apache/conf/httpd.conf'. Edit the config file and uncomment the following lines:

```
LoadModule status_module modules/mod_status.so
```

```
Include conf/extra/httpd-info.conf
```

#### **Exposing stats from module:**

The exposing of 'mod\_status' is controlled by the config file under '/usr/local/apache2/conf/extra/httpd-info.conf'. Make sure you have the following in that configuration file (at least, other directives will be there):

```
# Allow server status reports generated by mod_status,
# with the URL of http://servername/server-status
<Location /server-status>
        SetHandler server-status
</Location>

#
# ExtendedStatus controls whether Apache will generate "full" status
# information (ExtendedStatus On) or just basic information
(ExtendedStatus
# Off) when the "server-status" handler is called. The default is Off.
#
ExtendedStatus On
```

For detailed instructions on the 'mod status' module, see the Apache documentation

#### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Apache	Namespace Server	Node IP Node Name Port Parent Server Config Generation Parent Server MPM Generation Server Uptime Is Stopping	Busy Workers Bytes per Request Bytes per Second CPU Children System CPU Children User CPU Load CPU System CPU User Asynchronous Connections Closing Asynchronous Connections Keep Alive Asynchronous Connections Writing Connections Total Duration per Request Idle Workers Load Average (last 1m) Load Average (last 5m) Processes Requests per Second Total Accesses Total Duration Total KBytes Scoreboard Closing Scoreboard Closing Scoreboard Finishing Scoreboard Idle Cleanup Scoreboard Logging Scoreboard Reading Scoreboard Sending Scoreboard Starting Scoreboard Waiting

Additional information may be found from the Support page.

# **Consul Data Collector**

Cloud Insights uses this data collector to gather metrics from Consul.

#### Installation

1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Consul.

If you haven't configured an Agent for collection, you are prompted to install an agent in your environment.

If you have an agent already configured, select the appropriate Operating System or Platform and click

#### Continue.

2. Follow the instructions in the Consul Configuration screen to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.

# Setup

Information may be found in the Consul documentation.

#### **Objects and Counters for consul**

The following objects and their counters are collected:

Object:	Identifiers:	Attributes:	Datapoints:
Consul	Namespace Check ID Service Node	Node IP Node OS Node UUID Node Name Service Name Check Name Service ID Status	Critical Passing Warning

#### **Troubleshooting**

Additional information may be found from the Support page.

#### **Couchbase Data Collector**

Cloud Insights uses this data collector to gather metrics from Couchbase.

#### Installation

1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Couchbase.

Select the Operating System or Platform on which the Telegraf agent is installed.

- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Couchbase documentation.

#### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Couchbase Node	Namespace Cluster Couchbase Node Hostname	Node Name Node IP	Memory Free Memory Total
Couchbase Bucket	Namespace Bucket Cluster	Node Name Node IP	Data Used Data Fetches Disk Used Item Count Memory Used Operations Per Second Quota Used

Additional information may be found from the Support page.

# **CouchDB Data Collector**

Cloud Insights uses this data collector to gather metrics from CouchDB.

### Installation

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose CouchDB.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the CouchDB documentation.

#### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
CouchDB	Namespace Server	Node Name Node IP	Authentication Cache Miss Database Reads Database Writes Databases Open Open OS Files Max Request Time Min Request Time Httpd Request Methods Copy Httpd Request Methods Delete Httpd Request Methods Get Httpd Request Methods Head Httpd Request Methods Post Httpd Request Methods Post Httpd Request Methods Post Httpd Request Methods Post Httpd Request Methods Put Status Codes 200 Status Codes 201 Status Codes 201 Status Codes 301 Status Codes 301 Status Codes 400 Status Codes 400 Status Codes 400 Status Codes 401 Status Codes 403 Status Codes 404 Status Codes 405 Status Codes 409 Status Codes 500

Additional information may be found from the Support page.

# **Docker Data Collector**

Cloud Insights uses this data collector to gather metrics from Docker.

## Installation

1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Docker.

If you haven't configured an Agent for collection, you are prompted to install an agent in your environment.

If you have an agent already configured, select the appropriate Operating System or Platform and click **Continue**.

2. Follow the instructions in the Docker Configuration screen to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



#### Setup

The Telegraf input plugin for Docker collects metrics through a specified UNIX socket or a TCP endpoint.

#### Compatibility

Configuration was developed against Docker version 1.12.6.

#### **Setting Up**

# Accessing Docker through a UNIX socket

If the Telegraf agent is running on baremetal, add the telegraf Unix user to the docker Unix group by running the following:

```
sudo usermod -aG docker telegraf
```

If the Telegraf agent is running within a Kubernetes pod, expose the Docker Unix socket by mapping the socket into the pod as a volume and then mounting that volume to /var/run/docker.sock. For example, add the following to the PodSpec:

```
volumes:
...
- name: docker-sock
hostPath:
path: /var/run/docker.sock
type: File
```

Then, add the following to the Container:

```
volumeMounts:
...
- name: docker-sock
mountPath: /var/run/docker.sock
```

Note that the Cloud Insights installer provided for the Kubernetes platform takes care of this mapping automatically.

#### Access Docker through a TCP endpoint

By default, Docker uses port 2375 for unencrypted access and port 2376 for encrypted access.

# **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Docker Engine	Namespace Docker Engine	Node Name Node IP Node UUID Node OS Kubernetes Cluster Docker Version Unit	Memory Containers Containers Paused Containers Running Containers Stopped CPUs Go Routines Images Listener Events Used File Descriptors Data Available Data Total Data Used Metadata Available Metadata Total Metadata Used Pool Blocksize

Object:	Identifiers:	Attributes:	Datapoints:
Docker Container	Namespace Container Name Docker Engine	Kubernetes Container Hash Kubernetes Container Ports Kubernetes Container Restart Count Kubernetes Container Termination Message Path Kubernetes Container Termination Message Policy Kubernetes Pod Termination Grace Period Container Image Container Status Container Version Node Name Kubernetes Container Log Path Kubernetes Container Name Kubernetes Docker Type Kubernetes Pod Name Kubernetes Pod Name Kubernetes Pod UID Kubernetes Pod UID Kubernetes Pod UID Node IP Node UUID Docker Version Kubernetes IO Config Seen Kubernetes IO Config Seen Kubernetes Description Kubernetes Display Name OpenShift IO SCC Kubernetes Description Kubernetes Display Name OpenShift Tags Kompose Service Pod Template Hash Controller Revision Hash Pod Template Generation License Schema Build Date Schema License Schema VCS URL Schema VCS URL Schema Version Schema Version Schema Schema Version Maintainer Customer Pod	Memory Active Anonymous Memory Active File Memory Cache Memory Hierarchical Limit Memory Inactive Anonymous Memory Inactive File Memory Limit Memory Mapped File Memory Max Usage Memory Page Fault Memory Page Major Fault Memory Paged In Memory Paged Out Memory Resident Set Size Memory Resident Set Size Huge Memory Total Active File Memory Total Inactive Anonymous Memory Total Inactive File Memory Total Inactive File Memory Total Page Fault Memory Total Page Fault Memory Total Page Major Fault Memory Total Paged In Memory Total Paged Out Memory Total Resident Set Size Memory Total Resident Set Size Huge Memory Total Unevictable Memory Usage Memory Usage Memory Usage Memory Usage Memory Usage Memory Usage Percent Exit Code OOM Killed PID Started At Failing Streak

Object:	Identifiers:	Attributes:	Datapoints:
Docker Container Block IO	Namespace Container Name Device Docker Engine	Kubernetes Container Hash Kubernetes Container Ports Kubernetes Container Restart Count Kubernetes Container Termination Message Path Kubernetes Container Termination Message Policy Kubernetes Pod Termination Grace Period Container Image Container Status Container Version Node Name Kubernetes Container Log Path Kubernetes Container Name Kubernetes Docker Type Kubernetes Pod Name Kubernetes Pod Name Kubernetes Pod UID Kubernetes Pod UID Kubernetes Sandbox ID Node IP Node UUID Docker Version Kubernetes Config Seen Kubernetes Config Source OpenShift SCC Kubernetes Description Kubernetes Display Name OpenShift Tags Schema Schema Version Pod Template Hash Controller Revision Hash Pod Template Generation Kompose Service Schema Build Date Schema License Schema Vendor Customer Pod Kubernetes StatefulSet Pod Name Tenant Webconsole Build Date License Vendor	IO Service Bytes Recursive Async IO Service Bytes Recursive Read IO Service Bytes Recursive Sync IO Service Bytes Recursive Total IO Service Bytes Recursive Write IO Serviced Recursive Async IO Serviced Recursive Read IO Serviced Recursive Sync IO Serviced Recursive Write Total IO Serviced Recursive Write

Object:	Identifiers:	Attributes:	Datapoints:
Docker Container Network	Namespace Container Name Network Docker Engine	Container Image Container Status Container Version Node Name Node IP Node UUID Node OS K8s Cluster Docker Version Container ID	RX Dropped RX Bytes RX Errors RX Packets TX Dropped TX Bytes TX Errors TX Packets

Object:	Identifiers:	Attributes:	Datapoints:
Docker Container CPU	Namespace Container Name CPU Docker Engine	Kubernetes Container Hash Kubernetes Container Ports Kubernetes Container Restart Count Kubernetes Container Termination Message Path Kubernetes Container Termination Message Policy Kubernetes Pod Termination Grace Period Kubernetes Config Seen Kubernetes Config Seen Kubernetes Config Source OpenShift SCC Container Image Container Status Container Version Node Name Kubernetes Container Log Path Kubernetes Container name Kubernetes Pod Name Kubernetes Pod Name Kubernetes Pod Name Kubernetes Pod UID Kubernetes Pod UID Kubernetes Sandbox ID Node IP Node UUID Node OS Kubernetes Cluster Docker Version Kubernetes Description Kubernetes Display Name OpenShift Tags Schema Version Pod Template Hash Controller Revision Hash Pod Template Generation Kompose Service Schema License Schema Name Schema Vendor Customer Pod Kubernetes StatefulSet Pod Name Tenant Webconsole Build Date	Throttling Periods Throttling Throttled Time Usage In Kernel Mode Usage Percent Usage System Usage Total

Problem:	Try this:
I do not see my Docker metrics in Cloud Insights after following the instructions on the configuration page.	Check the Telegraf agent logs to see if it reports the following error:
	E! Error in plugin [inputs.docker]: Got permission denied while trying to connect to the Docker daemon socket
	If it does, take the necessary steps to provide the Telegraf agent access to the Docker Unix socket as specified above.

Additional information may be found from the Support page.

# **Elasticsearch Data Collector**

Cloud Insights uses this data collector to gather metrics from Elasticsearch.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Elasticsearch.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Elasticsearch documentation.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Elasticsearch Cluster	Namespace Cluster	Node IP Node Name Cluster Status	Master Node Count Total Node Count Filesystem Data Available (bytes) Filesystem Data Free (bytes) Filesystem Data Total (bytes) JVM Threads OS Allocated Proccessors OS Available Processors OS Mem Free (bytes) OS Mem Free OS Mem Total (bytes) OS Mem Used (bytes) OS Mem Used Process CPU Indices Completion Size (bytes) Indices Count Indices Docs Count Indices Docs Deleted Indices Field Data Evictions Indices Field Data Memory Size (bytes) Indices Query Cache Count Indices Cache Size Indices Segments Count Indices Segments Doc Values Memory (bytes) Indices Shards Index Primaries Avg Indices Shards Index Primaries Max Indices Shards Index Primaries Min Indices Shards Index Replication Avg Indices Shards Index Replication My Indices Shards Index Replication Min Indices Shards Primaries Indices Shards Primaries Indices Shards Primaries Indices Shards Total Indices Store Size (bytes)

Object:	Identifiers:	Attributes:	Datapoints:
Elasticsearch Node	Namespace Cluster ES Node ID ES Node	Zone ID	Enabled Machine Learning Memory Machine Learning Max Open Jobs X-Pack Installed Breakers Accounting Estimated Size (bytes) Breakers Accounting Limit Size (bytes) Breakers Accounting Overhead Breakers Accounting Tripped Breakers Field Data Estimated Size (bytes) Breakers Field Data Limit Size (bytes) Breakers Field Data Overhead Breakers Field Data Tripped Breakers Field Data Overhead Breakers In-Flight Sstimated Size (bytes) Breakers In-Flight Limit Size (bytes) Breakers In-Flight Tripped Breakers Parent Estimated Size (bytes) Breakers Parent Estimated Size (bytes) Breakers Parent Limit Size (bytes) Breakers Parent Tripped Breakers Request Estimated Size (bytes)

Additional information may be found from the Support page.

## Flink Data Collector

Cloud Insights uses this data collector to gather metrics from Flink.

#### Installation

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Flink.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



A full Flink deployment involves the following components:

JobManager: The Flink primary system. Coordinates a series of TaskManagers. In a High Availability setup, system will have more than one JobManager.

TaskManager: This is where Flink operators are executed.

The Flink plugin is based on the telegraf's Jolokia plugin. As such as a requirement to gather info from all Flink components, JMX needs to be configured and exposed via Jolokia on all components.

## Compatibility

Configuration was developed against Flink version 1.7.0.

## **Setting Up**

#### Jolokia Agent Jar

For all individual components, a version the Jolokia agent jar file must be downloaded. The version tested against was Jolokia agent 1.6.0.

Instructions below assume that downloaded jar file (jolokia-jvm-1.6.0-agent.jar) is placed under location '/opt/flink/lib/'.

# **JobManager**

To configure JobManager to expose the Jolokia API, you can setup the following environment variable on your nodes then restart the JobManager:

```
export FLINK_ENV_JAVA_OPTS="-javaagent:/opt/flink/lib/jolokia-jvm-1.6.0-
agent.jar=port=8778,host=0.0.0.0"
```

You can choose a different port for Jolokia (8778). If you have an internal IP to lock Jolokia onto you can replace the "catch all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from the telegraf plugin.

#### TaskManager

To configure TaskManager(s) to expose the Jolokia API, you can setup the following environment variable on your nodes then restart the TaskManager:

```
export FLINK_ENV_JAVA_OPTS="-javaagent:/opt/flink/lib/jolokia-jvm-1.6.0-
agent.jar=port=8778,host=0.0.0.0"
```

You can choose a different port for Jolokia (8778). If you have an internal IP to lock Jolokia onto you can replace the "catch all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from the telegraf plugin.

#### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Flink Task Manager	Cluster Namespace Server	Node Name Task Manager ID Node IP	Network Available Memory Segments Network Total Memory Segments Garbage Collection PS MarkSweep Count Garbage Collection PS MarkSweep Time Garbage Collection PS Scavenge Count Garbage Collection PS Scavenge Time Heap Memory Committed Heap Memory Init Heap Memory Max Heap Memory Used Thread Count Daemon Thread Count Peak Thread Count Thread Count Thread Count Started
Flink Job	Cluster Namespace server Job ID	Node Name Job Name Node IP Last Checkpoint External Path Restarting Time	Downtime Full Restarts Last Checkpoint Alignment Buffered Last Checkpoint Duration Last Checkpoint Size Number of Completed Checkpoints Number of Failed Checkpoints Number of in Progress Checkpoints Number of Checkpoints Uptime

Object:	Identifiers:	Attributes:	Datapoints:
Flink Job Manager	Cluster Namespace Server	Node Name Node IP	Garbage Collection PS MarkSweep Count Garbage Collection PS MarkSweep Time Garbage Collection PS Scavenge Count Garbage Collection PS Scavenge Time Heap Memory Committed Heap Memory Init Heap Memory Used Number Registered Task Managers Number Running Jobs Task Slots Available Task Slots Total Thread Count Daemon Thread Count Thread Count Thread Count Total Started

Object:	Identifiers:	Attributes:	Datapoints:
Flink Task	Cluster Namespace Job ID Task ID	Server Node Name Job Name Sub Task Index Task Attempt ID Task Attempt Number Task Name Task Manager ID Node IP Current Input Watermark	Buffers In Pool Usage Buffers Out Pool Usage Buffers Out Pool Usage Buffers Out Queue Length Number Buffers In Local Number Bufffers In Local Per Second Count Number Buffers in Local Per Second Rate Number Buffers In Remote Number Buffers In Remote Per Second Count Number Buffers In Remote Per Second Rate Number Buffers Out Number Buffers Out Per Second Count Number Buffers Out Per Second Rate Number Bytes In Local Number Bytes In Local Per Second Count Number Bytes In Local Per Second Rate Number Bytes In Remote Number Bytes In Remote Per Second Rate Number Bytes In Remote Per Second Rate Number Bytes Out Number Bytes Out Number Bytes Out Per Second Count Number Records In Number Records In Number Records In Per Second Count Number Records Out Number Records Out Number Records Out Number Records Out Per Second Count Number Records Out Per

Object:	Identifiers:	Attributes:	Datapoints:
Flink Task Operator	Cluster Namespace Job ID Operator ID Task ID	Server Node Name Job Name Operator Name Sub Task Index Task Attempt ID Task Attempt Number Task Name Task Manager ID Node IP	Current Input Watermark Current Output Watermark Number Records In Number Records In Per Second Count Number Records In Per Second Rate Number Records Out Per Second Count Number Records Out Per Second Count Number Records Out Per Second Rate Number Late Records Dropped Assigned Partitions Bytes Consumed Rate Commit Latency Avg Commit Latency Max Commit Failed Commits Succeeded Connection Close Rate Connection Count Connection Creation Rate Count Fetch Latency Avg Fetch Latency Max Fetch Rate Fetch Size Avg Fetch Throttle Time A

Additional information may be found from the Support page.

# **Hadoop Data Collector**

Cloud Insights uses this data collector to gather metrics from Hadoop.

#### Installation

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Hadoop.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.





A full Hadoop deployment involves the following components:

 NameNode: The Hadoop Distributed File System (HDFS) primary system. Coordinates a series of DataNodes.

- Secondary NameNode: a warm failover for the main NameNode. In Hadoop the promotion to NameNode does not occur automatically. Secondary NameNode gathers information from NameNode to be ready to be promoted when needed.
- DataNode: Actual owner for data.
- ResourceManager: The compute primary system (Yarn). Coordinates a series of NodeManagers.
- NodeManager: The resource for compute. Actual location for running of applications.
- JobHistoryServer: Responsible for servicing all job history related requests.

The Hadoop plugin is based on the telegraf's Jolokia plugin. As such as a requirement to gather info from all Hadoop components, JMX needs to be configured and exposed via Jolokia on all components.

## Compatibility

Configuration was developed against Hadoop version 2.9.2.

## **Setting Up**

#### Jolokia Agent Jar

For all individual components, a version the Jolokia agent jar file must be downloaded. The version tested against was Jolokia agent 1.6.0.

Instructions below assume that downloaded jar file (jolokia-jvm-1.6.0-agent.jar) is placed under location '/opt/hadoop/lib/'.

#### **NameNode**

To configure NameNode to expose the Jolokia API, you can setup the following in <HADOOP\_HOME>/etc/hadoop/hadoop-env.sh:

```
export HADOOP_NAMENODE_OPTS="$HADOOP_NAMENODE_OPTS
-javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
-agent.jar=port=7800,host=0.0.0.0 -Dcom.sun.management.jmxremote
-Dcom.sun.management.jmxremote.port=8000
-Dcom.sun.management.jmxremote.ssl=false
-Dcom.sun.management.jmxremote.password.file=$HADOOP_HOME/conf/jmxremote.p
assword"
You can choose a different port for JMX (8000 above) and Jolokia (7800).
If you have an internal IP to lock Jolokia onto you can replace the "catch
all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from
the telegraf plugin. You can use the option '-
Dcom.sun.management.jmxremote.authenticate=false' if you don't want to
authenticate. Use at your own risk.
```

## **Secondary NameNode**

To configure the Secondary NameNode to expose the Jolokia API, you can setup the following in <a href="https://example.com/hadoop/hadoop-env.sh">HADOOP HOME>/etc/hadoop/hadoop-env.sh</a>:

```
export HADOOP_SECONDARYNAMENODE_OPTS="$HADOOP_SECONDARYNAMENODE_OPTS
-javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
-agent.jar=port=7802,host=0.0.0.0 -Dcom.sun.management.jmxremote
-Dcom.sun.management.jmxremote.port=8002
-Dcom.sun.management.jmxremote.ssl=false
-Dcom.sun.management.jmxremote.password.file=$HADOOP_HOME/conf/jmxremote.p
assword"
You can choose a different port for JMX (8002 above) and Jolokia (7802).
If you have an internal IP to lock Jolokia onto you can replace the "catch
all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from
the telegraf plugin. You can use the option '-
Dcom.sun.management.jmxremote.authenticate=false' if you don't want to
authenticate. Use at your own risk.
```

#### **DataNode**

To configure the DataNodes to expose the Jolokia API, you can setup the following in <HADOOP HOME>/etc/hadoop/hadoop-env.sh:

```
export HADOOP_DATANODE_OPTS="$HADOOP_DATANODE_OPTS
-javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
-agent.jar=port=7801,host=0.0.0.0 -Dcom.sun.management.jmxremote
-Dcom.sun.management.jmxremote.port=8001
-Dcom.sun.management.jmxremote.ssl=false
-Dcom.sun.management.jmxremote.password.file=$HADOOP_HOME/conf/jmxremote.password"

You can choose a different port for JMX (8001 above) and Jolokia (7801).
If you have an internal IP to lock Jolokia onto you can replace the "catch all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from the telegraf plugin. You can use the option '-
Dcom.sun.management.jmxremote.authenticate=false' if you don't want to authenticate. Use at your own risk.
```

#### ResourceManager

To configure the ResourceManager to expose the Jolokia API, you can setup the following in <HADOOP HOME>/etc/hadoop/hadoop-env.sh:

```
export YARN_RESOURCEMANAGER_OPTS="$YARN_RESOURCEMANAGER_OPTS
-javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
-agent.jar=port=7803,host=0.0.0.0 -Dcom.sun.management.jmxremote
-Dcom.sun.management.jmxremote.port=8003
-Dcom.sun.management.jmxremote.ssl=false
-Dcom.sun.management.jmxremote.password.file=$HADOOP_HOME/conf/jmxremote.p
assword"
You can choose a different port for JMX (8003 above) and Jolokia (7803).
If you have an internal IP to lock Jolokia onto you can replace the "catch
all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from
the telegraf plugin. You can use the option '-
Dcom.sun.management.jmxremote.authenticate=false' if you don't want to
authenticate. Use at your own risk.
```

## NodeManager

To configure the NodeManagers to expose the Jolokia API, you can setup the following in <HADOOP HOME>/etc/hadoop/hadoop-env.sh:

```
export YARN_NODEMANAGER_OPTS="$YARN_NODEMANAGER_OPTS
-javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
-agent.jar=port=7804,host=0.0.0.0 -Dcom.sun.management.jmxremote
-Dcom.sun.management.jmxremote.port=8004
-Dcom.sun.management.jmxremote.ssl=false
-Dcom.sun.management.jmxremote.password.file=$HADOOP_HOME/conf/jmxremote.p
assword"
You can choose a different port for JMX (8004 above) and Jolokia (7804).
If you have an internal IP to lock Jolokia onto you can replace the "catch
all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from
the telegraf plugin. You can use the option '-
Dcom.sun.management.jmxremote.authenticate=false' if you don't want to
authenticate. Use at your own risk.
```

#### **JobHistoryServer**

To configure the JobHistoryServer to expose the Jolokia API, you can setup the following in <HADOOP HOME>/etc/hadoop/hadoop-env.sh:

export HADOOP JOB HISTORYSERVER OPTS="\$HADOOP JOB HISTORYSERVER OPTS

- -javaagent:/opt/hadoop/lib/jolokia-jvm-1.6.0
- -agent.jar=port=7805,host=0.0.0.0 -Dcom.sun.management.jmxremote
- -Dcom.sun.management.jmxremote.port=8005
- -Dcom.sun.management.jmxremote.password.file=\$HADOOP\_HOME/conf/jmxremote.password"

You can choose a different port for JMX (8005 above) and Jolokia (7805). If you have an internal IP to lock Jolokia onto you can replace the "catch all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from the telegraf plugin. You can use the option '-

Dcom.sun.management.jmxremote.authenticate=false' if you don't want to authenticate. Use at your own risk.

# **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop Secondary NameNode	Cluster Namespace Server	Node Name Node IP Compile Info Version	GC Copies Count GC Marks Sweep Compact Count GC Number Info Threshold Exceeded GC Number Warning Threshold Exceeded GC Time GC Copy Time GC Marks Sweep Compact Time GC Total Extra Sleep Time Logs Error Count Logs Fatal Count Logs Info Count Logs Warn Count Memory Heap Committed Memory Heap Used Memory Max Memory Non Heap Committed Memory Non Heap Used Threads Blocked Threads New Threads Runnable Threads Terminated Threads Timed Waiting Threads Waiting

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop NodeManager	Cluster Namespace Server	Node Name Node IP	Containers Allocated Memory Allocate Memory Allocated Oportunistic Virtual Cores Allocated Oportunistic Virtual Cores Allocated Memory Available Virtual Cores Available Directories Bad Local Directories Bad Local Directories Bad Log Cache Size Before Clean Container Launch Duration Avg Time Container Launch Duration Number Of Operations Containers Completed Containers Failed Containers Failed Containers Reiniting Containers Reiniting Containers Rolled Back on Failure Containers Running Disk Utilization Good Local Directories Disk Utilization Good Local Directories Disk Utilization Good Local Directories Bytes Deleted Private Bytes Deleted Public Containers Running Opportunistic Bytes Deleted Total Shuffle Connections Shuffle Output Bytes Shuffle Outputs Failed Shuffle Outputs Ok GC Count GC Copies Count GC Marks Sweep Compact Count GC Number Info Threshold Exceeded GC Number Warning Threshold Exceeded GC Time GC Copy Time GC Marks Sweep Compact Time GC Total Extra Sleep Time Logs Error Count Logs Fatal Count

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop ResourceManager	Cluster Namespace Server	Node Name Node IP	ApplicationMaster Launch Delay Avg ApplicationMaster Launch Delay Number ApplicationMaster Register Delay Avg ApplicationMaster Register Delay Number NodeManager Active Number NodeManager Decomissioned Number NodeManager Decomissioning Number NodeManager Lost Number NodeManager Rebooted Number NodeManager Shutdown Number NodeManager Healthy Number NodeManager Healthy Number NodeManager Wemory Limit NodeManager Virtual Cores Limit Used Capacity Active Applications Active Users Aggregate Containers Allocated Aggregate Containers Preempted Aggregate Containers Released Aggregate Node Local Containers Allocated Aggregate Node Local Containers Allocated Aggregate Off Switch Containers Allocated Aggregate Virtual Cores Seconds Preempted Containers Allocated Memory Allocated Virtual Cores Allocated Application Attempt First Container Allocation Delay Avg Time Application Attempt First Container Allocation Delay Number

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop DataNode	Cluster Namespace Server	Node Name Node IP Cluster ID Version	Transceiver Count Transmits in Progress Cache Capacity Cache Used Capacity DFS Used Estimated Capacity Lost Total Last Volume Failure Rate Blocks Number Cached Blocks Number Failed to Cache Blocks Number Failed to Uncache Volumes Number Failed Capacity Remaining GC Count GC Oppies Count GC Marks Sweep Compact Count GC Number Info Threshold Exceeded GC Number Warning Threshold Exceeded GC Time GC Copy Time GC Marks Sweep Compact Time GC Total Extra Sleep Time Logs Error Count Logs Fatal Count Logs Warn Count Memory Heap Max Memory Heap Used Memory Heap Used Memory Max Memory Non Heap Committed Memory Non Heap Committed Memory Non Heap Max Memory Non Heap Used Threads Blocked Threads Runnable Threads Terminated Threads Timed Waiting Threads Waiting

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop NameNode	Cluster Namespace Server	Node IP Transaction ID Last Written Time Since Last Loaded Edits HA State File System State Block Pool ID Cluster ID Compile Info Distinct Version Count Version	Block Capacity Blocks Total Capacity Used Capacity Used Non DFS Blocks Corrupt Estimated Capacity Lost Total Blocks Excess Heartbeats Expired Files Total File System Lock Queue Length Blocks Missing Blocks Missing Replication with Factor One Clients Active Data Nodes Dead Data Nodes Decommissioning Dead Data Nodes Decommissioning Live Data Nodes Decommissioning Encryption Zones Number Data Nodes Entering Maintenance Files Under Construction Data Nodes Dead in Maintenance Data Nodes Live Storages Stale Replication Pending Timeouts Data Node Message Pending Blocks Pending Deletion Blocks Pending Blocks Pending Replication Blocks Misreplicated Postponed Blocks Scheduled Replication Snapshots Snapshottable Directories Data Nodes Stale Files Total Load Total Sync Count Total Transactions Since Last Checkpoint

Object:	Identifiers:	Attributes:	Datapoints:
Hadoop JobHistoryServer	Cluster Namespace Server	Node Name Node IP	GC Copies Count GC Marks Sweep Compact Count GC Number Info Threshold Exceeded GC Number Warning Threshold Exceeded GC Time GC Copy Time GC Marks Sweep Compact Time GC Total Extra Sleep Time Logs Error Count Logs Fatal Count Logs Info Count Logs Warn Count Memory Heap Committed Memory Heap Used Memory Max Memory Non Heap Committed Memory Non Heap Used Threads Blocked Threads Runnable Threads Terminated Threads Timed Waiting Threads Waiting

Additional information may be found from the Support page.

## **HAProxy Data Collector**

Cloud Insights uses this data collector to gather metrics from HAProxy.

- 1. From **Admin > Data Collectors**, click **+Data Collector**. Under **Services**, choose HAProxy.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.

4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Telegraf's plugin for HAProxy relies on HAProxy Stats enablement. This is a configuration built into HAProxy but it is not enabled out of the box. When enabled, HAProxy will expose an HTML endpoint that can be viewed on your browser or scraped for extraction of status of all HAProxy configurations.

## Compatibility:

Configuration was developed against HAProxy version 1.9.4.

### **Setting Up:**

To enable stats, edit your haproxy configuration file and add the the following lines after the 'defaults' section, using your own user/password and/or haproxy URL:

```
stats enable
stats auth myuser:mypassword
stats uri /haproxy?stats
```

The following is a simplified example configuration file with stats enabled:

```
global
  daemon
  maxconn 256
defaults
  mode http
  stats enable
  stats uri /haproxy?stats
  stats auth myuser:mypassword
  timeout connect 5000ms
  timeout client 50000ms
  timeout server 50000ms
frontend http-in
  bind *:80
  default backend servers
frontend http-in9080
  bind *:9080
  default backend servers 2
backend servers
  server server1 10.128.0.55:8080 check ssl verify none
  server server2 10.128.0.56:8080 check ssl verify none
backend servers 2
  server server3 10.128.0.57:8080 check ssl verify none
  server server4 10.128.0.58:8080 check ssl verify none
```

For complete and up to date instructions, see the HAProxy documentation.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
HAProxy Frontend	Namespace Address Proxy	Node IP Node Name Proxy ID Mode Process id Sessions Rate Limit Server id Sessions Limit Status	Bytes In Bytes Out Cache Hits Cache Lookups Compression Bytes Bypassed Compression Bytes In Compression Bytes Out Compression Responses Connection Rate Connection Rate Max Connections Total Requests Denied by Connection Rule Requests Denied by Security Concerns Responses Denied by Security Concerns Responses Denied by Session Rule Requests Errors Responses 1xx Responses 1xx Responses 2xx Responses 3xx Responses 4xx Responses 5xx Responses 5xx Responses Other Requests Intercepted Sessions Rate Sessions Rate Sessions Rate Max Requests Rate Requests Total Sessions Sessions Max Sessions Total Requests Rewrites

Object:	Identifiers:	Attributes:	Datapoints:
HAProxy Server	Namespace Address Proxy Server	Node IP Node Name Check Time to Finish Check Fall Configuration Check Health Value Check Rise Configuration Check Status Proxy ID Last Change Time Last Session Time Mode Process id Server id Status Weight	Active Servers Backup Servers Bytes In Bytes Out Check Downs Check Fails Client Aborts Connections Connection Average Time Downtime Total Denied Responses Connection Errors Response Errors Responses 1xx Responses 2xx Responses 3xx Responses 5xx Responses 5xx Responses Other Server Selected Total Queue Current Queue Max Queue Average Time Sessions per Second Sessions per Second Sessions per Second Sessions Total Sessions Total Sessions Total Sessions Total Time Average Requests Redispatches Requests Retries Requests Rewrites

Object:	Identifiers:	Attributes:	Datapoints:
HAProxy Backend	Namespace Address Proxy	Node IP Node Name Proxy ID Last Change Time Last Session Time Mode Process id Server id Sessions Limit Status Weight	Active Servers Backup Servers Bytes In Bytes Out Cache Hits Cache Lookups Check Downs Client Aborts Compression Bytes Bypassed Compression Bytes In Compression Bytes Out Compression Responses Connections Connection Average Time Downtime Total Requests Denied by Security Concerns Responses Denied by Security Concerns Responses Errors Responses Errors Responses 1xx Responses 2xx Responses 3xx Responses 3xx Responses 5xx Responses 5xx Responses Other Server Selected Total Queue Current Queue Max Queue Average Time Sessions per Second Sessions per Second Sessions per Second Sessions Total Connection Reuse Response Time Average Sessions Sessions Total Sessions Total Time Average Requests Redispatches Requests Retries Requests Rewrites

Additional information may be found from the Support page.

## **JVM Data Collector**

Cloud Insights uses this data collector to gather metrics from JVM.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose JVM.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in JVM documentation.

### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
JVM	Namespace JVM	OS Architecture OS Name OS Version Runtime Specification Vendor Runtime Specification Version Uptime Runtime VM Name Runtime VM Version Node Name Node IP	Class Loaded Class Unloaded Memory Heap Committed Memory Heap Used Max Memory Heap Used Memory Non Heap Committed Memory Non Heap Init Memory Non Heap Init Memory Non Heap Max Memory Non Heap Used Memory Objects Pending Finalization OS Processors Available OS Committed Virtual Memory Size OS Free Physical Memory Size OS Free Swap Space Size OS Max File Descriptor Count OS Open File Descriptors Count OS Processor CPU Load OS Processor CPU Time OS System CPU Load OS System Load Average OS Total Physical Memory Size OS Total Swap Space Size Thread Daemon Count Thread Peak Count Thread Peak Count Thread Total Started Count Garbage Collector Copy Collection Count Garbage Collector Copy Collection Time Garbage Collector Mark- sweep Collection Count Garbage Collector G1 Old Generation Collection Count Garbage Collector G1 Old Generation Collection Time Garbage Collector G1 Time

Additional information may be found from the Support page.

## Kafka Data Collector

Cloud Insights uses this data collector to gather metrics from Kafka.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Kafka.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



The Kafka plugin is based on the telegraf's Jolokia plugin. As such as a requirement to gather info from all Kafka brokers, JMX needs to be configured and exposed via Jolokia on all components.

## Compatibility

Configuration was developed against Kafka version 0.11.0.2.

## Setting up

All the instructions below assume your install location for kafka is '/opt/kafka'. You can adapt instructions below to reflect your install location.

## Jolokia Agent Jar

A version the Jolokia agent jar file must be downloaded. The version tested against was Jolokia agent 1.6.0.

Instructions below assume that the downloaded jar file (jolokia-jvm-1.6.0-agent.jar) is placed under the location '/opt/kafka/libs/'.

### **Kafka Brokers**

To configure Kafka Brokers to expose the Jolokia API, you can add the following in <KAFKA HOME>/bin/kafka-server-start.sh, just before the 'kafka-run-class.sh' call:

```
export JMX_PORT=9999
export RMI_HOSTNAME=`hostname -I`
export KAFKA_JMX_OPTS="-javaagent:/opt/kafka/libs/jolokia-jvm-1.6.0-
agent.jar=port=8778,host=0.0.0.0
-Dcom.sun.management.jmxremote.password.file=/opt/kafka/config/jmxremote.p
assword -Dcom.sun.management.jmxremote.ssl=false
-Djava.rmi.server.hostname=$RMI_HOSTNAME
-Dcom.sun.management.jmxremote.rmi.port=$JMX_PORT"
```

Note that example above is using 'hostname -I' to setup the 'RMI\_HOSTNAME' environment variable. In multiple IP machines, this will need to be tweaked to gather the IP you care about for RMI connections.

You can choose a different port for JMX (9999 above) and Jolokia (8778). If you have an internal IP to lock Jolokia onto you can replace the "catch all" 0.0.0.0 by your own IP. Notice this IP needs to be accessible from the telegraf plugin. You can use the option '-Dcom.sun.management.jmxremote.authenticate=false' if you don't want to authenticate. Use at your own risk.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Kafka Broker	Cluster Namespace Broker	Node Name Node IP	Replica Manager Fetcher Max Lag Zookeeper Client Connections Zookeeper Client Connections (15m rate) Zookeeper Client Connections (5m rate) Zookeeper Client Connections (mean rate) Zookeeper Client Connections (1m rate) Replica Manager Partition Count Thread Count Daemon Thread Count Daemon Thread Count Total Started Offline Partitions Produce Requests Total Time (50th Percentile) Produce Requests Total Time (75th Percentile) Produce Requests Total Time (98 Percentile) Produce Requests Total Time (99 Percentile) Produce Requests Total Time (99th Percentile) Produce Requests Total Time Max Produce Requests Total Time Mean Produce Requests Total Time Mean Produce Requests Total Time Mean Produce Requests Total Time Max Produce Requests Total Time Mean Produce Requests Total Time Max Produce Requests Total Time Mean Produce Requests Total

Additional information may be found from the Support page.

## **Kibana Data Collector**

Cloud Insights uses this data collector to gather metrics from Kibana.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Kibana.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Kibana documentation.

### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Kibana	Namespace Address	Node IP Node Name Version Status	Concurrent Connections Heap Max Heap Used Requests per Second Response Time Average Response Time Max Uptime

Additional information may be found from the Support page.

## **Memcached Data Collector**

Cloud Insights uses this data collector to gather metrics from Memcached.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Memcached.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Memcached wiki.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Memcached	Namespace Server	Node IP Node Name	Accepting Connections Handled Authentication Requests Failed Authentications Bytes Used Bytes Read (per sec) Bytes Written (per sec) CAS Badval CAS Hits CAS Misses Flush Reqs (per sec) Get Reqs (per sec) Get Reqs (per sec) Touch Reqs (per sec) Connection Yields (per sec) Connection Structures Open Connections Current Stored Items Decr Requests Hits (per sec) Delete Requests Misses (per sec) Delete Requests Misses (per sec) Items Evicted Valid Evictions Expired Items Get Hits (per sec) Get Misses (per sec) Used Hash Bytes Hash Is Expanding Hash Power Level Incr Requests Hits (per sec) Used Hash Bytes Hash Is Expanding Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Is Expanding Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Is Expanding Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses (per sec) Used Hash Bytes Hash Power Level Incr Requests Misses Used Hash Bytes Hash Power Level Incr Requests Misses Used Hash Bytes Hash Power Level Incr Requests Misses Used Hash Bytes Hash Power Level Incr Requests Misses Used Hash Bytes Hash Byte

Additional information may be found from the Support page.

## **MongoDB Data Collector**

Cloud Insights uses this data collector to gather metrics from MongoDB.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose MongoDB.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the MongoDB documentation.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
MongoDB	Namespace Hostname		
MongoDB Database	Namespace Hostname Database name		

Information may be found from the Support page.

## **MySQL Data Collector**

Cloud Insights uses this data collector to gather metrics from MySQL.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose MySQL.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the MySQL documentation.

Objects and Counters			
The following objects and their counters are collected:			

Object:	Identifiers:	Attributes:	Datapoints:
MySQL	Namespace MySQL Server	Node IP Node Name	Aborted Clients (per sec) Aborted Connects (per sec) RX Bytes (per sec) Commands Admin (per sec) Commands Alter Event Commands Alter Event Commands Alter Instance Commands Alter Instance Commands Alter Function Commands Alter Instance Commands Alter Function Commands Alter Procedure Commands Alter Table Commands Alter Table Commands Alter Tablespace Commands Analyze Commands Assign To Keycache Commands Begin Commands Binlog Commands Change Master Commands Change DB Commands Change Master Commands Change Repl Filter Commands Check Commands Create DB Commands Create DB Commands Create Event Commands Create Event Commands Create Table Commands Create Index Commands Create Index Commands Create UDF Commands Create UDF Commands Create UDF Commands Create UDF Commands Create View Commands Create USer Commands Create UDF Commands Create USer Commands Create View Commands Create View Commands Create USer Commands Create View Commands Create View Commands Create USer Co

Additional information may be found from the Support page.

## **Netstat Data Collector**

Cloud Insights uses this data collector to gather Netstat metrics.

- From Admin > Data Collectors, click +Data Collector. Under Services, choose Netstat.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



## **Objects and Counters**

The following objects and their counters are collected:

Object:	Identifiers:	Attributes:	Datapoints:
Netstat	Node UUID	Node IP Node Name	

## **Troubleshooting**

Additional information may be found from the Support page.

## **Nginx Data Collector**

Cloud Insights uses this data collector to gather metrics from Nginx.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Nginx.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.





Nginx metric collection requires that Nginx http stub status module be enabled.

Additional information may be found in the Nginx documentation.

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
Nginx	Namespace Server	Node IP Node Name Port	Accepts Active Handled Reading Requests Waiting Writing

Additional information may be found from the Support page.

## **PostgreSQL Data Collector**

Cloud Insights uses this data collector to gather metrics from PostgreSQL.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose PostgreSQL.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the PostgreSQL documentation.

### **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
PostgreSQL Server	Namespace Database Server	Node Name Node IP	Buffers Allocated Buffers Backend Buffers Backend File Sync Buffers Checkpoint Buffers Clean Checkpoints Sync Time Checkpoints Write Time Checkpoints Requests Checkpoints Timed Max Written Clean
PostgreSQL Database	Namespace Database Server	Database OID Node Name Node IP	Blocks Read Time Blocks Write Time Blocks Hits Blocks Reads Conflicts Deadlocks Client Number Temp Files Bytes Temp Files Number Rows Deleted Rows Fetched Rows Fetched Rows Returned Rows Updated Transactions Committed Transactions Rollbacked

Additional information may be found from the Support page.

## **Puppet Agent Data Collector**

Cloud Insights uses this data collector to gather metrics from Puppet Agent.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Puppet.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Puppet documentation

## **Objects and Counters**

Object:	Identifiers:	Attributes:	Datapoints:
---------	--------------	-------------	-------------

Puppet Agent	Namespace Node UUID	Node Name Location Node IP Version Configstring Version Puppet	Changes Total Events Failure Events Success Events Total Resources Changed Resources Failed Resources Failed To Restart Resources Outofsync Resources Restarted Resources Scheduled Resources Skipped Resources Total Time Anchor Time Configretrieval Time Cron Time Exec Time File Time Filebucket Time Lastrun Time Package Time Schedule Time Service Time Sshauthorizedkey Time Total Time User
--------------	------------------------	--	--

Additional information may be found from the Support page.

## **Redis Data Collector**

Cloud Insights uses this data collector to gather metrics from Redis. Redis is an open source, in-memory data structure store used as a database, cache, and message broker, supporting the following data structures: strings, hashes, lists, sets, and more.

- 1. From Admin > Data Collectors, click +Data Collector. Under Services, choose Redis.
  - Select the Operating System or Platform on which the Telegraf agent is installed.
- 2. If you haven't already installed an Agent for collection, or you wish to install an Agent for a different Operating System or Platform, click *Show Instructions* to expand the Agent installation instructions.
- 3. Select the Agent Access Key for use with this data collector. You can add a new Agent Access Key by clicking the **+ Agent Access Key** button. Best practice: Use a different Agent Access Key only when you want to group data collectors, for example, by OS/Platform.
- 4. Follow the configuration steps to configure the data collector. The instructions vary depending on the type of Operating System or Platform you are using to collect data.



Information may be found in the Redis documentation.

## **Objects and Counters**

The following objects and their counters are collected:

Object:	Identifiers:	Attributes:	Datapoints:
Redis	Namespace Server		

## **Troubleshooting**

Additional information may be found from the Support page.

# **Object Icon Reference**

A quick reference for object icons used in Cloud Insights.



### **Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.