



ECE-218 Embedded Microcontroller Projects

Background for Exercise 0 – Setup




Overview of Exercise 0

- Install MPLAB X, XC16, and text PIC24 library
- Explore Microstick II Development Kit
- Add headers to the Microstick II board




In the Box



Microstick II

Schematic from Information Sheet in Box







Equipment/Parts Needed

- Two-pin header for VDD and GND
- Six-pin header for serial cable
- Soldering iron/Fan
- Laptop





1. Replace chip with PIC24HJ128GP502


Removing Chip from Socket

Ideally, use a chip puller.

 Can use fingers or small screwdriver.

 Try to have all pins release at the same time so they don't bend.








Inserting PIC24HJ128GP502

Top of Chip

- Line up top of chip with notch in outline on Microstick II board.
- Be sure pins are lined up with holes before pressing it in.






Top of Socket



Soldering Basics





Completed Board

