Document ID: DOC_FREEZER_01
Title: Freezer Temperature Monitoring
Category: Equipment
Version: 1.0
Active: true

Content:

Purpose: Keep frozen inventory at a safe temperature. The acceptable freezer range is 0°F (-18°C) or below.

1. Check and record the freezer temperature at opening, at mid-shift, and at closing on the Freezer Temperature Log.

2. If the reading is above 0°F, verify it with a calibrated probe thermometer placed between packages in the center of the freezer.

3. Confirm the door is fully closed, the door seal is intact, and the unit is plugged in. Wait 15 minutes and check again.

4. If the second reading is still above 0°F, keep the door closed and follow Food Storage Safety to protect inventory.

5. Record both readings, the time, the actions taken, and your initials on the Freezer Temperature Log.

6. Notify the shift manager immediately following Manager Escalation Procedures.

End of Document