
VYANET

Quick Setup Guide

Outdoor Security Camera




V1.0

Setting Up Your Vyanet Security Camera

1 *Getting Started*


Package Contents



Security Tips

- Please change the camera's password regularly, using a combination of numbers, letters and special characters.
- We recommend that you regularly update your camera with the latest available software and firmware to ensure the best experience with your camera.

2 Physical Description





The cords on this product are a potential strangulation hazard. For child safety, please keep these cords out of the reach of children.

3 Setting Up Your Camera: Connection via the Vyanet App (Recommended)

Before You Get Started

Scan the QR code below to download and install the Vyanet APP.

VYANET | GET IT ON Google Play | Available on the App Store | VYANET Mobile App


To ensure a smoother video experience on your smart phone, it is recommended that your smart phone meet the following specifications:

- iOS: version 11 or higher.
- Android: 5.0 or higher, using a device with a Graphics Processing Unit (GPU).


Note: For the best experience, please update the APP to the latest version!

■ Wi-Fi Connection


1. Please tighten the antenna clockwise and make sure it is in a vertical position.



2. Plug the power adapter into the camera, and please wait for a few seconds until hearing **"Ready for Wi-Fi configuration"**




3. Make sure that your smart phone is connected to your Wi-Fi router.



4. Open the Vyanet APP and please register a Vyanet account, or sign in if you have one already.




5. Follow the steps below:





















Note: Please point the smartphone camera at the QR code at a distance of 6 to 12in (15 to 30cm). If the QR code is still not readable, try moving the camera slowly around at distances of 6 to 12in (15 to 30cm) until read.










Note: If the adding process fails, please reset your camera and try adding again according to the above method.



4 PC and Mac Software (Optional)


■ Vyanet VMS

Vyanet VMS software can be installed to allow Vyanet cameras to be connected and viewed on a Windows PC or Mac.
This software does not require additional plug-ins and will support up to 36 simultaneous Vyanet camera connections.
To manage multiple cameras using a PC or Mac, we suggest you install Vyanet VMS.
You can download the "Vyanet VMS "Windows version or the "Vyanet VMS" Mac version at this location:
https://www.vyanet.com/software/


Note: For the best experience, please update Vyanet VMS to the latest version!

Add the IP Camera

1. Run Vyanet VMS, then create a local administrator account and login.
2. Tap the "+" icon on the Vyanet VMS and follow the setup wizard to add your camera.



5 Hardware Installation



Point the camera at the desired location and use the screws provided to mount it.

Please Note:


Ensure that rain or water will not reach the connector ports at the end of the tailcable. These connectors are not weather-resistant.

6 Important Notice

■ Camera Username & Password

The camera username & password are used to access and manage your camera. Having a strong password can significantly improve the security of your camera.

If you have forgotten either of them, please press the "Reset" button.



Press the "Reset" button and hold it for more than 3~5 seconds. Once reset, please return to step 3.

■ Storage Media

Your camera supports NVR (Network Video Recorder) and Micro SD card (supports FAT32 and exFAT format) storage formats.

To format your Micro SD card to FAT32, a format tool is available in the Vyanet App under the SD Card setting for each camera.



NVR



Micro SD card
(FAT32 & exFAT)

■ Safety Tips



Prohibit use at high temperature



Prohibit use at low temperature



Keep away from children



Not a children's toy



Keep dry



Caution Electricity

7 Product Performance

WLAN frequency range: 2412MHz - 2472MHz
5725MHz - 5850MHz
Maximum transmission power: < 18dBm
Wireless Standard: IEEE802.11b/g/n (2.4GHz)
IEEE802.11a/n/ac (5GHz)
Power Supply: DC 12V 1.0A 12W



Keep away from fire



Use the supplied screw pack



Use the correct power supply

and

8 *Troubleshooting*

- **IP cameras is not powering on**

If you find your camera is not powering on, please the check following:

1. Please check whether the outlet is working properly or not. Try to plug the camera into a different outlet and see whether it will work.
2. Please check whether the DC adapter is working or not. If you have another 12V/1A power adapter which is working, please try with another power adapter and see whether it will work.
3. If it still won't work, please contact Vyanet support.

- **How to re-configure the Wi-Fi connection for Vyanet cameras after router changed?**

1. Reset your camera using Step 3.
2. Open the Vyanet app and scan your camera's QR code.
3. Verify to make sure that your smartphone is connected to the same Wi-Fi network as the camera.

VYANET

Vyanet Operating Group, Inc.
410 SW Columbia St, Ste 120
Bend, OR 97702
(844) 4-VYANET



socworks@vyanet.com
(844) 4-VYANET

VYANET V5P Install

For a more detailed install guide, please refer to the Vyanet V5P Install Guide which can be accessed using this QR Code.

www.vyanet.com