Data File C:\CHEM32\1\DATA\19060601\19060601 2009-07-16 20-49-47\16.D

Sample Name: 16

Acq. Operator : Brittni Seq. Line : 16 Acq. Instrument : Instrument 1 Location : Vial 16

Inj Volume : 5 μl


 $Sequence \ File : C: \ Chem32\ 1\ DATA\ 19060601\ 19060601\ 2009-07-16\ 20-49-47\ 19060601. \ S$

Method : C:\CHEM32\1\DATA\19060601\19060601 2009-07-16 20-49-47\FID_TCD_2019.M (

Sequence Method)

Last changed : 7/16/2009 8:49:46 PM by Brittni
Method Info : Method for FID and TCD columns

Created by Nate Heili Date: July 25, 2018



._____

Area Percent Report

Sorted By : Retention Time Multiplier: : 1.0000 Dilution: : 1.0000 Use Multiplier & Dilution Factor with ISTDs

Signal 1: FID2 B, Signal 2: TCD1 A,

Peak	RetTi me	Si g	Туре	Area	Hei ght	Area
#	[mi n]					%
1	1. 448	1	ВВ	232. 90651	60. 49547	90. 52032
2	2. 190	2	BB	24. 39099	7. 21719	9. 47968

Total s: 257. 29750 67. 71266

Data File C:\CHEM32\1\DATA\19060601\19060601 2009-07-16 20-49-47\16.D

Sample Name: 16

*** End of Report ***