Data File C:\CHEM32\1\DATA\19060402\19060402 2009-07-14 21-26-12\23.D

Sample Name: 23

\_\_\_\_\_\_

Acq. Operator : Brittni Seq. Line : 23
Acq. Instrument : Instrument 1 Location : Vial 23

Inj Volume : 5 μl


 $\label{lem:condition} Sequence \ \mbox{File} \quad : \ \mbox{C:\hem32\1\DATA\19060402\2009-07-14\ 21-26-12\19060402\.} \ S$ 

Method : C:\CHEM32\1\DATA\19060402\19060402 2009-07-14 21-26-12\FID\_TCD\_2019.M (

Sequence Method)

Last changed : 7/14/2009 5:15:07 PM by Brittni
Method Info : Method for FID and TCD columns

Created by Nate Heili Date: July 25, 2018



------

## Area Percent Report

\_\_\_\_\_

Sorted By : Retention Time Multiplier: : 1.0000 Dilution: : 1.0000 Use Multiplier & Dilution Factor with ISTDs

No peaks found

\_\_\_\_\_

\*\*\* End of Report \*\*\*