Data File C:\CHEM32\1\DATA\19060501\19060501 2009-07-15 18-54-56\35.D

Sample Name: 35

\_\_\_\_\_\_

Acq. Operator : Brittni Seq. Line : 35
Acq. Instrument : Instrument 1 Location : Vial 35

Inj Volume : 5 μl


 $\label{eq:conditional_condition} Sequence \ \mbox{File} \quad : \ \mbox{C: \hem32\label{lem32\labeleq} 19060501\labeleq} \ 2009-07-15\ \ 18-54-56\labeleq 19060501\labeleq \ Sequence \ \mbox{File} \ \ : \ \mbox{C: \hem32\labeleq} \ \mbox{C:$ 

Method : C:\CHEM32\1\DATA\19060501\19060501 2009-07-15 18-54-56\FID\_TCD\_2019.M (

Sequence Method)

Last changed : 7/15/2009 6:54:55 PM by Brittni
Method Info : Method for FID and TCD columns

Created by Nate Heili Date: July 25, 2018



------

## Area Percent Report

\_\_\_\_\_

Sorted By : Retention Time Multiplier: : 1.0000 Dilution: : 1.0000 Use Multiplier & Dilution Factor with ISTDs

No peaks found

\_\_\_\_\_

\*\*\* End of Report \*\*\*