Data File C:\CHEM32\1\DATA\19060701\19060701 2009-07-17 22-09-51\17.D

Sample Name: 17

-----

Acq. Operator : Brittni Seq. Line : 17
Acq. Instrument : Instrument 1 Location : Vial 17

Inj Volume : 5 μl


 $\label{lem:condition} Sequence \ \mbox{File} \quad : \ \mbox{C:\hcm32\1\DATA\19060701\ 2009-07-17\ 22-09-51\19060701.S}$ 

Method : C:\CHEM32\1\DATA\19060701\19060701 2009-07-17 22-09-51\FID\_TCD\_2019.M (

Sequence Method)

Last changed : 7/17/2009 10:09:50 PM by Brittni
Method Info : Method for FID and TCD columns

Created by Nate Heili Date: July 25, 2018



.\_\_\_\_\_

## Area Percent Report

\_\_\_\_\_

Sorted By : Retention Time Multiplier: : 1.0000 Dilution: : 1.0000 Use Multiplier & Dilution Factor with ISTDs

Signal 1: FID2 B,

Peak RetTime Sig Type Area Height Area
# [min] %
----|-----|----|-----|
1 1.448 1 BB 11.10146 2.92619 1.220e2

Totals: 9. 10146 9. 26193e-1

\_\_\_\_\_\_