



Radon Monitoring

User manual

Local monitoring for GQ RadonScan devices

Version	5.5.3
Date	27 July 2026
Home Assistant	Local app / Ingress
Data	Local SQLite + optional external upload

Contents

1. Purpose, measurement principle and limitations
2. Installation, upgrade and first start
3. Overview
4. Analysis and statistics
5. Devices & System, factor and calibration
6. Rooms, assignments and events
7. GQ Radiation World Map
8. Scientific PDF reports
9. Data management and security
10. Operation, mobile layout and accessibility
11. Troubleshooting
12. Privacy and responsible use
13. New in version 5.5.3

Important: this app is a monitoring and documentation tool, not an official measurement system.

1. Purpose, measurement principle and limitations

Radon Monitoring reads completed hourly records from compatible GQ RadonScan devices using read-only SPIR commands. It stores raw counts (CPH), the conversion factor used for each record and the calculated activity concentration locally in SQLite.

The app supports continuous observation, statistical analysis and traceable documentation. It does not replace traceable calibration, a recognised regulatory measurement or professional medical, building or legal advice.

A high individual hourly value is not automatically an exceedance of an annual reference value. The interface and reports distinguish the current value, period statistics, counting uncertainty, calibration information and professional interpretation.

2. Installation, upgrade and first start

Connect the RadonScan by USB, make MQTT available to Home Assistant and start the app. Version 5.5.3 defaults to `/dev/serial/by-id/usb-1a86_USB_Serial-if00-port0`. A fixed `serial_port` is used exclusively; auto deliberately enables discovery.

Create a Home Assistant backup before upgrades and destructive actions. After upgrading, the sidebar or Help view must show version 5.5.3. If an old Ingress view remains open, close the panel and reopen it.

Only completed hours are imported. A newly connected device can therefore remain without a current value until a complete record is available.

3. Overview

The Overview context bar selects a device and campaign. The most recently or currently assigned room is resolved automatically. Current value, period windows, selected sample count, 24-hour maximum and chart are derived from that device, campaign and room. Device and campaign choices are retained locally in the browser.

The Radon traffic light primarily assesses the 24-hour mean. Until duration or coverage is sufficient, it provisionally uses the latest completed hourly value. The assessment basis, coverage and configured warning/danger thresholds are displayed directly below the signal.

The fourth metric shows the observed maximum within the latest 24-hour window, including its time and coverage, instead of a potentially mixed overall mean. Documented events appear as chart markers and gaps are shown as breaks rather than connected lines.

Depending on the privacy mode, the Home Assistant location card shows an address and precise coordinates, only the location name and rounded coordinates, or no location card. Coordinates include degree units and cardinal directions, for example 51.60176° N, 7.45410° E. Directly below it, the interface shows only the automatically assigned room and, when available, the measurement height. Location values come only from the local Home Assistant Core configuration and no external geocoding is performed.

4. Analysis and statistics

Analysis starts with a plain-language summary of trend direction, warning/danger threshold share and data coverage. Basic analysis contains mean, median, minimum, maximum, quantiles and threshold time. Effective sample size, moving-block-bootstrap confidence intervals, autocorrelation, distribution diagnostics and sensitivity analysis are grouped in an advanced section that is collapsed by default.

Missing measurements are not imputed. Unusual observations are not deleted automatically. Quality flags identify undocumented factors, non-primary sources, implausible values and duplicate timestamps.

Change-point analysis is exploratory. For very long series, only this diagnostic is bounded to an evenly distributed, time-ordered sample. Descriptive statistics, threshold calculations and data checksums continue to use every selected record.

Statistical significance proves neither causality nor practical importance. Events and interventions still require professional interpretation.

5. Devices & System, factor and calibration

The former Expert view was removed completely from the interface and sidebar in version 5.1.0. Device, protocol, service and database status is grouped under Devices & System; configured thresholds and other operating parameters are shown under Settings.

The on-demand System self-test checks the API version, SQLite integrity, a rolled-back room persistence round trip, the report directory, device runtime, MQTT and the local Home Assistant connection. Results are shown as an actionable checklist and do not alter stored rooms or measurements.

The currently configured factor is displayed separately from the factor stored with the selected historical measurement. Historical results therefore remain reproducible after later configuration changes.

Calibration records can include date, laboratory, certificate reference, factor, uncertainty, next due date and notes. A calibration entry does not silently alter existing measurements.

6. Rooms, assignments and events

The Local metadata view is named Rooms and events. Place or address and building name are taken directly from the general Home Assistant settings and cannot be entered again or differently in the app. Only the room and measurement height are added manually.

The workflow is divided into two steps: first create or edit a room, then assign it to a device and time period. Assignment remains disabled until at least one room has been stored. Validation messages appear directly beside the affected field, and stored assignments are shown in a dedicated list below the forms.

Room storage is idempotent: saving the same normalised room name again updates the existing record instead of creating a duplicate. Both decimal points and decimal commas are accepted for measurement height, and under Home Assistant Ingress the interface sends tightly bounded fallback information if a proxy changes the regular request body.

Measurements can be assigned to a room for a defined period. Campaign, purpose, start, end and notes remain local. Ventilation, interventions, device moves, construction work or outages can be documented as events without changing original measurements. Matching events are marked in Overview and Analysis charts.

7. GQ Radiation World Map

Upload is optional and disabled by default. When `gmcmmap_enabled` is off, the World Map view is omitted from the sidebar. When enabled it contains only external upload, queue and history functions; local rooms, assignments and events remain in their dedicated view. Account ID and device ID are shown only in masked form.

A persistent queue prevents duplicates, retries temporary failures with increasing delay and can discard measurements older than a configured limit. Manual upload is a protected POST action.

RadonScan values are sent through the dedicated `rdlog.asp` radon endpoint using only AID, GID and pCi. The app does not submit CPM, ACPM or uSV and does not fall back to the generic `log2.asp` radiation endpoint. New uploads therefore no longer create artificial 0 CPM radioactivity entries.

The public position is managed in the GQ account. Radon Monitoring does not transmit its own GPS coordinates. Zero-valued records uploaded previously are stored by the external GMCMMap service and are not removed by an application update.

8. Scientific PDF reports

Compact and detailed reports contain period, room, measurement height, Home Assistant location and building, device, factor, coverage, statistics, time series, method, quality information, software version and SHA-256 checksums.

For multi-year series, only the time-series chart is reduced to a bounded peak-preserving point set. Statistics, threshold events and the data checksum continue to use all selected measurements.

Reports are documentation aids, not official certificates.

9. Data management and security

The complete Data management area can be hidden from navigation and blocked at the API using `data_management_enabled`.

Complete local reset automatically creates a safety backup, clears app data transactionally, verifies SQLite integrity and reports operation ID, deleted records, removed files, sizes and duration. Immediate re-import of the deleted device history is suppressed.

Home Assistant Recorder purge submits recognised RadonScan entities and stable name patterns to `recorder.purge_entities`. An optional long-lived administrator token may be required. It is never displayed, excluded from diagnostics and centrally redacted from error messages.

Verification subsequently checks recent Home Assistant history. It does not prove immediate physical compaction of every Recorder backend and does not automatically cover separately retained long-term statistics.

10. Operation, mobile layout and accessibility

On small screens the sidebar opens as a menu. Tables and the weekly heatmap remain horizontally scrollable inside their own cards; the rest of the page must not create horizontal page overflow.

The interface supports keyboard operation, visible focus, a skip link, Escape to close the menu, reduced motion and text scaling to 200 percent.

Version 5.5.3 adds automated tests for exclusive fixed-port use, skipping recognisable Zigbee and console adapters, de-duplicating device aliases and exposing actionable connection codes. Existing radon-only, layout and language tests remain in place.

11. Troubleshooting

No device: check USB mapping, permissions, configured port and competing processes.

No new values: only completed hours are imported. Press Refresh and inspect the latest scan time under Devices & System.

Old interface: restart the app, close the Ingress panel and reopen it.

Recorder purge fails: check administrator token, Recorder integration and Home Assistant administrator rights.

Verification reports remaining data: wait and verify again; Recorder maintenance can be asynchronous. Treat long-term statistics separately.

Restore rejected: only readable SQLite backups with a compatible schema are accepted. The active database remains unchanged after validation failure.

12. Privacy and responsible use

Measurements and metadata remain local by default. Only enabled external functions transmit data. Location, address and building name are read only through the local Home Assistant Core API and are not manually duplicated. No external geocoding service is used. `location_display_mode` can show full, reduced or no location details. Before screenshots, reports and World Map publication, confirm that visible location data meets your privacy requirements.

Protect backups and reports because they may contain device identifiers, rooms, periods and building information.

13. New in version 5.5.3

Version 5.5.3 stabilises device connectivity on hosts with several serial adapters. The configured `/dev/serial/by-id/usb-1a86_USB_Serial-if00-port0` path is used exclusively. Automatic discovery skips recognisable Sonoff, ITEAD, Zigbee, Z-Wave and ttyAMA devices and de-duplicates aliases for the same physical port. Devices & System shows the checked port and an actionable diagnosis such as port busy, no response or wrong device type. The startup message now reports the actual app version. The database and measurements remain compatible.

Configuration overview

Option	Purpose
<code>serial_port</code>	Fixed RadonScan path; use auto only for deliberate discovery
<code>factor_bq_m3_per_cph</code>	Currently configured conversion factor
<code>minimum_data_coverage_percent</code>	Minimum coverage for period results and quality
<code>analysis_timezone</code>	Time zone for daily and weekly profiles
<code>location_display_mode</code>	Show full, reduced or no location details
<code>data_management_enabled</code>	Enable Data management navigation and API
<code>homeassistant_access_token</code>	Optional administrator token for Recorder actions
<code>gmcmmap_enabled</code>	Enable GQ Radiation World Map
<code>gmcmmap_auto_upload</code>	Enable the automatic upload queue

Further technical details are available in [DOCS.md](#) and the built-in Help view.