


## **ENSURE HEAT SET IS FULLY SEATED**

This doesn't need to be precise but the heat set should not be flush with the surface


## **BUFFER WHEEL ASSEMBLY**

#### WHEEL BEHAVIOUR

The wheel should spin fairly freely, it doesn't exactly have to be a fidget spinner but make sure there isn't much resistence. If your wheel isn't turning well check to make sure your heat set is inserted straight by putting a bolt in without the wheel to see if its relatively straight.



# **BUFFER SCREEN**



## **DONT OVER TIGHTEN**

Don't over tighten the M2 bolts, they are screwing into plastic and are not load bearing. Just make sure theyre mostly flush with the surface

