







GRID3 1 BT_TIME
K2 2 Conn_01x02_Socket

GRID3 1 BT_SIGNAL
K1 2 Conn_01x02_Socket

GRID4 1 BT_SLEEP_FRONT
K1 2 Conn_01x02_Socket

GRID4 1 BT_ILLUM
K2 2 Conn_01x02_Socket

SW_Push
GRID1 FAST K2

SW_Push
GRID1 SLOW K1

GRID2 1 BT_SLEEP_TOP
K2 2 Conn_01x02_Socket

K2 BUTTONS_K2
K1 BUTTONS_K1
GRID4 BUTTONS_GRID4
GRID3 BUTTONS_GRID3
GRID2 BUTTONS_GRID2
GRID1 BUTTONS_GRID1



Button	Grid	Key
SLOW	1	1
FAST	1	2
SLEEP_TOP	2	2
SIGNAL	3	1
TIME	3	2
SLEEP_FRONT	4	1
ILLUM	4	2

Bruno Landau Albrecht
brunolal@gmail.com

Sheet: /Buttons/
File: buttons.kicad_sch

Title: Telefunken_Digitale_Electronic_101 - Display

Size: A4	Date:	Rev: 1.0
KiCad E.D.A. 10.0.4		Id: 3/5



Bruno Landau Albrecht
brunolal@gmail.com

Sheet: /RTC/
File: rtc.kicad_sch

Title: Telefunken_Digitale_Electronic_101 – Display


Size: A4

Date:

Rev: 1.0

KiCad E.D.A. 10.0.4

Id: 4/5



Bruno Landau Albrecht
brunolab@gmail.com

Sheet: /Display/
File: display.kicad_sch

Title: Telefunken_Digitale_Electronic_101 – Display

Size: A4	Date:	Rev: 1.0
KiCad E.D.A. 10.0.4		Id: 5/5