

# NITGEN USB Device Driver for Linux Installation Guide

Version 1.05 20-JUN-2008

**NITGEN Co., Ltd.** 

### **Document Version History**

Version	Date	Comments
1.00	24-OCT-2004	Initial Release
1.01	26-NOV-2004	version modify
1.02	29-NOV-2007	Added device
1.03	08-JAN-2008	version modify
1.04	08-MAY-2008	version modify & Added device
1.05	20-JUN-2008	version modify

# 1. Overview

This Document guides NITGEN USB Fingkey Hamster and NITGEN USB eNBioScan-F device driver install on your Linux system.

# 2. System

#### **2.1** System Requirement

item	Recommendation
СРИ	Intel Pentium or higher / Intel Pentium 4 2.0G or higher (HFDU05)
RAM	128M or higher / 512M or higher (HFDU05)
kernel	Linux kernel 2.6 higher
USB	USB 1.1 / 2.0 : HFDU01/04 USB 2.0 : HFDU05
Device	NITGEN USB Fingkey Hamster (HFDU01/HFDU04) / NITGEN USB eNBioScan-F (HFDU05)

## 3. Installation

#### **3.1** NITGEN USB Fingkey Hamster

#### 3.1.1 Package File Name

- VenusDrv-1.0.1-7.tar.gz : NITGEN USB Fingkey Hamster(HFDU01/HFDU04) for Linux

#### 3.1.2 How to install

]#tar -zxvf VenusDrv-1.0.1-7.tar.gz ]#cd VenusDrv-1.0.1-7 ]#cd [gcc3.3 or gcc4.0] ]#./CreateModule ]#./install.sh

#### 3.1.3 Folder Information

Venus-1.0.1-7.tar.gz				
File name	Directory	Description	Attribute <sup>1)</sup>	
VenusLib.so	/lib	Device Driver library used in eNBSP SDK for Linux	755	
VenusDrv.ko	/lib/modules/\$kernel- version/kernel/drivers/usb/misc/	NITGEN USB Fingkey Hamster Driver Module	644	
VenusDrv.h	/usr/include/linux/	Driver Module header	644	
VenusDrv.conf	/etc/	Device configuration value	666	
Device node	/dev/nitgen0 /dev/nitgen1 /dev/nitgen2 /dev/nitgen3 /dev/nitgen4 /dev/nitgen5 /dev/nitgen6 /dev/nitgen7	Create nodes for the device. Character device node.		

<sup>1)</sup> Default attribute value

#### 3.2 NITGEN USB eNBioScan-F

#### 3.2.1 Package File Name

- nfrd05rf-1.0.0-2.tar.gz : NITGEN USB eNBioScan-F(HFDU05) for Linux

#### **3.2.2** How to install

]#tar -zxvf nfrd05rf-1.0.0-2.tar.gz ]#cd nfrd05rf-1.0.0-2 ]#cd [gcc3.3 or gcc4.0] ]#./CreateModule05 ]#./install.sh

#### 3.2.3 Folder Information

nfrd05rf-1.0.0-2.tar.gz				
File name	Directory	Description	Attribute <sup>1)</sup>	
nfrd05rf.so	/lib	Device Driver library used in eNBSP SDK for Linux	755	
nfrd05rf.ko	/lib/modules/\$kernel- version/kernel/drivers/usb/misc/	NITGEN USB eNBioScan-F Driver Module	644	
nfrd05rf.h	/usr/include/linux/	Driver Module header	644	
nfrd05rf.conf	/etc/	Device configuration value	666	
Device node	/dev/nfrd050 /dev/nfrd051 /dev/nfrd052 /dev/nfrd053 /dev/nfrd054 /dev/nfrd055 /dev/nfrd056 /dev/nfrd057	Create nodes for the device. Character device node.		

#### \* Attribute

Numeral	Character	Meaning
755	rwxr-xr-x	1. owner/group/other
666	rw-rw-rw-	2. r - read w - write
644	rw-rr	x - execute

[End Of Doc]

<sup>1)</sup> Default attribute value