
Desk Lamp

+



Materials:

Copper Tape - 1/4"
Battery - CR2032 - 3v
Transparent Tape
LED - 5mm or 10mm
LilyPad Button Switch
Circuit Stickers (optional)

Tools:

Scissors Scoring Tool X-Acto Knife

Time Required:

30 minutes

Steps:

- Apply copper tape to trace line.
 Smooth with finger.
 Allow a gap for LED and switch
- Fold copper tape at all corners. Try to maintain a continuous strip with no cuts.
- Place battery on top of copper tape with negative (-) facing down.
- Stick end of the copper tape to the top of battery (+)
- Bend legs of LED at a 90' angle.
 Use clear tape to secure LED to copper tape.
 Long leg of LED goes on positive.
- Mount LilyPad switch using clear tape. Make sure there is a gap in the copper tape below switch.
- Optional put the desk lamp overlay on top of circuit.
 The words PRESS should align with LilyPad switch.

Desk Lamp



Makerspaces.com/paper-circuits