Digit	Display	a	b	С	d	е	f	g
0	D	on	on	on	on	on	on	off
1	В	off	on	on	off	off	off	off
2	2	on	on	off	on	on	off	on
3	3	on	on	on	on	off	off	on
4	9	off	on	on	off	off	on	on
5	S	on	off	on	on	off	on	on
6	8	on	off	on	on	on	on	on
7	B	on	on	on	off	off	off	off
8	8	on						
9	9	on	on	on	on	off	on	on