Using BOSS TONE STUDIO for SY-1000

This document explains basic operation of BOSS TONE STUDIO for SY-1000 (subsequently referred to as "TONE STUDIO").

Getting Ready to Use TONE STUDIO

Installing the USB Driver

Before you use TONE STUDIO, the appropriate USB driver for the product you're using must be installed on your computer.

1. From the product support page, download the SY-1000 Driver.

To obtain the latest USB driver, access the following URL, and download the appropriate driver for the product you're using.

http://www.boss.info/support/

2. Double-click the downloaded SY-1000 Driver.

Installation begins.

Proceed with the installation as directed by the installation screens.

When the screen indicates "Installation has been completed." click the [Close] button.

The SY-1000 Driver has been installed on your computer.

Installing TONE STUDIO

MEMO

Before you install TONE STUDIO, the USB driver must be installed in your computer as described in "Installing the USB Driver" (p. 1).

Windows Users

1. Unpack the Zip file.

2. Double-click "BOSS TONE STUDIO for SY-1000 Installer.exe."

Installation begins.

3. Proceed with installation as directed by the install screens.

4. When the screen indicates "Completing the BOSS TONE STUDIO for SY-1000 Setup Wizard," click the [Finish] button.

Mac Users

1. Unpack the Zip file.

2. Double-click "BOSS TONE STUDIO for SY-1000 Installer.pkg."

Installation begins.

3. Proceed with installation as directed by the install screens.

4. When the screen indicates "The installation was successful. The software was installed.," click the [Close] button.

Starting TONE STUDIO

1. Use a USB cable to connect the SY-1000 to your computer, and then turn on the power of the SY-1000.

MEMO

You can edit livesets and download livesets from BOSS TONE CENTRAL even if the SY-1000 is not connected to your computer via a USB cable.

However, you can't save the result of editing a patch. In order to save the edited patch, you'll need to be connected to your computer.

2. In the [Start] menu, choose [All Programs]➡[BOSS TONE STUDIO for SY-1000]➡[BOSS TONE STUDIO for SY-1000].

The first time you start up, the dialog box "Choose a device connect with." appears.

* On the second and subsequent startups, the device is selected automatically.

Mac OS users

From the Finder, in the application/BOSS/SY-1000 folder, double-click [BOSS TONE STUDIO for SY-1000 (.app)].

3. Choose "SY-1000," and click the [OK] button.



TONE STUDIO starts.

MEMO

Since data will be loaded from the SY-1000, it may take some time until you can use TONE STUDIO.

© 2020 Roland Corporation

Editor Basic Screen



1 Patch select area

The patches that are shown differ depending on the mode of the SY-1000 unit.
When switching between guitar mode and bass mode, first switch the mode on the SY-1000 unit, and then restart TONE STUDIO.

2 Function select area

3 [CTL/EXP] button

Click this to access the CONTROL FUNCTION, ASSIGN, PATCH MIDI, CONTROL LED COLOR, and GUITAR TO MIDI (BASS TO MIDI) popup screen.

4 [WRITE] button

Click this to access the WRITE or CLEAR list.

5 Effect select area

Click a block once to select an effect. The parameters of the selected effect are shown at the bottom of the screen. The second and subsequent clicks turn the effect on/off.
The selected block indicates , and you can move the effect by dragging and dropping it.

6 Effect ON/OFF button

7 [VARIATION] button

Click this to access the VARIATION menu.

8 Parameter editing area

Drag the dial of each parameter up or down to edit its value (you can also use the mouse wheel to edit the value).
You can double-click, and then enter a numeric value from your computer keyboard, or directly select a value from a list.
When you click the [TYPE] box, a list appears, allowing you to choose the TYPE.

Editing a Patch

As an example, we'll explain how to edit the user patch "U01-1 DYNAMIC SAW LEAD."

1. At the top of TONE STUDIO screen, click the [EDITOR] button.

2. Click the [USER] button

3. Click the patch that you want to edit. In this example, click "U01-1 DYNAMIC SAW LEAD."



4. In the effect blocks of the effect chain screen (the upper part of the screen), click the effect block that you want to edit.

Here we will click the [REV] block.

A frame is shown on the effect block that you click, and the effect settings are shown in the lower part of the screen.

5. Edit the effect.

- If you want to change the type of reverb, click the [TYPE] box and choose from the list.



- You can also change the placement of the various effect types in the effect chain screen. Drag and drop the effect that you want to move. (You can move it to the location shown in red.)



- You can drag a parameter's dial up or down to edit its value (you can also use the mouse wheel to edit the value). You can also double-click, and then enter a numeric value from your computer keyboard.



6. If you want to edit another effect, repeat steps 4–5.

Saving an Edited Patch to the SY-1000 (WRITE)

Here's how to save the edited patch to the SY-1000.

1. In the upper right of the TONE STUDIO screen, click the [WRITE] button.

2. Click "WRITE."

The "WRITE" dialog box appears.

3. Select the save-destination user patch number.

In this example, select "U01-1."



NOTE

When you save, the user patch of the selected number is overwritten; the original settings cannot be recovered. Select a user patch that you don't mind overwriting.

4. If you want to change the name of the user patch, click the user patch name field. You can use your computer keyboard to enter a user patch name.



5. Click the [WRITE] button.

The settings of the new user patch are saved in TONE STUDIO's patch list and in the SY-1000.



Editing the Controller Settings

Here you can make settings for CONTROL FUNCTION, ASSIGN, PATCH MIDI, CONTROL LED COLOR, and GUITAR TO MIDI(BASS TO MIDI).

1. In the TONE STUDIO screen, click the [CTL/EXP] button.



The controller assignment screen appears.

2. Assign the function.



LIBRARIAN Basic Screen



1 [CREATE LIVESET] button
Press this button to create a new empty liveset.

2 Liveset name
Shows the name of the liveset and the number of patches.

3 Liveset name edit button
Click this to edit the name of the liveset. You can click the trash can symbol to delete the liveset.

4 PATCH name edit button
Click this to edit the name of the patch. You can click the trash can symbol to delete the patch.

5 [Import] button
This lets you import all of the SY-1000 unit's patches into the LIBRARIAN, or import a LIBRARIAN file from your computer into the LIBRARIAN.

6 [Export] button
This lets you export a liveset to the SY-1000 unit, or export a liveset and save it on your computer.

MEMO
TONE STUDIO has a separate LIBRARIAN for guitar mode and bass mode. The LIBRARIAN corresponding to the mode of the connected SY-1000 is shown.

Importing All the SY-1000's User Patches into the LIBRARIAN (Import from SY-1000)

Here's how to import all of the SY-1000's user patches into LIBRARIAN. All user patches are saved as a liveset.

1. In TONE STUDIO screen, click the [LIBRARIAN] button.



2. At the top of the TONE STUDIO screen, click the [Import] button.



3. Click the [ ] button.



The CREATE LIVESET screen appears.



4. Enter the liveset name, and click the [OK] button.

Import begins. If you decide to cancel during the operation, click the [CANCEL] button.

It will take some time to import all of the SY-1000's user patches. When import is finished, the message "Completed." appears.

5. Click the [OK] button.

The user patches are saved as a liveset in the LIBRARIAN.



Exporting a LIBRARIAN Liveset to the SY-1000 (EXPORT TO SY-1000)

Here's how a liveset that you saved can be restored to the SY-1000's user patch.

NOTE

Patches 201 and higher are not restored.

1. At the top of the TONE STUDIO screen, click the [Export] button.



2. From SELECT LIVESET, select the liveset that you want to export.

3. Click the [ ] button.



Export begins. If you decide to cancel during the operation, click the [CANCEL] button.

When export is finished, the message "Completed." appears.

4. Click the [OK] button.

The selected liveset is written back into the SY-1000.

Restoring a Patch to the SY-1000

Here's how to select a patch from a liveset that you saved, and restore it back to the SY-1000.

1. Drag the patch that you want to restore and drop it onto the desired user patch number of the SY-1000.

NOTE

When you drop a patch, it overwrites the user patch of the selected number; the original settings cannot be recovered. Select a user patch that you don't mind overwriting.

In this example, drag and drop the patch "U01-1 DYNAMIC SAW LEAD" onto "U01-3 12STR ORCH*."



On the SY-1000, select user patch "U01-3" and you'll be able to use the restored patch.

MEMO

You can also select multiple patches as described in "Selecting multiple patches" (p. 9).

Saving a Liveset to a Computer (EXPORT TO FILE)

A liveset that you backed up can be exported to your computer (Export).

1. At the top of the TONE STUDIO screen, click the [Export] button.

2. From SELECT LIVESET, select the liveset that you want to export.

3. Click the [FILE] button.

The "Save As" dialog box appears.

4. Enter a name and save-destination, and click the [Save] button.

A liveset file (.tsl) is created at the save-destination.

Ways to use an exported liveset

- Use a USB flash drive to copy the liveset to a different computer.
- Sent the liveset via email to another SY-1000 user.

Importing a Liveset from a Computer into the LIBRARIAN (IMPORT FROM FILE)

A liveset that you exported to a computer can be imported into a TONE STUDIO library (Import).

1. At the top of the TONE STUDIO screen, click the [Import] button.



2. Click the [FILE] button.

The "Open" dialog box appears.

3. Select the liveset file (extension: .tsl) that you want to import into the library, and click the [Open] button.

The liveset is imported into the LIBRARIAN.

Creating an Original Liveset

You can collect your favorite patches to create an original liveset.

1. At the top of the TONE STUDIO screen, click the [CREATE LIVESET] button.



2. Input a name for the liveset.



3. Click the [OK] button.

An empty liveset containing no patches is created.



4. From the patch list at the left of the TONE STUDIO screen, drag and drop your favorite patches into the new liveset.



The selected patches are registered in the new liveset.

MEMO

- A maximum of 300 patches can be registered in one liveset. If inserting patches would cause the liveset to exceed 300 patches, the patches that exceed 300 are not inserted (a message is displayed).
- Patches that are registered in another liveset can also be dragged and dropped into the new liveset.
- You can drag and drop the patches in the liveset to change their order.
- TONE STUDIO lets you create up to 30 livesets. If you want to create and save more than 30 livesets, use the EXPORT TO FILE function to save existing livesets on your computer.

Copying Patches

Here's how to copy a patch to another liveset or to an SY-1000 patch.

1. Click the patch that you want to copy.

MEMO

You can also select and copy multiple patches as described in "Selecting multiple patches" (p. 9).

2. Drag and drop the selected patches onto the desired copy-destination.

NOTE

When you drop the patches, they are overwritten onto the patches of the selected red area, and the original settings cannot be recovered. Select patches that you don't mind overwriting.



MEMO

- If you select non-consecutive patches and copy them, they are copied as successive patches.



- A maximum of 300 patches can be registered in one liveset. If inserting patches would cause the liveset to exceed 300 patches, the patches that exceed 300 are not inserted (a message is displayed).
- Patches that are registered in a liveset can be copied to your own liveset or to a new liveset.

Selecting multiple patches

By using your computer's mouse and keyboard together, you can select multiple patches.

Selecting a range of patches

Here's how to select a range of consecutive patches.

1. Click the first patch that you want to select.

2. While holding down your computer keyboard's [Shift] key, click the last patch that you want to select.

The first through last patches that you click are selected.

Selecting patches individually

Here's how to select just the individual patches that you click.

1. While holding down your computer keyboard's [Ctrl] key, click a patch that you want to select.

The patch you click is selected. The selected patch is highlighted.

Mac OS users

While holding down your computer keyboard's [command] key, click a patch that you want to select.

2. If you want to select other patches, repeat step 1.

If you hold down the [Ctrl] key and click a selected (highlighted) patch once again, the selection is cleared (that patch is no longer highlighted).

The difference between operations when selecting and copying multiple patches

When you drag and drop the selected patches, the copy result will differ depending on your mouse operation.

Drag and drop when a red area is shown at the copy-destination (overwrite copy)



The patches are copied to the area indicated by the red color.

Drag and drop between copy-destination patches (insert)



The patches are inserted at the position of the red line. Subsequent patches are moved backward.

Moving Patches

Here's how to move a patch to another liveset or to an SY-1000 patch. When you move a patch, it disappears from its previous location.

1. Click the patch that you want to move.

MEMO

You can also select and move multiple patches as described in "Selecting multiple patches" (p. 9).

2. While holding down your computer keyboard's [Alt] key, drag and drop the selected patch to the desired copy-destination.

Mac OS users

While holding down your computer keyboard's [option] key, drag and drop.

Deleting Patches

Here's how to delete an unwanted patch.

1. Click the patch that you want to delete.

MEMO

You can also select and delete multiple patches as described in "Selecting multiple patches" (p. 9).

2. Press your computer keyboard's [Delete] key.

The "DELETE PATCH" message appears.



NOTE

Deleted patches cannot be recovered. If you decide not to delete, click the [CANCEL] button.

3. Click the [OK] button.

The selected patches are deleted.

Editing a Liveset Name

1. Click the [⋮] button located at the right of the name of the liveset that you want to edit.





Rearranging Livesets

Here's how to rearrange the livesets that are displayed.

1. Click the liveset that you want to rearrange.

2. Drag and drop the liveset name.

The liveset moves to the position indicated by the red line.



Deleting a Liveset

Here's how to delete a liveset that you no longer need.

1. Click the [⋮] button located at the right of the name of the liveset that you want to delete.



2. Click the [🗑] button.

The "Delete liveset" message appears.



NOTE

The deleted liveset cannot be recovered. If you decide to cancel without deleting, click the [CANCEL] button.

3. Click the [OK] button.

The selected liveset is deleted.

What You Can Do with BOSS TONE EXCHANGE

BOSS TONE EXCHANGE is a sound sharing service that lets users from around the world share the livesets that they have created in BOSS TONE STUDIO.
Here's what you can do with BOSS TONE EXCHANGE.

- Upload and share your livesets to BOSS TONE EXCHANGE.
- Download livesets created by BOSS users from around the world.

MEMO

You must sign in with your Roland account to use BOSS TONE EXCHANGE.

Signing in to BOSS TONE EXCHANGE

1. Click the [TONE EXCHANGE] button.

2. Click "Sign in" at the top of the screen.

3. Enter the e-mail address and password you registered for your Roland account.



* Your computer must be connected to the Internet in order to sign in.

Uploading Livesets to BOSS TONE EXCHANGE

1. Click the [LIBRARIAN] button.

2. Click the [ ] button at the top of the screen.

3. Click and then click the [NEXT] button.

You aren't signed in to BOSS TONE EXCHANGE if "Please SignIn" (Please SignIn) is shown. Sign in to BOSS TONE EXCHANGE.
The app is checking your sign-in status to BOSS TONE EXCHANGE if "Checking" (Checking) is shown, so wait for a little while.

4. Select the liveset you want to upload, and click the [NEXT] button.

5. Input the liveset information, and click "Upload".

This starts the upload.



Downloading Livesets from BOSS TONE EXCHANGE

1. Click the [TONE EXCHANGE] button.

2. Click the product name of the liveset you want to download.

3. Search for a liveset by inputting a keyword or genre.

MEMO

Downloads from BOSS TONE EXCHANGE are done per liveset. Individual memories can't be downloaded, and individual memories can't be added to the library.

4. Select the liveset you want to download, and click the [Download] button.

The liveset is added to LIBRARIAN.

Selecting the Device Controlled by TONE STUDIO

Here's how to select the device controlled by TONE STUDIO.

1. At the top of the TONE STUDIO screen, click the [SYSTEM] button.

The SYSTEM screen appears.



2. Click the [DEVICE SETTING] button.

The "Device" screen appears.

3. Click SELECT DEVICE, and from the list choose [SY-1000].



Saving VARIATION Settings to the Computer (VARIATION DATA BACKUP)

Here's how variation data saved in the SY-1000 can be written to the computer.

1. At the top of the TONE STUDIO screen, click the [SYSTEM] button.

2. Click [VARIATION DATA BACKUP].

The VARIATION DATA BACKUP screen appears.

3. Click the [TO FILE] button.



The "Save As" dialog box appears.

4. Input a name and save-destination, and click the [Save] button.

Export begins. When it is finished, the message "Completed." appears.

5. Click the [OK] button.

A variation file (.vrb file) is created in the save-destination.

Restoring a Saved Variation File from the Computer to the SY-1000 (VARIATION DATA RESTORE)

Here's how a variation file written to the computer can be restored back to the SY-1000.

NOTE

When you restore, the variation data is overwritten, and cannot be returned to its previous settings.

1. At the top of the TONE STUDIO screen, click the [SYSTEM] button.

2. Click [VARIATION DATA BACKUP].

The VARIATION DATA BACKUP screen appears.

3. Click the [FROM FILE] button.



The "Open" dialog box appears.

4. Select the variation file (extension: .vrb) that you want to restore, and click the [Open] button.

Import begins. When it is finished, the message "Completed." appears.

5. Click the [OK] button.

The variation data is restored to the SY-1000.

Saving SY-1000 System Settings to the Computer (SYSTEM DATA BACKUP)

Here's how system settings data saved in the SY-1000 can be backed-up to the computer.

MEMO

Only the data of the current mode is saved to the computer.
If you want to save the data of guitar mode and bass mode, switch modes on the SY-1000 unit, and execute this operation in each mode.

1. At the top of the TONE STUDIO screen, click the [SYSTEM] button.

2. Click [SYSTEM DATA BACKUP].

The SYSTEM DATA BACKUP screen appears.

3. Click the [TO FILE] button.



The "Save As" dialog box appears.

4. Input a name and save-destination, and click the [Save] button.

Export begins.
It will take some time for all data to be exported.
When the operation is finished, the message "Completed." appears.

5. Click the [OK] button.

A system data file (.syb file) is created in the save-destination.

Restoring a System Data File from the Computer to the SY-1000 (SYSTEM DATA RESTORE)

Here's how a system data file previously saved on the computer can be restored to the SY-1000.

NOTE

When you restore, all data is overwritten, and cannot be returned to its previous settings.

1. At the top of the TONE STUDIO screen, click the [SYSTEM] button.

2. Click [SYSTEM DATA BACKUP].

The SYSTEM DATA BACKUP screen appears.

3. Click the [FROM FILE] button.



The "Open" dialog box appears.

4. Select the system data file (extension: .syb) that you want to restore, and click the [Open] button.

Import begins.
Since all data is being imported, this will take some time. When the operation is finished, the message "Completed." appears.

5. Click the [OK] button.

The system settings data are restored to the SY-1000.