# Thinkpad 电池系统

#### 一 概述

Thinkpad 电池系统分为单电池系统和双电池系统。

所谓双电池系统就是机器配备了二块电池。或者,虽然机器只装备了一块电池,但提供了第二块电池的接口以及对应的 ACPI。第二块电池作为可选件,可以后期安装。双电池系统的机器可能有一块电池,也可能有二块电池。

单电池系统是机器配备了一块电池,且只有一块电池的 ACPI。

比如, T470、T470s 的电池结构属于双电池系统; T470P 的电池结构属于单电池系统。

再比如, T430 系列属于双电池系统, 机器本身只有一块电池, 但可以通过光驱位安装第二块电池。

### 二 单、双电池系统判定

ACPI 中同时存在"BAT0"和"BAT1"的即为双电池系统; ACPI 中只有"BAT0",无"BAT1"的即为单电池系统。

## 三 电池补丁和更名

ACPI	单电池系统	双电池系统 一块物理电池	双电池系统 二块物理电池
ВАТ0	√	√	√
BAT1	X	√	√
补丁	本机电池补丁	1 本机电池补丁 2 SSDT-BAT1-disable	1 本机电池补丁 2 SSDT-BATC-TP
更名	_	,	1 选择所有 battery BAT0 2 选择 batC#1 3 选择 batC#2 4 选择 batC#3

注1: 本机电池补丁为对应机器型号的电池补丁。

注 2: 勾选 config\Acpi\Fixes\2\FixMutex。

注 3: "LPC "和 "EC" 控制器名称必须是 LPCB 和 EC,同时注意 ACPI 中是否存在 ECDT 文件,如果有 ECDT 文件,可能需要修正它。见《关于 ECDT 及其修 正方法》。

# 四 示例

(→) T470, T470s:

# 补丁:

 $SSDT\text{-}TP\text{-}bat\_re80\_tx70\_x1c5th\text{-}6th\_s12017\_p51$ 

SSDT-BATC-TP

# 更名:

battery BAT0:GBIF03 to XBIF03

battery BAT0:GBST04 to XBST04

battery BAT0:GBIX03 to XBIX03

battery BAT0:SBMN to BMNX128

battery BAT0:SBDN to BDNX128

```
batC#1
```

batC#2

batC#3

#### (二) T470P:

#### 补丁:

SSDT-TP-bat\_re80\_tx70\_x1c5th-6th\_s12017\_p51

### 更名:

battery BAT0:GBIF03 to XBIF03

battery BAT0:GBST04 to XBST04

battery BAT0:GBIX03 to XBIX03

battery BAT0:SBMN to BMNX128

battery BAT0:SBDN to BDNX128

#### (三) T430S

## 补丁:

SSDT-TP-bat\_wtx20-60\_e40-70\_x1c1th-3th

SSDT-BAT1-disable

# 更名:

battery BAT0:GBIF03 to XBIF03

battery BAT0:GBST04 to XBST04

battery BAT0:GBIX03 to XBIX03

battery BAT0:SBMN to BMNX128

battery BAT0:SBDN to BDNX128

battery BAT1:\_STA to XSTA