PIPER

Mission:

Piper Make Motion Ball

SIDE A
Assembly



Front View

GETTING STARTED
Gather and organize your supplies



Center Base x 1

Caps x 2



Sides x 4



O-Ring x 2

Screws x 2

4-Pin Cable x 1



Sensor x 1

1
Install 2 Screws through the holes



Connect 4-Pin Cable to Sensor

2





Orient the + of Z-axes upwards

3
Attach O-Rings



ASSEMBLY COMPLETE!

Head to Piper Make to continue your mission

make.playpiper.com

INVENTORY

1 Center Base	2 O-Ring	1 4-Pin Cable
4 Sides	1 Sensor	2 1/4" Screws
2 Caps		

Piper Make Motion Ball - Version 2.1.0

PIPER

Mission:

Piper Make Motion Ball

SIDE B

Disassembly



1 ●○○ Remove O-Rings

Place each item on its spot in the clean up box

2 ●●○ Disassemble wood pieces



3 ●●● Remove Screws



Disconnect 4-Pin Cable

DISASSEMBLY COMPLETE!

If not already done, place each piece on its spot in the clean up area below

CLEAN UP

Organize your supplies before storage



Center Base x 1

Caps x 2



Sides x 4



O-Ring x 2

Screws x 2

4-Pin Cable x 1



Sensor x 1

INVENTORY

1 Center Base	2 O-Ring	1 4-Pin Cable
4 Sides	1 Sensor	2 1/4" Screws
2 Caps		