PIPER

Mission:

Piper Make Solar House

SIDE A
Assembly



Front View

Back View

INVENTORY

1 Solar Panel	2 Side Walls
1 Large Roof Panel	4 Nuts
1 Small Roof Panel	4 #4-40 Screws
1 Back Wall	1 Capacitor
1 Front Wall	3 1M ohm Resistors

1 ●○○

Attach Solar Panel to Large Roof piece with velcro



2 ●●○

Assemble house by tilting to slide the notches into slots

3 ●●●

Add both Roof pieces and attach with Screws and Nuts



Place house on top of breadboard

ASSEMBLY COMPLETE!



Head to Piper Make to continue your mission

make.playpiper.com

Piper Make Solar House - Version 1.0.1

PIPER

Mission:

Piper Make Solar House

SIDE B

Disassembly



INVENTORY

1 Solar Panel	2 Side Walls
1 Large Roof Panel	4 Nuts
1 Small Roof Panel	4 #4-40 Screws
1 Back Wall	1 Capacitor
1 Front Wall	3 1M ohm Resistors

1

Remove Screws and Nuts then detach Roof pieces



Place each item on its spot on the Component Sheet

2

Detach Solar Panel



3

Disassemble house by tilting to slide the notches out of slots

DISASSEMBLY COMPLETE!

If not already done, place each piece on its spot in the Component Sheet

Piper Make Solar House - Version 1.0.1

Mission:

Piper Make Solar House

Components Sheet

Gather and organize your supplies