

Operations handbook. The Northfield pump station is maintained by the operations team.

Pressure procedure. The maximum safe operating pressure is 8 bar. The maintenance interval is 30 days. Escalate critical incidents within 15 minutes. Before maintenance, isolate the pump and verify zero pressure on the local gauge.

Maintenance records. Every inspection must be recorded with the date and technician name.