

CheckConnection manual

This program uses the function „GetSerial“ from the GetSerialNum.dll library to check for connection with Datecs devices and retrieve serial number.

GetSerial	
Syntax	function GetSerial(Port,BaudRate,DeviceType, LogicalNumber : integer; var SerialNumber : string) : boolean ; stdcall ;
Description	Returns the serial number for a given device via the SerialNumber parameter.Function result is true if there is connection with the device, false on no connection.
Parameters	Port – serial port number BaudRate – serial port speed DeviceType – index of the device to check (see “Additional notes” on page 2) LogicalNumber – logical number(if any) for the device SerialNumber – string variable, containing the serial number after its successful retrieval.

Additional notes

- ECRs

DeviceType index	Device name
1	DP50
2	DP50D
3	DP50-Ke
4	DP50-Ro
5	DP50D-Ro
6	ER250F
7	MP50
8	MP55
9	MP55-Arm
10	MP55M
11	MP55B
12	MP55M-Yu
13	MP55-Ro
14	MP55L-Ro
15	MP55LD-Ro
16	MP56-Li
17	MP500
18	MP500-La
19	MP500T
20	MP500TR
21	MP500TR-Yu
22	MP500TR-La
23	MP5000
24	MP5000M
25	MP5000-Est
26	MP5000-Mo
27	MP5000-Ro

-Fiscal printers

DeviceType index	Device name
29	FP300
30	FP300-Ke
31	FP3530
32	FP550F-40
33	FP550F
34	FP550F-Mo
35	FP550F-Ro
36	FP550F-Yu
37	FP550F-Ser
39	FP550-Bd
40	FP300-Kz
41	FP1000-Kz
42	FP550-Kz
43	FP 60 Ethiopia
<i>KL devices - Bulgaria</i>	
45	DP 05 KL - Bulgaria
46	DP 15 KL - Bulgaria
47	DP 25 KL - Bulgaria
48	DP 35 KL - Bulgaria
49	DP 50 KL - Bulgaria
50	DP 55 KL - Bulgaria
51	DP 500 KL - Bulgaria
52	MP 55 KL - Bulgaria
53	FP 60 KL - Bulgaria
54	FP 300 KL - Bulgaria
55	FP 1000 KL - Bulgaria
56	FP 2000 KL - Bulgaria