
## Hand-Powered Water Filter

# Detail and Assembly



# **Model 5.01**

Patent Pending

Last Updated January 5, 2018


Christopher Bulkley - Logston

Kaylea Brase


#### Contents

1)	Ultra Filter Detail	2
2)	Check Valve Detail	3
3)	Parts List	4
4)	Pump Assembly	7
5)	Plunger Assembly	?

## 1) Ultra Filter Detail



## 2) Check Valve Detail



## 3) Parts List


No.	Description	Image	QTY	PPU	TOT
A	PVC Tee, $20 \ mm$ plane female $\times$ $20 \ mm$ plane female $\times$ $20 \ mm$ plane female		2	₹8	₹16
В	PVC Pipe Piece, 20 mm diameter, 3 cm long		3	₹1	₹3
С	PVC Adapter, 20 $mm$ plane female $\times$ $^{1}/_{2}$ " threaded male		2	₹8	₹16
D	PVC Reducing Coupler, $20 \ mm$ plane female $\times$ $25 \ mm$ plane female		1	₹8	₹8
E	PVC Pipe Piece, 25 mm diameter, 35 cm long		1	₹10	₹10

No.	Description	Image	QTY	PPU	TOT
F	Brass Check Valve $^{1}/_{2}$ " threaded female $\times$ $^{1}/_{2}$ " threaded female		2	₹110	₹220
G	PVC Nipple $^{1}/_{2}$ " threaded male $\times$ $^{1}/_{2}$ " threaded male		2	₹8	₹16
Н	Quick Connect Fitting $^{1}/_{2}$ " threaded female $\times$ $^{1}/_{4}$ " quick connect female		2	₹45	₹90
I	PVC Pipe Piece 20 mm diameter, 35 cm long		1	₹10	₹10
J	PLA Chamber Plug		1	₹20	₹20


No.	Description	Image	QTY	PPU	TOT
К	Plug O-ring		3	₹5	₹15
L	Quick Connect Tubing  1/4" diameter,  50 cm long		2	₹7	₹14
М	Quick Connect Coupler  1/4" quick connect female ×  1/4" quick connect female		1	₹30	₹30
N	Ultrafilter $^{1}/_{4}$ " quick connect male $\times$ $^{3}/_{8}$ " quick connect male		1	₹600	₹600
Device Total:					₹1068

#### 4) Pump Assembly


Step 01: Insert each of the  $20\ mm$  PVC pipe pieces into the PVC tee.



Step 02: Attach two adapters and a reducing coupler to each of the free ends.




Step 03: Insert the thicker pipe piece into the reducing coupler.




Step 04: Attach a check valve to each open adapter end.



Step 05: Insert a threaded nipple into each check valve.




Step 06: Attach a quick connect fitting to the end of each nipple.




## 5) Plunger Assembly


Step 07: Attach the smaller tee to the smaller pipe.




Step 08: Insert chamber plug into the other end of the smaller pipe.




Step 09: Attach three O-rings to the plug.



Step 10: Insert plunger assembly into pump assembly.



Step 11: Insert RO tubing into inlet and outlet.



Step 12: Attach RO coupling and ultra filter to free end of outlet tube.

