
## Hand-Powered Water Filter

# Detail and Assembly



## Version 5.00

Patent Pending

Last Updated January 5, 2018


Christopher Bulkley - Logston

Kaylea Brase


### Contents

1)	Ultra Filter Detail	2
2)	Check Valve Detail	3
3)	Raw Parts List	4
4)	Check Valve Assembly	7
5)	Pump Assembly	13
6)	Plunger Assembly	20

## 1) Ultra Filter Detail



### 2) Check Valve Detail



### 3) Raw Parts List

No.	Description	Image	QTY	PPU	TOT
A	PVC Pipe Piece, $25 \ mm \ { m diameter}, \\ 50 \ cm \ { m long}$		1	₹15	₹15
В	PVC Adapter, $25~mm$ plane female $\times$ $^{1}/_{2}$ " threaded male		4	₹10	₹40
С	Glass Marble,  1/2" diameter		2	₹2	₹4
D	Small Galvanized Nail, about $25 \ mm$ long		2	₹1	₹2
E	PVC Tee, $25 \ mm$ plane female $\times$ $25 \ mm$ plane female $\times$ $25 \ mm$ plane female		1	₹10	₹10

No.	Description	Image	QTY	PPU	TOT
F	PVC Adapting Coupling, $25~mm$ plane female $\times$ $^{1}/_{2}$ " threaded female		2	₹10	₹20
G	PVC Elbow, $25 \ mm$ plane female $\times$ $25 \ mm$ plane female		1	₹8	₹8
Н	Quick Connect Fitting, $^{1}/_{2}$ " threaded female $\times$ $^{1}/_{4}$ " quick-connect female		2	₹45	₹90
I	PVC Tee, $20 \ mm$ plane female $\times$ $20 \ mm$ plane female $\times$ $20 \ mm$ plane female		1	₹8	₹8
J	PVC Pipe Piece, 20 mm diameter, 33 cm long		1	₹10	₹10

No.	Description	Image	QTY	PPU	тот
K	PLA Chamber Plug		1	₹20	₹20
L	Plug O-ring		3	₹5	₹15
M	Quick Connect Tubing,  1/4" diameter,  50 cm long		2	₹7	₹14
N	Quick Connect Coupler,  1/4" quick-connect female ×  1/4" quick-connect female		1	₹30	₹30
О	Ultrafilter		1	₹600	₹600
			Device	Total:	₹886


#### 4) Check Valve Assembly


Step 01: Sand and cut six pieces from the 50 cm long, 25 mm PVC pipe piece.

P: 1 piece, 35 cm long


**Q:** 2 pieces, each 3 cm long


R: 3 pieces, each 3 cm long






Step 02: Drill a small hole in two of the 30 cm long pipe pieces.









Step 03: Insert each drilled pipe piece into a PVC adapter.




Step 04: Insert a pin into each drilled pipe piece.



Step 05: Insert a marble into each drilled pipe piece.




Step 06: Attach another PVC adapter to the other end of each drilled pipe piece.




#### 5) Pump Assembly


Step 07: Insert two of the remaining pipe pieces into two ends of the  $25 \ mm$  PVC tee.




Step 08: Attach one of the adapting couplings to the bottom piece.




Step 09: Attach the elbow to the other pipe piece.




Step 10: Insert last undrilled pipe piece and adapting coupling into elbow.




Step 11: Insert a check valve into the open end of each coupling adapter.



Step 12: Attach RO fitting to open end of each check valve.




Step 13: Insert the longer 25 mm pipe piece into the tee's last open end.




### 6) Plunger Assembly


Step 14: Attach the smaller tee to the smaller pipe.




Step 15: Insert chamber plug into smaller pipe.




Step 16: Attach three O-rings to the plug.



Step 17: Insert plunger assembly into pump assembly.



Step 18: Insert RO tubing into inlet and outlet.



Step 19: Attach RO coupling and ultra filter to free end of outlet tube.

