

ASIGNMENT-2.3

Q1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

ANS:-

Common USB Keyboard or Mouse Problems and Solutions

1. **Device Not Detected** – The laptop does not recognize the USB keyboard or mouse.
Solution: Unplug the device and reconnect it to another USB port.
2. **Keyboard or Mouse Not Working** – The device suddenly stops responding.
Solution: Restart the laptop and reconnect the USB device.
3. **USB Port Not Working** – The keyboard or mouse works in one port but not another.
Solution: Try a different USB port and check whether the port is working properly.
4. **Cursor Freezes or Moves Slowly** – The mouse cursor becomes unresponsive or moves incorrectly.
Solution: Clean the mouse sensor and use it on a flat, suitable surface.
5. **Keys Not Responding** – Some keyboard keys do not work properly.
Solution: Clean the keyboard and reconnect it; if the problem continues, update or reinstall the keyboard driver.

Q2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

ANS:-

Bluetooth Headphones Not Connecting to Phone – Troubleshooting Steps

1. **Check the headphones:** Make sure the headphones are switched on and have enough battery.
2. **Check Bluetooth:** Open the phone's **Settings** → **Bluetooth** and make sure Bluetooth is turned **ON**.
3. **Check pairing mode:** Put the headphones into **Bluetooth pairing mode** and look for a flashing indicator light or pairing sound.
4. **Check available devices:** In the phone's Bluetooth settings, look under **Available Devices** and select the headphones.
5. **Check the pairing status:** Make sure the headphones show as **Connected** rather than just **Paired**.
6. **Move closer:** Keep the headphones close to the phone, preferably within a few meters, and remove obstacles that may interfere with the connection.
7. **Disconnect other devices:** If the headphones are connected to another phone, laptop, or tablet, disconnect them from that device.
8. **Forget the device:** If the headphones appear in **Paired Devices** but will not connect, tap the headphones' name and select **Forget/Unpair**.
9. **Pair again:** Turn Bluetooth off and on, put the headphones back into pairing mode, and select them again from the available devices list.
10. **Restart both devices:** Restart the phone and turn the headphones off and on again, then try pairing.
11. **Reset the headphones:** If the problem continues, perform the manufacturer's **Bluetooth/factory reset** procedure and try pairing again.
12. **Final check:** Test the headphones with another phone. If they still do not connect, the headphones may have a hardware or battery problem.

Q3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.

ANS:-

Webcam Troubleshooting Checklist – Windows 10

1. **Check the USB connection:** Disconnect and reconnect the webcam, or try a different USB port.
2. **Check Device Manager:** Open **Device Manager** → **Cameras/Imaging Devices** and confirm that the webcam is listed.
3. **Update the driver:** If the webcam has a warning icon, right-click it in Device Manager and select **Update driver**.
4. **Check camera privacy settings:** Go to **Settings** → **Privacy** → **Camera** and turn on camera access.
5. **Check Zoom permissions:** Make sure Zoom is allowed to access the camera and select the external webcam under **Zoom** → **Settings** → **Video**.
6. **Restart and test:** Close Zoom, restart Windows, reconnect the webcam, and test it using the **Camera app** before opening Zoom again.

Q4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

ANS:-

* How to Use Windows Printer Troubleshooter

Steps to Run the Printer Troubleshooter

1. **Open Settings:** Press **Windows + I** on the keyboard.
2. **Open Troubleshooting:**
 - **Windows 10:** Go to **Update & Security** → **Troubleshoot** → **Additional troubleshooters**.
 - **Windows 11:** Go to **System** → **Troubleshoot** → **other troubleshooters**.
3. **Select Printer:** Find **Printer** in the list and click **Run the troubleshooter**.
4. **Select the Printer:** If Windows asks you to choose a printer, select the printer showing **Offline** and click **next**.
5. **Wait for the Diagnosis:** Windows checks the printer connection, drivers, print queue, and related services.
6. **Apply the Recommended Fix:** If a problem is detected, follow the instructions provided by Windows and allow it to apply the suggested fix.
7. **Test the Printer:** After troubleshooting is complete, print a test page to check whether the printer is back **online**.

Information Provided by the Troubleshooter

The troubleshooter provides information about:

- **Printer Connection:** Checks whether the printer is connected through USB or Wi-Fi/network.
- **Print Spooler:** Checks whether the Windows Print Spooler service is running correctly.
- **Printer Status:** Checks whether the printer is paused or set to **Use Printer Offline**.
- **Print Queue:** Detects stuck or pending print jobs that may be preventing printing.

- **Driver Problems:** Checks for problems with the installed printer driver.
- **Final Results:** Shows whether a problem was **Fixed**, **Detected**, or **Not Resolved**, and may provide additional instructions.