Encoders							
C							
Left Dial	Right Dial	Group Speed	Track MIDI Out Channel	Track Velocity	Group Length	Pattern	Select Group
Pots							
Tempo	Note Speed	Save	Swing		Select Group	Volume	Select Transition
Pads							
Mark	Сору	Swap	Copy Group	Swap Groups	Copy Whole Track	Swap Whole Tracks	Accent
Top Left Buttons							
Back	Middle	Select	Bypass	Previous Group	Next Group	Clear Group	Stamp Group
Bottom Left Buttons							
Select	Solo Track	Mute Track	Next Transition	Next Sequence	Clear	Pause	Drum Note
Faders	Image: Control of the	ightharpoons	$\dot{\Box}$	$\dot{\Box}$	Image: Control of the	$\dot{\Box}$	Image: Control of the
Tempo	Note Speed	Save	Swing		Change Group	Volume	Select Transition
Top Right Buttons							
Track 1	Track 2	Track 3	Track 4	Track 5	Track 6	Track 7	Track 8
Bottom Right Buttons							
Track 9	Track 10	Track 11	Track 12	Track 13	Track 14	Track 15	Track 16
Fader	_	Transport					
		Click	Next	Start	Stop	Continue	Unlock

## Notes:

- Faders just replicate the pots
  Change group is replicated a few times for convenience
  Select is replicated for convenience