

If the device has a full-featured USB-C port, please use Method 1 or Method 2.



Method 1



Method 2 (Adapter not included)

If the device does not have a full-featured USB-C port but has an HDMI port, please use Method 3 or Method 4.



Method 3



Method 4 (Adapter not included)

Note: If you use Method 1/3 and your device's battery is low or its voltage is insufficient, the screen may go black, flicker, or become too dim to use. In this case, you will still need to power the portable monitor as shown in Method 2/4.