

Mutaty i

User Manual




一、Product Specifications

- ◆ Color: Black
- ◆ Shell and Frame Material: Aluminum Alloy
- ◆ Resolution: 2560 x 1600
- ◆ Refresh Rate: 144 Hz
- ◆ Brightness: 400 cd/m²
- ◆ Screen Size: 16 inches
- ◆ Aspect Ratio: 16:10
- ◆ Color Depth: 16.7 million colors
- ◆ Contrast Ratio: 1500:1
- ◆ Speakers: Built-in dual speakers
- ◆ Color Gamut: 100% sRGB
- ◆ Viewing Angle: 178°
- ◆ Panel Type: IPS full-viewing angle panel
- ◆ Language Support: Multilingual
- ◆ Dimensions: 35.3 x 22.9 x 1 cm (0.5 cm at the thinnest point)

二、Package Contents

- ◆ Portable Monitor x 1
- ◆ USB-C to USB-C charging cable x 1
- ◆ USB-C to USB-C full-function cable x 1
- ◆ HDMI to Mini HDMI cable x 1
- ◆ Power Adapter x 1
- ◆ User Manual x 1
- ◆ Protective Case x 1

三、Button Overview



- ◆ **3.5 mm Jack:** Headphone/speaker extension port.
- ◆ **Menu:** Enter the system menu or confirm a selection.
- ◆ **Volume:** Normally, it functions as an up/down scroll key. Pressing the left or right side, however, serves as a shortcut.
 - A. Press the left side to quickly adjust the volume.
 - B. Press the right side to quickly adjust the brightness.
- ◆ **Back/Power:** Short press to go back; press and hold for 3 seconds to turn the power on or off.
- ◆ **USB-C(Power Port):** For charging only. Support maximum 20V voltage input.
- ◆ **Mini HDMI:** Transmits audio and video signals.
- ◆ **Full-Featured USB-C Port:** Supports high-speed data transfer, video transmission, and fast charging.

四、Button Operation

◆ Press and hold the POWER/BACK button for 3 seconds to turn the monitor on/off.

◆ Press the MENU button to open the monitor's OSD menu. In the menu, use the VOLUME +/- buttons to navigate up and down. Press the MENU button to confirm. To go back, press the POWER/BACK button briefly.

◆ Normally, you don't need to press the menu button. Just press the left or right side of the VOLUME +/- button to quickly access volume or brightness adjustment.

五、What's the full-featured USB-C port

◆ A Full-Featured USB-C port is a Type-C connector that supports three core functions at the same time: USB data transfer, USB-PD power delivery, and DisplayPort Alternate Mode (DP-Alt Mode) for video/audio output.

◆ Such as USB 3.1 Gen2 Type-C with DP-Alt Mode、USB 3.2 Type-C with DP-Alt Mode、USB4 Type-C、Thunderbolt 3/4 /5.

◆ Some full-featured USB-C port icons are shown below.



六、Connection Overview

(1)、If the device has a full-featured USB-C port :



Method 1



Method 2

Note:

- 1、 The display has two USB-C ports. The one in the middle is a full-function port, and the other is a charging-only port. When you use a full-function cable for a single-cable connection, make sure to connect it to the full-function port, not the charging port.
- 2、 There are two pieces USB-C to USB-C cables: the thicker one is a full-function cable, and the thinner one is a charging-only cable.

3、 If you use Method 1 and your device's battery is low or its voltage is insufficient, the screen may go black, flicker, or become too dim to use. In this case, you will still need to power the portable monitor as shown in Method 2.

(2)、 If the device does not have a full-featured USB-C port but has an HDMI port, ...



Method 3:

七、 How to Use the Leather Case

Step 1: Unfold the leather case



Step 2: Flip the leather case to the back.

Turn the holster inside out, and make sure this part is snug against the back of the holster.



Step 3: Press in from the crease on the back.

It has magnets here, you need to stick it closely to the back for it to work as a stand to support the portable display.




八、Display Screen Functions


(1) Mirror/Expand/Main Display



A: Mirror Mode



B: Extended Mode




C:Main Display (Only primary screen active)

(2) Settings

A: Windows

- ✧ Right-click the desktop and select **Display settings**.
- ✧ Scroll down to the **Multiple displays** section.
- ✧ To select a different display mode, choose **Duplicate these displays**, **Extend these displays**, or **Show only on 2**.


Multiple displays



B: MacOS

- ✧ Choose Apple menu > System Preferences, then click **Displays**.
- ✧ Click the **Arrangement** tab.

- ✧ For **Extend Mode**, make sure the **Mirror Displays** checkbox is not selected. For **Mirror Mode**, make sure it is selected.




C: How to extend a second screen to the left?

- ✧ Press and hold the left mouse button, drag the display icon to the left of the other display icon, and release the mouse button.
- ✧ Click **Apply**

Rearrange your displays


Select a display below to change the settings for it. Press and hold (or select) a display, then drag to rearrange it.



(3) Vertical Mode


A: Windows

- ✧ Right-click the desktop and select **Display settings**.
- ✧ Scroll down to the **Display orientation** option.
- ✧ Select **Landscape** or **Portrait**.



B: Mac OS

- ✧ Choose Apple menu > System Preferences.
- ✧ Hold down the Command and Option (Alt) keys, then click **Displays**.
- ✧ Look for the newly visible **Rotation** drop-down menu.



九、Troubleshooting

1. The monitor flickers frequently, restarts repeatedly, or becomes too dim.

These are usually caused by insufficient power. If this happens, connect portable monitor to an power source.

2. Black Screen or No Signal

A. Use the original cable.

B. If you are using a full-featured single-cable connection, make sure you connect to the full-featured USB-C port on the portable monitor, not the power-only USB-C port.

C. Regardless of the connection type, if your device's battery is low or its voltage is insufficient, you still need to connect the power cable to the portable monitor.

3. My phone has a USB-C port but does not respond after connecting to the monitor

A. Some phones' USB-C ports only support charging, not display output. The portable monitor only supports phones with a full-featured USB-C port (Thunderbolt 3/4/5 or a USB 3.1 USB-C port with DP Alt Mode).

B. If your phone has a full-featured port, it may not provide enough power to the monitor. In this case, connect the portable monitor to power source.

4. **Compatible Devices**

Mobile phones、 laptops、 desktop computers、 tablet、 steam deck、 switch、 PS3/4/5、 Xbox、 game consoles etc..