

SENSORS FOR MASS FLOW AND PRESSURE

How to use strings to communicate directly with a RS232 com port

"send" or "request " commands can be send to a MBC (Digital Mass Flow Controller with integrated RS232 interface) by means of text files.

In this document an example using HyperTerminal is described.

Start the HyperTerminal program.



- Give a name for the connection, f.i. 'test'.
- Select the RS232 com port where the MBC is connected.






SENSORS FOR MASS FLOW AND PRESSURE

- Set the Properties of the com port.
- RS232 / Flowbus interface
 All versions → 38400 Baud
- MBC (Digital Mass Flow Controller with integrated RS232 interface)


Firmware < V6.16 \rightarrow 19200 Baud

Firmware \geq V6.16 \rightarrow 38400 Baud



Test the communication

- At power up of the MBC the MBC sends an identification string to the RS232 port.
- Please check if the identification string is displayed in Hyper Terminal.






SENSORS FOR MASS FLOW AND PRESSURE

Send / write Setpoint 100%

- Select "Transfer" → "Send text file"



- Select the file "writesp100.txt "

