

Product specification Robot user documentation, IRC5 with RobotWare 6



Trace back information:
Workspace R17-1 version a8
Checked in 2017-03-29
Skribenta version 5.1.011

Product specification Robot user documentation, IRC5 with RobotWare 6

Document ID: 3HAC052355-001

Revision: G

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damages to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2017 ABB. All rights reserved.

ABB AB, Robotics

Robotics and Motion

Se-721 68 Västerås

Sweden

Table of contents

	Over	view of this specification	7
1	Intro	duction	9
	1.1 1.2 1.3 1.4	Easy-to-use information products User documentation package Types of manuals Languages and article numbers	10 11
2	Robotics user manuals		15
	2.1 2.2 2.3 2.4 2.5	DVD documentation Operating manuals Technical reference manuals Application manuals Product manuals	15 16 18 19 22



Overview of this specification

About this product specification

This specification lists all active user documentation for ABB Robotics products with RobotWare 6.

Revisions

Revision	Description
-	Released in October 2014, R14.2. First release.
Α	Released in April 2015, R15.1.
В	Released in October 2015, R15.2.
С	Released in December 2015, R15.2.
D	Released in March 2016, R16.1.
E	Released in June 2016, R16.1+.
F	Released in October 2016, R16.2.
G	Released in March 2017, R17.1. The list of product specifications is removed. The product specifications are no longer part of the user documentation package.



1.1 Easy-to-use information products

1 Introduction

1.1 Easy-to-use information products

Introduction to Robot User Documentation

The Robot User Documentation is aimed at all robot users, providing easy to use information and guidelines as well as in-depth descriptions and detailed reference literature. There is a robot user document for each stage of use, from installation and commissioning, through programming, operation and maintenance, to troubleshooting and decommissioning of your robot system.

ABB's group of skilled editors provide professional user documentation, ensuring efficient communication of robot expertize, from our engineers to your personnel.

Key benefits

- · Easy-to-use user documentation
- In-depth reference information
- · Detailed product information
- · Maintenance and service procedures

1.2 User documentation package

1.2 User documentation package

Introduction

The documentation package includes the user documentation for all standard robotics products. The robot user documentation is translated into 18 languages, including a number of Asian languages. Documents that are not translated are available in English.

Updates of the documentation package are released at every major product change (manipulators, controllers, and RobotWare).

The robot user documentation is available in RobotStudio for users with Premium license, and can be ordered on a DVD.

Updated versions of all user documentation can be found on the ABB intranet, in ABB Library (inside.abb.com/library). ABB Library is a fast and easy way to find updated robot information and can be accessed by all ABB employees. Some integrators and customers also have access to online documentation on MyABB (www.abb.com/myabb).

Ordering the DVD

The robot user documentation DVD is ordered using the standard Robot Specification form.



Note

There are three packages available. See *DVD documentation on page 15*.

Help for searching the DVD faster

All files on the DVD can be searched in one operation in Adobe Acrobat. To search all files takes quite a long time, but you can create an index to make it faster to search the next time. How to set up an index is described in Adobe Acrobat Help (press F1 in Acrobat).

Printed manual

There is one manual that is delivered also as a printed version together with the robot system. The manual is *Operating manual - Emergency safety information*, which is translated into 18 languages.

1.3 Types of manuals

1.3 Types of manuals

Operating manuals

The *operating manuals* are directed to persons with first hand contact with the robot system, that is production operators, programmers, and service personnel.

Technical reference manuals

The technical reference manuals include reference information for the products.

The technical reference manuals for RAPID and system parameters describe the controller software. The manuals include syntax and detailed information on instructions, functions, and data types in the RAPID language and on system parameters.

Application manuals

The application manuals describe RobotWare base functionality and options, directed to specific applications, such as RobotWare Arc, Spot, Dispense, Integrated Vision. The content includes:

- · Purpose of the option: For what is the option intended?
- What is included in the option, for example RAPID instructions, system parameters.
- Which hardware is required, for example cables and I/O boards.
- Setup, programming, and configuration examples.

Product manuals

There is a product manual for each robot and controller. The content includes:

- · Safety information
- · Installation and commissioning
- Maintenance (maintenance schedules and preventive maintenance routines)
- Repair (lists of spare parts and repair procedures)
- · Calibration procedures
- Decommissioning procedures
- · Reference information
- Part list or reference to separate spare part list
- · Foldouts or exploded views
- · References to circuit diagrams

Product specifications

There is a *product specification* for each product. The content varies depending type of product but usually includes:

- Description
- Variants and options

1.3 Types of manuals Continued



Note

The product specifications are removed from the documentation package in release R17.1, RobotWare 6.05.

1.4 Languages and article numbers

Article numbers

The article number for a manual or the documentation DVD is the same for all languages except for the subnumber (language code).

Example:

Article number	Title
3HAC047136-001	Product manual - IRC5
3HAC047136-003	Product manual - IRC5
Product manual - IRC5 IRC5 with main computer DSQC1000.	3HAC047136-001

Language codes

The manuals are available in the following languages (with matching subnumber).

Language code		Subnumber	
English	en	1	001
Swedish	sv	2	002
German	de	3	003
French	fr	4	004
Spanish	es	5	005
Portugese	pt	6	006
Italian	it	7	007
Danish	da	8	008
Dutch	nl	9	009
Chinese (simplified)	zh or zh-cn	10	010
Korean	ko	11	011
Japanese	ja	12	012
Finnish	fi	13	013
Czech	cs or cz	14	014
Polish	pl	15	015
Russian	ru	16	016
Hungarian	hu	17	017
Turkish	tr	18	018
Slovenian	sl	19	019



2.1 DVD documentation

2 Robotics user manuals

2.1 DVD documentation

Article numbers

The documentation DVD contains all languages.

Title	Article number	Option number
DVD documentation, DSQC 639 with RobotWare 5.15.xx i	3HAC032875-001	808-1
DVD documentation, DSQC1000 with RobotWare 5.6x i	3HAC048193-001	808-1
DVD documentation, DSQC1000 with RobotWare 6	3HAC052153-001	808-1

i The user documentation for RobotWare 5 is described in Product specification - Robot user documentation, IRC5 with RobotWare 5.

2.2 Operating manuals

2.2 Operating manuals

Article numbers

Title	Article number
Operating manual - Emergency safety information (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Hungarian, Turkish, Slovenian)	3HAC027098-001
Operating manual - General safety information (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Turkish, Slovenian)	3HAC031045-001
Operating manual - Getting started, IRC5 and RobotStudio (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Turkish, Slovenian)	3HAC027097-001
Operating manual - IRC5 with FlexPendant (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Turkish, Slovenian)	3HAC050941-001
Operating manual - IRC5 with T10 (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Turkish, Slovenian)	3HAC050943-001
Operating manual - IRC5 Integrator's guide (English)	3HAC050940-001
Operating manual - RobotStudio (English, German, French, Spanish, Italian, Chinese, Japanese)	3HAC032104-001
Operating manual - Trouble shooting IRC5 (English, Swedish, German, French, Spanish, Portuguese, Italian, Danish, Dutch, Chinese, Korean, Japanese, Finnish, Czech, Polish, Russian, Turkish, Slovenian)	3HAC020738-001
Operating manual - Calibration Pendulum (English, German, French, Spanish, Italian, Chinese, Korean)	3HAC16578-1
Operating manual - IRB 14000 (English, German, French, Spanish, Italian, Chinese, Japanese)	3HAC052986-001
Operating manual - Service Information System (English, German, French, Spanish, Italian)	3HAC050944-001
Operating manual - IRBP /D2009 (English, German, French, Spanish, Italian)	3HAC038435-001
Introduction and Safety - Arc Welding Products (English, Swedish, German, French, Spanish, Italian, Dutch)	3HEA801212-001
Operating manual - Seam tracking with Weldguide III and MultiPass	3HEA802921-001
(English, German, French, Spanish, Italian)	

2.2 Operating manuals Continued

Title	Article number
Operating manual - Seam tracking with Weldguide IV and MultiPass	3HAC054886-001
(English, German, French, Spanish, Italian)	
Operating Manual - ArcWelding PowerPac (English)	3HAC028931-001
Operating manual - Machining PowerPac - CAM Converter Functionality (English)	3HAC050262-001
Operating manual - Machining PowerPac (English)	3HAC030420-001
Operating manual - Machining PowerPac - Machining Functionality (English)	3HAC054781-001
Operating manual - Palletizing PowerPac (English)	3HAC042340 -1
Operating manual - RobotWare Machine Tending (English)	3HAC044397-001
Operating manual - RobotWare Machine Tending (English)	3HAC044397-001
Operating manual - Tracking and searching with optical sensors (English)	3HAC055269-001

2.3 Technical reference manuals

2.3 Technical reference manuals

Article numbers

Title	Article number
Technical reference manual - RAPID Instructions, Functions and Data types	3HAC050917-001
(English, German, French, Spanish, Italian, Chinese)	
Technical reference manual - RAPID kernel (English, Chinese)	3HAC050946-001
Technical reference manual - RAPID overview (English, German, French, Spanish, Italian, Chinese)	3HAC050947-001
Technical reference manual - System parameters (English, German, French, Spanish, Italian, Chinese)	3HAC050948-001
Technical reference manual - Lubrication in gearboxes (English, German, French)	3HAC042927-001

2.4 Application manuals

Hardware options

Title	Article number
Application manual - Additional axes and stand alone controller (English)	3HAC051016-001
Application manual - Electronic Position Switches (English, German, French, Spanish, Italian)	3HAC050996-001
Application manual - Functional safety and SafeMove (English, German, French, Spanish, Italian)	3HAC052610-001
Application manual - SafeMove (English, German, French, Spanish, Italian)	3HAC050974-001

Fieldbus and industrial network options

Title	Article number
Application manual - DeviceNet Master/Slave (English, German)	3HAC050992-001
Application manual - DeviceNet Anybus Slave (English, German)	3HAC050993-001
Application manual - EtherNet/IP Anybus Adapter (English, German)	3HAC050997-001
Application manual - EtherNet/IP Scanner/Adapter (English, German)	3HAC050998-001
Application manual - Local I/O (English, German)	3HAC059109-001
Application manual - PROFIBUS Anybus Device (English, German)	3HAC050965-001
Application manual - PROFIBUS Controller (English, German)	3HAC050966-001
Application manual - PROFlenergy Device (English, German)	3HAC050967-001
Application manual - PROFINET Anybus Device (English, German)	3HAC050968-001
Application manual - PROFINET Controller/Device (English, German)	3HAC050969-001

RobotWare options

Title	Article number
Application manual - Continuous Application Platform (English)	3HAC050990-001
Application manual - Controller software IRC5 (English, German, Chinese)	3HAC050798-001

2.4 Application manuals *Continued*

Title	Article number
Application manual - Conveyor tracking (English, German)	3HAC050991-001
Application manual - Discrete application platform (English)	3HAC050994-001
Application manual - Force Control (English)	3HAC050377-001
Application manual - Integrated Vision (English, German, French, Spanish, Chinese, Japanese)	3HAC044251-001
Application manual - MultiMove (English, German, French, Spanish, Italian, Chinese)	3HAC050961-001
Application manual - PickMT (English, Swedish)	3HAC051771-001
Application manual - PickMT FeedLine Light (English, Swedish)	3HAC052311-001
Application manual - PickMT integration with ABB robot (English, Swedish)	3HAC051770-001
Application manual - SoftMove (English)	3HAC050977-001
Application manual - Production Screen (English)	3HAC050964-001
Application manual - Tool change support (English)	3HAC050980-001

PC software

Title	Article number
Application manual - PickMaster 3 (English, German, French, Spanish, Italian, Japanese)	3HAC031978-001
Application manual - PickMaster 5 (English)	3HAC025829-001
Application manual - IRC5 OPC Server help (English)	3HAC023113-001

Arc welding

Title	Article number
Application manual - Arc and Arc Sensor (English, German)	3HAC050988-001
Application manual - BullsEye (English, German)	3HAC050989-001
Application manual - Laser Tracker Calibration Interface (English)	3HAC050957-001
Application manual - Lincoln ArcLink Interface and Weld Editor (English)	3HAC049194-001

2.4 Application manuals Continued

Title	Article number		
Application manual - Miller Ethernet I/P Interface and Weld Editor	3HAC054885-001		
(English)			
Application manual - Navigator (English)	3HAC050962-001		
Application manual - Production Manager (English)	3HAC052855-001		
Application manual - Production Monitor (English)	3HAC026810-001		
Application manual - Programming Integrated Power Source (English)	3HAC050972-001		
Application manual - Programming ABB RPC S-series Integrated Power Source (English, Chinese)	3HAC050970-001		
Application manual - Programming Fronius power source (English)	3HAC050971-001		
Application manual - Signal description for arc welding products (English)	3HAC050975-001		
Application manual - SKS Interface with Feldbus 5 (English, German)	3HAC054884-001		
Application manual - SmarTac (English, German)	3HAC024845-001		
Application manual - Torch services (English)	3HAC050981-001		
Application manual - Weld Data Monitor (English)	3HAC050983-001		

Spot welding

Title	Article number
Application manual - Mechanical Unit Manager (English)	3HAC050959-001
Application manual - Servo gun tuning (English)	3HAC026820-001
Application manual - Spot options (English, German)	3HAC050979-001
Application manual - Tool change support (English)	3HAC050980-001

Dispense

Title	Article number
Application manual - Dispense (English, German)	3HAC050995-001

2.5 Product manuals

2.5 Product manuals

Controllers

Title	Article number
Product manual - IRC5 (English, German, French, Spanish, Italian, Japanese, Russian)	3HAC047136-001 IRC5 of design 14, main computer DSQC1000/1018
Product manual - IRC5 Compact (English, German, French, Spanish, Italian, Chinese)	3HAC047138-001 IRC5 of design 14, main computer DSQC1000/1018
Product manual - IRC5 Panel Mounted Controller (English, German, French, Spanish, Italian)	3HAC047137-001 IRC5 of design 14, main computer DSQC1000/1018

Manipulators

Title	Article number			
Product manual - IRB 120 (English, German, French, Spanish, Italian, Chinese, Japanese)	3HAC035728-001			
Product manual, spare parts - IRB 120 (English)	3HAC049098-001			
Product manual - IRB 140 (English, German, French, Spanish, Italian, Japanese)	3HAC027400-001			
Product manual, spare parts - IRB 140 (English)	3HAC049099-001			
Product manual - IRB 260 (English, German, French, Spanish, Italian)				
Product manual, spare parts - IRB 260 3HAC049100-001 (English)				
Product manual - IRB 360 (English, German, French, Spanish, Italian)	3HAC030005-001			
Product manual, spare parts - IRB 360 (English)	3HAC049101-001			
Product manual - IRB 460 (English, German, French, Spanish, Italian, Chinese)	3HAC039842-001			
Product manual, spare parts - IRB 460 (English)	3HAC040628-001			
Product manual - IRB 660 (English, German, French, Spanish, Italian, Russian)	3HAC025755-001			
Product manual, spare parts - IRB 660 (English)	3HAC049102-001			
Product manual - IRB 760 (English, German, French, Spanish, Italian)	3HAC039838-001			
Product manual, spare parts - IRB 760 (English)	3HAC040446-001			

2.5 Product manuals Continued

Title	Article number		
Product manual - IRB 1200 (English, German, French, Spanish, Italian, Chinese)	3HAC046983-001		
Product manual, spare parts - IRB 1200 (English)	3HAC046984-001		
Product manual - IRB 1410 (English, German, French, Spanish, Italian, Chinese, Korean)	3HAC026320-001		
Product manual, spare parts - IRB 1410 (English)	3HAC049103-001		
Product manual - IRB 1520 (English, German, French, Spanish, Italian, Chinese)	3HAC043435-001		
Product manual, spare parts - IRB 1520 (English)	3HAC043436-001		
Product manual - IRB 1600/1660 (English, German, French, Spanish, Italian, Polish)	3HAC026660-001		
Product manual, spare parts - IRB 1600/1660 3HAC049104-00 (English)			
Product manual - IRB 2400 (English, German, French, Spanish, Italian)	3HAC022031-001		
Product manual, spare parts - IRB 2400 (English)	3HAC049105-001		
Product manual - IRB 2600 (English, German, French, Spanish, Italian)	3HAC035504-001		
Product manual, spare parts - IRB 2600 (English)	3HAC049106-001		
Product manual - IRB 4400 (English, German, French, Spanish, Italian)	3HAC022032-001		
Product manual, spare parts - IRB 4400 (English)	3HAC049107-001		
Product manual - IRB 4600 (English, German, French, Spanish, Italian, Japanese)	3HAC033453-001		
Product manual - IRB 4600 Foundry Prime (English, German, French, Spanish, Italian)	3HAC040585-001		
Product manual, spare parts - IRB 4600 (English)	3HAC049108-001		
Product manual - IRB 6620 (English, German, French, Spanish, Italian)	3HAC027151-001		
Product manual, spare parts - IRB 6620 (English)	3HAC049109-001		
Product manual - IRB 6620LX (English, German, French, Spanish, Italian)	3HAC035737-001		
Product manual, spare parts - IRB 6620LX (English)	3HAC049110-001		

2.5 Product manuals *Continued*

Title	Article number		
Product manual - IRB 6640 Foundry Prime (English, German, French, Spanish, Italian)	3HAC040586-001		
Product manual, spare parts - IRB 6640 (English, German)	3HAC038330-001		
Product manual - IRB 6650S (English, German, French, Spanish, Italian)	3HAC020993-001		
Product manual, spare parts - IRB 6650S (English)	3HAC049111-001		
Product manual - IRB 6660 (English, German, French, Spanish, Italian)	3HAC028197-001		
Product manual, spare parts - IRB 6660 (English)	3HAC049112-001		
Product manual - IRB 6700 (English, German, French, Spanish, Italian)	3HAC044266-001		
Product manual - IRB 6700Inv (English, German, French, Spanish, Italian)			
Product manual, spare parts - IRB 6700 (English, German, French, Spanish, Italian)	3HAC044268-001		
Product manual - IRB 7600 (English, German, French, Spanish, Italian)	3HAC022033-001		
Product manual, spare parts - IRB 7600 (English)	3HAC049113-001		
Product manual - IRB 8700 (English, German, French, Spanish, Italian)	3HAC052853-001		
Product manual, spare parts - IRB 8700 (English, German, French, Spanish, Italian)	3HAC052854-001		
Product manual - IRB 910SC (English)	3HAC056430-001		
Product manual, spare parts - IRB 910SC (English)	3HAC056433-001		
Product manual - IRB 14000 (English, German, French, Spanish, Italian, Chinese, Japanese)	3HAC052983-001		
Product manual, spare parts - IRB 14000 (English, German, French, Spanish, Italian, Chinese, Japanese)	3HAC052984-001		
Product manual - Gripper IRB 14000 (English, German, French, Spanish, Italian, Chinese)	3HAC054949-001		
Product manual - IRBP /D2009 (English, German, French, Spanish, Italian)	3HAC037731-001		
Product manual, spare parts - IRBP /D2009 (English)	3HAC038416-001		
Product manual - IRBT 2005 (English, German, French, Spanish, Italian, Chinese)			

2.5 Product manuals Continued

Title	Article number
Product manual, spare parts - IRBT 2005 (English)	
Product manual - IRBT 4004/6004/7004/IRT 104 (English, German, French, Spanish, Italian)	3HAC028506-001
Product manual, spare parts - IRBT 4004/6004/7004 (English, German, French, Spanish, Italian)	3HAC042864-001

Other hardware

Title	Article number		
Product manual - DressPack/SpotPack IRB 6620 3HAC027309-001 (English, German, French, Spanish, Italian)			
Product manual - DressPack/SpotPack IRB 6620LX (English, German, French, Spanish, Italian)	3HAC055327-001		
Product manual - DressPack/SpotPack IRB 6640 (English, German, French, Spanish, Italian)	3HAC028638-001		
Product manual - DressPack/SpotPack IRB 6650S 3HAC055424-001 (English, German, French, Spanish, Italian)			
Product manual - DressPack/SpotPack IRB 6700 (English, German, French, Spanish, Italian)	3HAC044270-001		
Product manual - DressPack/SpotPack IRB 7600 (English, German, French, Spanish, Italian)	3HAC056372-001		
Product manual - DressPack/SpotPack IRB 8700 (English, German, French, Spanish, Italian)	3HAC055802-001		
Product manual - FlexMT (English)	3HAC051768-001		
Product manual - FlexPLP IRPLP220 (English)	3HAW050041018-001		
Product manual - Safety center for FlexMT (English)	3HAC051769-001		
Product manual - Arc welding equipment for IRB 1520ID (English, German, French, Spanish, Italian, Chinese)			
Product manual - Motor Units and Gear Units (English, German, French, Spanish, Italian, Chinese)			
Assembly Instructions - Torch Cleaner (TC 2013) / Torch Service Centre (TSC 2013) (English, German)	3HDA000057A8519-001		

Contact us

ABB AB, Robotics Robotics and Motion S-721 68 VÄSTERÅS, Sweden Telephone +46 (0) 21 344 400

ABB AS, Robotics Robotics and Motion Nordlysvegen 7, N-4340 BRYNE, Norway Box 265, N-4349 BRYNE, Norway Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd. Robotics and Motion No. 4528 Kangxin Highway

PuDong District
SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc. Robotics and Motion 1250 Brown Road Auburn Hills, MI 48326 USA

Telephone: +1 248 391 9000

www.abb.com/robotics

