


LED REFERENCE CHART

| | Red (Camera) | Blue (DVR) | Yellow (DVR) | Vibrate (DVR) |
|------------------------------|-----------------|---------------------|-------------------|--------------------|
| Power and Record | | | | |
| Powering On | - | Alternating Flash | 1 pulse | |
| Event Recording | On | - | - | 1 pulse/15 seconds |
| Standby or Standby Pre-Event | Off | - | - | - |
| Memory Alerts | | | | |
| 15 minutes remaining | - | - | 1 flash/5 seconds | 1 pulse/5 seconds |
| Battery Alerts | | | | |
| 15% Charge remaining | - | 2 flashes/5 seconds | - | 2 pulses/5 seconds |
| Charge in Progress | - | Flash | - | - |
| Charging Complete | - | On | - | - |
| Data Transfer | | | | |
| Transfer in Progress | - | - | Flash | - |
| Transfer complete | - | - | On | - |
| VuLink | | | | |
| Connected to VuLink | - | - | On | - |
| Error | - | 3 flashes/5 seconds | | 3 pulses/5 seconds |

CONFIGURE YOUR FIRSTVU HD

The FirstVu HD is configured through VuVault or the Mini Configuration Manager software. Please consult your Operation Guide.



SUPPORT@DIGITALALLYINC.COM
800.440.4947 | 913.814.7774



CHARGING THE BATTERY

The FirstVu HD must be fully charged before initial use. Insert the battery into the FirstVu HD and connect one of the battery chargers. Charge the unit initially for 12-16 hours with the unit powered off. Refer to the Operation Guide for more information.

POWERING ON & OFF ①

Slide the master power switch to the ON position. The unit will vibrate once and the BLUE & YELLOW status indicators will flash in unison every 3 seconds to indicate it is powering on. To power off, stop recording then slide the switch to the OFF position.

RECORDING ②

Press the RECORD / MARK button to start a recording. Press and hold for approximately 3 seconds to stop the recording.

MARKING EVENTS ②

While recording, press the RECORD / MARK button once to insert a Mark into the event. You may insert as many marks as you wish.

MUTING THE AUDIO ③

Audio is active when the switch is in the UP (green) position. Audio can be muted by moving the switch into the DOWN position.