MODE	Nilai	Fungsi
00	0x0	Input Mode
01	0x1	Output 10 MHz
10	0x2	Output 2 MHz
11	0x3	Output 50 MHz
CNF	Nilai	Mode
00	0x0	Push-Pull
01	0x1	Open-Drain
10	0x2	Input Floating
11	0x3	Input Pull-up/down