LABORATORY 10

Họ tên: Vũ Quốc Bảo MSSV: 20225694

Assignment 1:

```
.eqv SEVENSEG LEFT 0xFFFF0011 # Dia chi cua den led 7 doan trai.
# Bit 0 = \text{doan a};
# Bit 1 = doan b: ...
# Bit 7 = dau.
.eqv SEVENSEG RIGHT 0xFFFF0010 # Dia chi cua den led 7 doan phai
.data
n0: .byte 63
n1: .byte 6
n2: .byte 91
n3: .byte 79
n4: .byte 102
n5: .byte 109
n6: .byte 125
n7: .byte 7
n8: .byte 127
n9: .byte 111
.text
main:
            # Khởi tao biến đếm $t1
li $t1, 0
li $v0, 32
li $t0, SEVENSEG RIGHT
beg $t1, 10, loop2 # Nếu đã hiển thi hết các giá tri từ n0 đến n9 thì thoát khỏi vòng lặp
lb $a0, n0($t1) # Lấy giá tri tương ứng với $t1 (tức là n0, n1, n2,...)
jal SHOW 7SEG RIGHT # Hiển thị giá trị lấy được
li $a0, 1000
syscall
nop
addi $t1, $t1, 1 # Tăng biến đểm để lấy giá trị tiếp theo
j loop1
loop2:
addi $t1, $t1, -1 # Tăng biến đếm để lấy giá trị tiếp theo
blt $t1, 0, loop2 # Nếu đã hiển thị hết các giá trị từ n0 đến n9 thì thoát khỏi vòng lặp
lb $a0, n0($t1) # Lấy giá tri tương ứng với $t1 (tức là n0, n1, n2,...)
jal SHOW 7SEG RIGHT # Hiển thị giá trị lấy được
li $a0, 1000
syscall
```

```
nop
j loop2
nop
exit: li $v0, 10
syscall
endmain:
#-----
# Function SHOW 7SEG LEFT: turn on/off the 7seg
# param[in] $a0 value to shown
# remark $t0 changed
#-----
SHOW 7SEG LEFT:
li $t0, SEVENSEG LEFT # assign port's address
sb a0, 0(t0) # assign new value
nop
jr $ra
nop
#-----
# Function SHOW 7SEG RIGHT: turn on/off the 7seg
# param[in] $a0 value to shown
# remark $t0 changed
#-----
SHOW 7SEG RIGHT:
li $t0, SEVENSEG RIGHT # assign port's address
sb $a0, 0($t0) # assign new value
nop
jr $ra
nop
Assignment 2:
* Trái sang phải:
.eqv MONITOR SCREEN 0x10010000 # Địa chỉ bắt đầu của bộ nhớ màn hình
.eqv RED 0x00FF0000 # Các giá trị màu thường sử dụng
.eqv BLACK 0x00000000
.text
main:
li $v0, 32
li $k0, MONITOR SCREEN # Nạp địa chỉ bắt đầu của màn hình
li $t1, RED
li $t2, BLACK
# Dùng vòng lặp để lặp lại quá trình ghi màu
li $t3, 60 # Bắt đầu từ offset 60
```

```
li $t4, 0 # Khởi tao biến đếm
li $t5, 10 # Cho tối đa 10 lần đổi vi trí
loop:
sw $t1, ($k0) # Ghi màu đỏ vào địa chỉ $k0
li $a0, 1000
syscall
sw $t2, ($k0) # Ghi màu đen vào địa chỉ $k0 (tô đè lên màu đỏ)
addi $k0, $k0, 4 # Dịch con trỏ đến ô nhớ tiếp theo
addi $t4, $t4, 1 # Tăng biến đếm lên 1
beq $t4, $t5, exit # Nếu số lần đổi vị trí đạt giá trị tối đa như đã cho thì thoát
i loop
exit:
li $v0, 10
syscall
* Phải sang trái:
.eqv MONITOR SCREEN 0x10010000 # Địa chỉ bắt đầu của bộ nhớ màn hình
.eqv RED 0x00FF0000 # Các giá trị màu thường sử dụng
.eqv BLACK 0x00000000
.text
main:
li $v0, 32
li $k0, MONITOR SCREEN # Nap địa chỉ bắt đầu của màn hình
addi $k0, $k0, 60
li $t1, RED
li $t2, BLACK
# Dùng vòng lặp để lặp lại quá trình ghi màu
li $t3, 60 # Bắt đầu từ offset 60
li $t4, 0 # Khởi tao biến đếm
li $t5, 10 # Cho tối đa 10 lần đổi vi trí
loop:
sw $t1, ($k0) # Ghi màu đỏ vào địa chỉ $k0
li $a0, 1000
syscall
sw $t2, ($k0) # Ghi màu đen vào địa chỉ $k0 (tô đè lên màu đỏ)
addi $k0, $k0, -4 # Dich con trỏ đến ô nhớ tiếp theo
addi $t4, $t4, 1 # Tăng biến đếm lên 1
beg $t4, $t5, exit # Nếu số lần đổi vi trí đat giá tri tối đa như đã cho thì thoát
j loop
```

```
exit:
li $v0, 10
syscall
```

Assignment 3:

```
.eqv HEADING 0xffff8010
                                   # Integer: An angle between 0 and 359
                            # 0 : North (up)
                            # 90: East (right)
                            # 180: South (down)
                            # 270: West (left)
                                   # Boolean: whether or not to move
.eqv MOVING
                 0xffff8050
.eqv LEAVETRACK 0xffff8020
                                   # Boolean (0 or non-0):
                            # whether or not to leave a track
.eqv WHEREX
                  0xffff8030
                                   # Integer: Current x-location of MarsBot
                                   # Integer: Current y-location of MarsBot
.eqv WHEREY
                  0xffff8040
.text
main:
       addi $a0, $zero, 135 # Marsbot rotates 135* and start running
      jal ROTATE
       nop
      jal GO
      nop
sleep1: addi $v0, $zero, 32 # Keep running by sleeping in 5000 ms
       li $a0, 5000
       syscall
      jal TRACK # And draw new track line
edge1: addi $a0, $zero, 150 # Marsbot rotates 150*
      jal ROTATE
sleep2: addi $v0, $zero, 32 # Keep running by sleeping in 5000 ms
       li $a0, 5000
       syscall
      jal UNTRACK # Keep old track
      jal TRACK # And draw new track line
edge2: addi $a0, $zero, 270 # Marsbot rotates 270*
      jal ROTATE
sleep3: addi $v0, $zero, 32 # Keep running by sleeping in 5000 ms
       li $a0, 5000
```

```
syscall
     jal UNTRACK # Keep old track
     jal TRACK # And draw new track line
     nop
edge3: addi $a0, $zero, 30 # Marsbot rotates 30*
     ial ROTATE
sleep4: addi $v0, $zero, 32 # Keep running by sleeping in 5000 ms
     li $a0, 5000
     syscall
     jal UNTRACK # Keep old track
     ial STOP
exit:
     li $v0, 10
     syscall
end main:
#-----
# GO procedure, to start running
# param[in] none
#-----
GO: li
          $at, MOVING # change MOVING port
     addi
          $k0, $zero,1 # to logic 1,
          $k0, 0($at) # to start running
     sb
     jr
          $ra
#-----
# STOP procedure, to stop running
# param[in] none
#-----
STOP: li
          $at, MOVING # change MOVING port to 0
     sb
          zero, 0(at) # to stop
          $ra
     jr
# TRACK procedure, to start drawing line
# param[in] none
#-----
TRACK: li $at, LEAVETRACK # change LEAVETRACK port
          $k0, $zero,1 # to logic 1,
     addi
          $k0, 0($at) # to start tracking
     sb
     jr
          $ra
#-----
# UNTRACK procedure, to stop drawing line
# param[in] none
```

```
UNTRACK:li
                    $at, LEAVETRACK # change LEAVETRACK port to 0
             $zero, 0($at) # to stop drawing tail
      sb
      jr
# ROTATE procedure, to rotate the robot
# param[in] $a0, An angle between 0 and 359
           0 : North (up)
           90: East (right)
#
           180: South (down)
#
#
           270: West (left)
ROTATE: li $at, HEADING # change HEADING port
             a0, 0(at) # to rotate robot
      sw
      jr
             $ra
Assignment 4:
.eqv KEY CODE
                    0xFFFF0004
                                               # ASCII code from keyboard, 1 byte
                                               \#=1 if has a new keycode?
.eqv KEY READY 0xFFFF0000
# Auto clear after lw
.eqv DISPLAY CODE 0xFFFF000C
                                                     # ASCII code to show, 1 byte
.eqv DISPLAY READY 0xFFFF0008
                                                     #=1 if the display has already to do
# Auto clear after sw
.data
exit: .asciiz
             "exit"
.text
      $k0, KEY_CODE
li
      $k1, KEY READY
1i
li
      $s0, DISPLAY CODE
li
      $s1, DISPLAY READY
      $s2, exit
la
1i
      $t3, 0
loop: nop
WaitForKey:
1w $t1, 0($k1) # $t1 = [$k1] = KEY READY
beq $t1, $zero, WaitForKey # if $t1 == 0 then Polling
nop
ReadKey:
lw $t0, 0($k0) # $t0 = [$k0] = KEY_CODE
nop
WaitForDis:
```

```
lw $t2, 0($s1) # $t2 = [$s1] = DISPLAY_READY
nop
beq $t2, $zero, WaitForDis # if $t2 == 0 then Polling
nop
checkExit:
add $t4, $t3, $s2
lb $t4, 0($t4)
bne $t4, $t0, reset
addi $t3, $t3, 1
j ShowKey
reset:
addi $t3, $0, 0
beq $t0, 'e', checkExit
j ShowKey
ShowKey:
sw $t0, 0($s0) # show key
nop
beq $t3, 4, end
j loop
end:
li $v0, 10
syscall
```