MICHIGAN CDL SKILLS TEST VEHICLE INSPECTION MEMORY AID

CAB CHECK/ENGINE START

safety belt emer. equip safe start temperature gauge oil pressure gauge ammeter or voltmeter *air gauge lighting indicators

horn
heater/defroster
mirrors/windshield
wipers/washers

parking brake service brake/ABS *air brake check hydraulic brake check

All Combination Vehicles

<u>Truck</u> air & electric connectors

Coupling System
mounting bolts
pintle hook
hitch release lever to prove safety devices

Trailer
air & electric connectors &

Coupling System body of tongue or draw bar bolts mounting bolts safety devices sliding pintle

Tractor
air & electric connectors &
lines
Coupling System

mounting bolts
platform
locking jaws or lever
release arm & safety latch
5th wheel skid plate
Slide 5th wheel pins

Semi-Trailer air & electric connectors

Coupling System king pin apron gap

SCHOOL BUS/TRUCK/TRACTOR

Front of Vehicle lights & reflectors

Engine Compartment
oil level
coolant level
power steering fluidbelt or gear
water pump
alternator belt or gear

air compressor- belt or gear leaks & hoses

Steering Steering box & hoses steering linkage

Front Wheel tires flug of grims lug nuts axle seal

Front Suspension of the springs & shocks u-bolts spring mounts a managinary

Front Brake
brake hose/line
*brake chamber
*slack adjustor & push rod
drum & linings / rotor & pad

Driver Fuel Area

door & mirror fuel tank & cap & leaks catwalk & steps lights & reflectors

Under Vehicle drive shaft exhaust system frame

Rear Wheels
tires
rims
lug nuts
axle seal
spacers or budd spacing

Rear Suspension springs & airbags & shocks u-bolts spring/air mounts & torque arm

Rear Brake brake hose/line *brake chamber *slack adjustor & push rod drum & linings / rotor & pad

Rear of Vehicle doors & ties & lift splash guards lights, reflectors & reflective tape

TRAILER

Trailer Front
header board or bulkhead
lights & reflectors

Side of Trailer
landing gear
frame & tandem release
doors, ties & lifts
lights & reflectors

Wheels
tires
rims
lug nuts
axle or hub oil seal
spacers or budd spacing

Suspension
springs & airbags & shocks
u-bolts
spring/air mounts & torque arm

brake
brake hose/line
*brake chamber
*slack adjustor & push rod
drum&linings / rotor&pad

Rear of Trailer
doors & ties & lift
splash guards
lights, reflectors & reflective
tape

All Passenger Vehicles

Passenger Items
passenger entry & lifts
emergency exits
seating

Baggage compartment doors secure (baggage)

School Bus Only student lights

student Safety Items
stop arm & safety arm
student mirrors
passenger entry / lifts
emergency kit & body fluid kit

Rev (10/01/2013)

Lot: 110 S. Delaney Rd. Owosso, MI, 48867

^{*}Inspect on vehicles equipped with air brakes only




State of Michigan Ruth Johnson, Secretary of State


DEPARTMENT OF STATE

LANSING

Minor changes have been made to Michigan's CDL driving skills test to comply with new Federal rules after some manuals were published. This document describes changes in the basic control skills test exercises (Section 12) and the vehicle inspection (Section 11).

The basic control skills test exercises now include the following maneuvers: 1) straight-line backing; 2) off-set backing (either right or left); and 3) alley dock. The off-set backing exercise is new to Michigan's test (see diagrams).





The following items have beer added to the required vehicle inspection elements. The memory aid on the reverse page includes these items. You may use this memory aid during your test.

Air gauge: During the cab check and engine start, you must check the air gauge (if vehicle is equipped with air brakes):

- Make sure the air gauge is working properly.
- Build air pressure to governor cut-out, roughly 120-140 psi.

<u>Air brake automatic failure</u>: Failure to properly perform all components of the air brake check results in an automatic failure of the vehicle inspection test.

Parking brake: You must inspect the parking brake.

 With the parking brake released and the trailer parking brake engaged (combination vehicles only), check that the trailer parking brake will hold vehicle by gently trying to pull forward with the trailer parking brake on.

Service brake: You must check the application of air or hydraulic service brakes.

Pull forward at 5 mph, apply the service brake and stop. Check to see that the vehicle
does not pull to either side and that it stops when brake is applied.

Reflector tape condition: When checking that all external lights and reflective equipment are clean and functional, light and reflector checks, you must check the reflector tape condition.

Body fluid clean-up kit: If the vehicle is a school bus, you must check for a body fluid clean-up kit when checking the emergency equipment.