

UM2159 User manual

Getting started with Ultra-low-power STM32L0 and LoRa® Discovery kit

Introduction

The LoRa® Discovery kit (B-L072Z-LRWAN1) is an RF Discovery board featuring the CMWX1ZZABZ-091 LoRa® module from Murata. This module incorporates the SX1276 low-power transceiver which features a LoRa® long-range modem. This module supports high-performance and OOK/FSK modulations. The transceiver is controlled by an STM32L072CZY6 microcontroller embedded in the module. A complete and certified LoRaWAN[™] middleware stack, compliant with the LoRaWAN[™] specification and running on the STM32L072CZY6 microcontroller, provides support for bi-directional end-devices in Class A and Class C protocols and for end-device activation either via Over-The-Air Activation (OTAA) or via Activation-By-Personalization (ABP). For all the details refer to the STM32 LoRa® software expansion for STM32Cube (UM2073) User manual, at the www.st.com website. This document describes the hardware environment to build the system and to run an application based on the B-L072Z-LRWAN1 Discovery kit.



Figure 1. B-L072Z-LRWAN1 LoRa® Discovery kit

Picture is not contractual.



January 2017 DocID030169 Rev 1 Contents UM2159

Contents

1	Hard	Hardware configuration			
	1.1	Features	4		
	1.2	System requirement	4		
	1.3	Development toolchains	4		
	1.4	Powering up the Discovery kit	5		
	1.5	Reset the Discovery kit	5		
	1.6	Hardware block diagram	5		
2	Firmware demonstration				
	2.1	Factory default firmware	6		
	2.2	I-CUBE-LRWAN	7		
3	Revi	sion history	8		



UM2159 List of figures

List of figures

Figure 1.	B-L072Z-LRWAN1 LoRa® Discovery kit	. 1
Figure 2.	Hardware block diagram	. 5



1 Hardware configuration

1.1 Features

The B-L072Z-LRWAN1 Discovery kit offers the following features:

- A CMWX1ZZABZ-091 LoRa® module from Murata embedding:
 - STM32L072CZY6 microcontroller featuring 192 Kbytes of Flash memory, 20 Kbytes of RAM, 20 Kbytes of EEPROM
 - SX1276 low-power transceiver which features a LoRa[®] long-range modem
- ARM[®] mbed[™] (see http://mbed.org)
- On-board ST-LINK/V2 with selection mode switch to use the kit as a standalone ST-LINK/V2 (with SWD connector for programming and debugging)
- Board powered through the USB bus or from an external 3V or 5V supply voltage or battery
- Six LEDs:
 - LD7 (red/green) for USB communication
 - LD2 (red) for 3.3V power-on
 - Four user LEDs: LD1 (Green), LD2 (red), LD3 (blue) and LD4 (red)
- Two push-buttons (user and reset)
- USB with Micro-B connector for the CMWX1ZZABZ-091 modue
- Arduino[™] connector to plug Arduino/Mbed compatible expansion board.
- Extension header for a quick connection to the prototyping board and an easy probing

1.2 System requirement

- Windows[®] OS (XP, 7, 8,10), Linux 64-bit or macOS[™]
- USB Type-A to Micro-B cable
- ST-LINK/V2

1.3 Development toolchains

- Keil[®] MDK-ARM^(a)
- IAR[™] EWARM^(a)
- GCC-based IDEs including free SW4STM32 from AC6
- ARM[®] mbed[™] online

a. On Windows[®] only.

1.4 Powering up the Discovery kit

The B-L072Z-LRWAN1 Discovery kit can be powered up from three sources:

- USB ST-LINK: to power the board from the USB connector CN7, use the 'Type-A to Micro-B' USB cable and connect it between the host and the USB connector CN7 of the board
- External sources: DC power supply can be inserted in the GND and 3V (or 5V) pin
- Battery case: insert three AA batteries in the battery case at the bottom of the board

1.5 Reset the Discovery kit

There are three ways to reset the B-L072Z-LRWAN1 Discovery kit:

- Push the reset button (B1) mounted on the B-L072Z-LRWAN1
- Remove and reinsert the USB cable
- The STM32 can also be reset by debuggers

1.6 Hardware block diagram

The B-L072Z-LRWAN1 Discovery kit is designed around the CMWX1ZZABZ-091 module from Murata. *Figure 2* illustrates the connections between the CMWX1ZZABZ-091 and its peripherals (STLINK/V2, push-button, LEDs, USB and connectors).




Figure 2. Hardware block diagram

Firmware demonstration UM2159

2 Firmware demonstration

2.1 Factory default firmware

The demonstration software is preloaded in the STM32 Flash memory in factory.

This example requires two B-L072Z-LRWAN1 kits. This demonstration consists in establishing a simple Rx/Tx RF link between the two LoRa $^{\circledR}$ objects.

By default the boards are blinking their LEDs (LED1, LED2, LED3 and LED4). Each LoRa[®] object starts as a master and transmits a "Ping" message, then each of them waits for an answer. The first LoRa[®] object receiving a "Ping" message becomes a slave and answers the master with a "Pong" message, which starts the ping-pong game between them. The master then blinks only the red LED (LED4) and the slave blinks only the blue LED (LED3).

Both kits output information about their activity on a serial COM port with the following configuration:

• Baud rate: 115200 bauds

Data: 8 bitParity: noneStop: 1 bit

• Flow control: none

The respective output of the kits looks like the following:

on Ping side (master)

txDone

OnRxDone

RssiValue=-15 dBm, SnrValue=26

rxDone

...PING

OnTxDone

txDone

OnRxDone

RssiValue=-15 dBm, SnrValue=27

rxDone

...PING

OnTxDone

txDone

OnRxDone

on Pong side (slave)

OnTxDone

txDone

OnRxDone

RssiValue=-14 dBm, SnrValue=27

rxDone

...PONG

OnTxDone

txDone

OnRxDone

RssiValue=-14 dBm, SnrValue=27

rxDone

...PONG

OnTxDone

txDone

OnRxDone

2.2 I-CUBE-LRWAN

The demonstration firmware provided with the B-L072Z-LRWAN1 Discovery kit is the PingPong example from the I-CUBE-LRWAN package.

Other examples are provided inside the I-CUBE-LRWAN expansion package. The middelware stack (I-CUBE-LRWAN) enables the user to easily develop LoRa® applications. It offers a set of dedicated APIs and configuration templates to build end-devices (LoRa® objects) able to join a LoRa® network and to communicate through LoRa® technology. For more details refer to the "STM32 LoRa® software expansion for STM32Cube" User manual (UM2073) at the www.st.com website.

Revision history UM2159

3 Revision history

Table 1. Document revision history

Date	Revision	Changes	
27-Jan-2017	1	Initial release.	

IMPORTANT NOTICE - PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2017 STMicroelectronics - All rights reserved

