

STRUTHIO ONE SLIM

Quick start · the whole build on one page · every step is in the manual with a picture and a check

1

Order

Everything on **STRUTHIO_ORDER** (package 5): the screen board, cell, plug-in speaker, 5 screws, a header strip, foam tape. Board from JLCPCB at **0.8 mm**; print the 7 parts in PETG.

2

Flash

Plug the screen board in by USB-C. Double-click **FLASH_ME.bat** (package 1). Wait for **DONE**.

3

Pins

Board **face down** in the pin jig. A strip of 4 and a strip of 8 pins, long side first. Solder, slide the plastic off, snip flush.

4

Front shell

Wing buttons, rocker (axle cut in the jig's slot), power button, then the screen board face down.

5

Board

The ONE SLIM onto the screen board, pins into the long socket, flat on its posts.

6

Back shell

Speaker in its lip, cell taped in the corner, leads under the clips. Plug the speaker into **J9**, the cell into **J2**.

7

Close

Tongue into the groove. **5 x M2 x 6**, snug.

8

Power

Press the button on the left side. The screen checks every button, the speaker and the battery. **Both wings**: play.

9

Panel

Peel the liner, drop the panel into its pocket inside the lip, press from the middle out.

Off: hold the power button 4 s. Charge: USB-C, about 3 hours. Re-flash: FLASH_ME.bat again. Full manual: STRUTHIO_ONE_SLIM_Build_Manual_Windows11.pdf · rev S3 · commit ba90005 · 2026-10-02