
Rev	Description	Date	Drawn
Ver1.0	First release	2013-01-28	
•		,	

A10_Cover Rev V1.0 Document Number Monday, January 28, 2013 Sheet



A10_BLOCK Document Number Rev V1.0 Monday, January 28, 2013 Sheet

unction	GPIO List	Pin Name	Direction	Net Name	Active	Default	Description	
	ERXD2/SPI1_CLK/PA1	E5	0	SPI1_CLK				
SPI1	ERXD1/SPI1_MOSI/PA2	D6	0	SPI1_MOSI			SPI1_LINK	
	ERXD0/SPI1_MISO/PA3	E6	I	SPI1_MISO				
	SPIO0_CS0/UART5_TX/EINT22/PI10	C17	0	SPI0_CS			SPIO_LINK/PWM	
SPI0	SPIO0_CLK/UART5_RX/EINT23/PI11	D17	0	SPI0_CLK			SPI01_LINK	
	SPIO0_MOSI/UART6_TX/EINT24/PI12	C16	0	SPI0_MOSI			SPIO_LINK/PWM	
	SPIO0_MISO/UART6_RX/EINT25/PI13	D16	1	SPI0_MISO			SPI0_LINK	
IICO	TWI0_SCK/PB0	A15	0	PMU-SCK			PMU_IIC_LINK IIC_LINK CONN_IIC_LINK	
1100	TWI0_SDA/PB1	B15	1/0	PMU-SDA				
TTC1	TWI1_SCK/PB18	A8	0	TWI1-SCK				
IIC1	TWI1_SDA/PB19	B8	1/0	TWI1-SDA				
TTCO	TWI2_SCK/PB20	C8	0	TWI2-SCK				
IIC2	TWI2_SDA/PB21	C7	1/0	TWI2-SDA				
HADTO	UARTO_TX/IR1_TX/PB22	Α7	0	UARTO-TX			UARTO LINK For debug	
UART0	UARTO_RX/IR1_RX/PB23	B7	1	UART0-RX			OAKTO_ENAKTOI debug	
	JTAG_MS0/SPI2_CS0/PB14	A10	0	JTAG-MS				
	JTAG_CK0/SPI2_CLK/PB15	B10	0	JTAG-CK				
JTAG	JTAG_DO0/SPI2_MOSI/PB16	A9	0	JTAG-DO			JJTAG_LINK	
5	JTAG_DI0/SPI2_MISO/PB17	B9	1	JTAG-DI				
	JTAGSEL	T10	I	JTAG-SEL				
	NMI#	F5	0	NMI#			PMU_INT	
	SDC0_DI/JATG_MS1/PF0	M20	1/0	SD0-D1				
	SDC0_D0/JATG_DI1/PF1	M19	1/0	SD0-D0			SD_CARD	
SD0	SDC0_CLK/UART0_TX/PF2	L20	0	SD0-CLK				
אמפ	SDC0_CMD/JTAG_DO1/PF3	L19	0	SD0-CMD				
	SDC0_D3/UART0_RX/PF4	K20	1/0	SD0-D3				
	SDC0_D2/JATG_CK1/PF5	K19	1/0	SD0-D2				
UART2	EINT30/SPI1_MOSI/UART2_TX/PI18	E15	0	UART2_TX			UART2 LINK/GPIO	
UAKIZ	EINT30/SPI1_MISO/UART2_RX/PI19	D14	I	UART2_RX			OARTZ_LINK/GFTO	
	I2S_DO1/PB9	C12	I	USB0-DR∨	Н	Н	PMU_CHANEL_SEL	
USB0 -	DM0	N20	1/0	DM0			OTG_USB	
	DP0	N21	1/0	DP0			010_038	
IICD 1	DM1	P20	1/0	DM1			USB_WIFI	
USB1	DP1	P21	1/0	DP1				
USB2	DM2	R20	1/0	DM2			USB_Type_A HDMI_DDC	
	DP2	R21	1/0	DP2				
	SCL_HDMI	R23	0	HSCL				
IDWI	SDA_HDMI	R22	1/0	HSDA			HDINII_DDC	
HD∎I	HPD_HDMI	P22	1	HHPD	Н	L	HDMI_HPD	
	CEC_HDMI	P23	1	HCEC	Н	L	HDMI_CEC	
DMW	PWM0/PB2	A14	0	PWM1			PWM	
P₩I	PWM1/PI3	B19	0	PWM2			PWM	
	XP_TP	Y22	I	ADC_2			·	
Ī	XN_TP	AA22	I	ADC_3				
ADC:	YP_TP	Y23	I	ADC_4			6_CHANEL_ADC	
ADC	YN_TP	AA23	1	ADC_5				
	LRADC0	AB23	I	ADC_0				
	LRADC1	AB22	I	ADC_1				
	LCD1_D1/ATAA1/UART3_RX/EINT1/CSI1_D1/PH1	B6	I	SD0-DET#	L	Н	SD_CARD_DET	
	LCD4_D1/ATAD0/UART4_TX/EINT4/CSI1_D4/PH4	B5	I	USB0_ID_DET	L	Н	OTG_USB_DET	
P₩I	LCD5_D1/ATAD1/UART4_RX/EINT5/CSI1_D5/PH5	C5	1/0	PWM3			PWM	
I.ME	LCD6_D1/ATAD2/UART5_TX/EINT6/CSI1_D6/PH6	A4	1/0	PWM0			PWM	
	LCD1_D7/ATAD3/UART5_RX/EINT7/CSI1_D7/PH7	B4	1/0	GPIO2			GPIO	
	LCD1_D8/ATAD4/EINT8/CSI1_D8/PH8	C4	1/0	GPIO3			GPIO	
GP10	LCD1_D9/ATAD5/EINT9/CSI1_D9/PH9	D4	1/0	GPIO4			GPIO	
	LCD1_D10/ATAD6/EINT10/CSI1_D10/PH10	А3	1/0	GPIO5			GPIO	
	LCD1_D11/ATAD7/EINT11/CSI1_D11/PH11	В3	1/0	GPIO6			GPIO	
	LCD12_D12/ATAD8/EINT12/CSI1_D12/PH12	C3	1/0	GPIO7			GPIO	
	LCD1_D13/ATAD9/EINT13/CSI1_D13/PH13	A2	1/0	GPIO8			GPIO	
	LCD14 D14/ATAD10/EINT14/CSI1 D14/PH14	B2	1/0	GPIO9			GPIO	
	LCD1 D15/ATAD11/EINT15/CSI1 D15/PH15	A1	0	TX LED	L	Н	TX LED	
				RX LED	L	Н	RX LED	
	LCD1 D16/ATAD12/EINT16/CSI1 D16/PH16	B1	0					
	LCD1_D16/ATAD12/EINT16/CSI1_D16/PH16 LCD1_D17/ATAD13/EINT17/CSI1_D16/PH17							
	LCD1_D16/ATAD12/EINT16/CSI1_D16/PH16 LCD1_D17/ATAD13/EINT17/CSI1_D16/PH17 LCD1_D18/ATAD14/EINT18/CSI1_D16/PH18	B1 C1 C2	1	Key_Back Key_Home	L	H	Key_Back Key_Home	

