

User Manual of Geiger-counter GMV2, GMJ3

--2022-0626 Supplement

Display Mode:

M1: usv/h ,With beep sound , Marking symbol :B(Top Row 13)

Bottom: SAFETY or DANGER!!



M2, usv/h ,no beep sound

Bottom: SAFETY or DANGER!!



M3: CPM,With beep sound , Marking symbol :B(Top Row 13)



M4: CPM,no beep sound



M5:Accumulated Dose



M6:usv/h With beep sound ,

Accumulated Dose Bottom



M7:usv/h no beep sound ,

Accumulated Dose Bottom



Adjust function Key:

F1: With alarm threshold

F2: Press M, increase Alarm-Threshold, press M and F together after it auto return could save the Updated Alarm-Threshold to mcu

F3: Press M, decrease Alarm-Threshold, press M and F together after it auto return could save the Updated Alarm-Threshold to mcu

F4: no Alarm when radiation intensity over Alarm-Threshold

F5: Press M and LCD light auto-off turned off, and with Marking symbol:L (Top Row 15)

Press M and F together could save current M, F value, and next time turn on machine, it still on this page.

Set Accumulated Dose to zero or save Accumulated Dose to MCU:

When M5 and F5, press M and F together could set Accumulated Dose to zero, and save this value to MCU.

When M and F are other value, press M and F together could save Accumulated Dose to MCU, and next time turn on machine the Accumulated Dose start from the value when you press M and F.

Acknowledgment:

Thanks a lot for ZuZu's proposal and sketch.