LCC Scenario

T Clock	Controller	Command		
GO/NO GO POLL				
0:11:30	TCon	All parties, this is the test GO/NO GO poll....		Total Commands
0:11:00	TCon	All parties have reported go for test countdown...		35
0:10:10	TCon	All parties will now enter the GO command...		
0:10:00	TCon	T minus ten minutes. Countdown sequences have now commenced...		
Commence T-10:00 Countdown Sequence				
0:10:00	ALL	Print "Test Countdown Sequence Started" on all consoles in response to each "go" command		
0:09:57	Fluids 2 Downstream	*Open Valve PB7*	Fuel Load	Valve is opened so pressure can release from the tank as it is filled
0:09:30	Fluids 2 Downstream	Open Valve B4		Opening the fuel valve
0:09:00	Fluids 2 Tank	Start Fuel Fill		Fueling the tank
0:08:30	Fluids 2 Tank	Stop Fuel Fill Once Tank Hits 20lbf (Verify via LC2)		Making sure the tank is full with margin
0:08:00	Fluids 1 Downstream	Open Valve B3	LOX load	Valve is opened so pressure can release from the tank as it is filled
0:07:30	Fluids 1 Downstream	Open Valve B1		Opening the lox valve
0:07:00	Fluids 1 Tank	Verify Tank Weight, Weight is increasing (via LC1)		Fueling the tank
0:06:30	Fluids 1 Tank	Stop LOX tank weight once it reaches 25lbf		Making sure the tank is full with margin
0:06:00	Fluids 2 Upstream	Regulate R2 to 975 PSI (+/- 10 PSI)		This is the pressure to get the correct mdot into the chamber (lookup CdA if your curious)
0:05:45	Fluids 2 Upstream	Regulate R3 to 200 PSI		Setting Purge Pressure
0:05:30	Fluids 1 Upstream	Regulate R1 to 1000 PSI (+/- 10 PSI)		This is the pressure to get the correct mdot into the chamber (lookup CdA if your curious)
	Fluids 1 Downstream	Close B1		Making sure the dewar is closed so no more fluid gets to lox tank
0:05:00	Visual Control	Start Test Control Cameras		Starting Visual Control Cameras
0:04:30	Fluids 1 Upstream	Open S6		Pressurizing the Fuel Tank
0:04:00	Fluids 2 Upstream	Open S5		Pressurizing the LOX Tank
	Fluids 2 Tank	Verify Pressure is 975 psi (+/- 10 psi)		Make sure tank is at correct pressure
	Fluids 1 Tank	Verify Pressure is 1000 psi (+/- 10 psi)		Make sure tank is at correct pressure
0:03:45	Visual Control	Verify System is GO		Verify go
0:03:25	Fluids 2 Downstream	Activate LOX chill sequence		lox chill so no hard start
0:03:10	Fluids 2 Downsteam	Verify LOX dragon temp is < 250F		lox lines are verified but fail
0:02:35	Fluids 2 Downstream	Run the Lox chill sequence again		this is anomaly so it runs again
0:02:25	Fluids 2 Downstream	Verify LOX dragon temp is < 250F		Making sure it actually chilled
0:02:00	Engines	Activate Pyrograin		this is the igniter for the engine
0:01:45	Engines	Open Run Valves (PB4 + PB8)		these are the run valves which put prop into the engine
0:01:25	Engines	Confirm Nominal Shutdown		confirms no anomaly for engine shutdown
0:01:16	Fluids 2 Upstream	Close PB5 and S6		closing upstream valves to vent the system pressure
0:01:09	Fluids 1 Upstream	Close PB1 and S4		closing upstream valves to vent the system pressure
0:01:09	Fluids 2 Upstream	Open PB7		Opening valves to drain the tanks and pressure
0:01:00	Fluids 1 Upstream	Open PB3		Opening valves to drain the tanks and pressure
0:00:45	Fluids 2 Downstream	Open S2 for 5 seconds		n2 purging the engine
0:00:40	Fluids 1 Downstream	Open S1 for 5 seconds		n2 purging the engine
0:00:10	Fluids 2 Tank	Verify Tank Weight and Pressure is ~0 lbf and psi		making sure proper vent
0:00:00	Fluids 1 Tank	Verify Tank Weight and Pressure is ~0 lbf and psi		making sure proper vent
+0:30	Engines	Verify Chamber Pressure, LOX and Fuel Manifold is ~0 psi		making sure nothing is left in engine
+0:50	Visual Control	Verify system is safed		visually verifying things
	Visual Control	Proceed with data collection		collecting the data from the test

	Fluids 1 Upstream	Fluids 1 Tank	Fluids 1 Downstream	Fluids 2 Upstream	Fluids 2 Tank	Fluids 2 Downstream	Engines	Visual Control
Line Item Counts-->	4	4	4	5	4	6	4	4