CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · OPERATIONS

# Vehicle Logbook Register

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026 · The picture uses sample data, not real records

## 1. What this report shows

Lists every saved Vehicle Log Book (VLB) of the chosen dates, one line per book, with its meter readings, kilometres, running hours and trips. MIS staff use it to find a book and to check its readings against the trip card.


> **One row.** One row is one saved Vehicle Log Book: one vehicle, one driver and one shift on one date.

## 2. Open the report and choose what to see

In the left menu open **Reports** → **Operations** → **Vehicle Logbook Register**. Then set the selectors described below.

| Selector or button | What it does |
|---|---|
| **From / To** | First and last date to include, by the Book Date of the log book. From starts on the 1st of the current month and To on today's date. Dates before 01-11-2026 cannot be chosen, From must not be after To, and the range can be at most 366 days. If the dates are not valid, the screen shows "Choose a valid date range of at most 366 days." and no data is loaded. Changing a date loads the data again. |
| **Site** | Keeps only the log books of one site. "All" keeps every site your login can see. Once a site is chosen, the Shift, Vehicle / equipment, Driver / operator and Work order lists show only that site's entries. |
| **Shift** | Keeps only the log books of the chosen shift. Every shift in the list belongs to one site, so shifts of the same name at two sites appear as separate entries. Choose Site first, then Shift. |
| **Vehicle / equipment** | Keeps only the log books of the chosen door number. The list also has equipment doors; choosing one of them leaves this table empty. |
| **Driver / operator** | Keeps only the log books saved in the name of the chosen person. The list has only the people found on the log books and scan cards of the chosen dates. |
| **Work order** | Keeps only the log books saved against the chosen work order. The list has only the work orders found on the log books and scan cards of the chosen dates. |

## 3. What is on the screen




**Picture 1.** The report screen: selectors, totals and the table. *Sample data.*

| On the screen | What it shows |
|---|---|
| **Report** | Drop-down at the top with every report, listed under its group. Choosing a name opens that report. |
| **Saved operational records** | Line under the report name. It repeats the From and To dates in use. |
| **Refresh** | Loads the saved log books again for the same dates. Press it when log books were saved or corrected after the report was opened. While data is loading the button cannot be pressed and "Loading complete report data…" is shown. |
| **Filters:** | One line listing the selectors that are set. With none set it reads "All sites, assets, shifts and employees". The line uses short names: site, shift, asset (Vehicle / equipment), employee (Driver / operator), workOrder and loading. For shift, asset and employee it shows the record number of the choice, not its name. |
| **logbooks** | Number of saved log books, VLB and ELB together, that match the dates and filters. |
| **assets** | Number of different vehicles and equipment on those log books. |
| **trips** | Total trips on those log books. |
| **report rows** | Number of rows in the table below. |
| **No matching records or exceptions found.** | Shown inside the table when nothing matches the dates and filters. |

## 4. The columns

| Column | Meaning |
|---|---|
| **Date** | Book Date of the log book. On screen it shows as DD-MM-YY, for example 13-12-26. |
| **Site** | Site saved on the log book. |
| **Book NO** | Book number the system gave when the log book was saved. A number that begins with VLB_M is a typed entry; one that begins with VLB_S came from a scanned card. |
| **Door NO** | Door number of the vehicle, for example V9001. |
| **Caliber ID** | Employee ID of the driver on the log book, for example CMPL90001. |
| **Employee** | Name of the driver on the log book, for example SAMPLE DRIVER 01. |
| **Shift** | Shift name saved on the log book. |
| **WO / Contract** | Work order saved on the log book. Shows — when the log book has none. |
| **OPN KMR** | Opening KMR reading saved on the log book. |
| **CLO KMR** | Closing KMR reading saved on the log book. |
| **KM** | CLO KMR minus OPN KMR. If the log book was saved with a separate actual distance because the meter was replaced, that distance is shown instead. |
| **OPN HMR** | Opening HMR reading saved on the log book. |
| **CLO HMR** | Closing HMR reading saved on the log book. |
| **Running HRS** | Running hours of the log book: CLO HMR minus OPN HMR. |
| **Trips** | Trips counted for this log book. |
| **Remarks** | Remark saved on the log book. |

## 5. Keep in mind

- Only Vehicle Log Books are listed. Equipment log books are in Equipment Logbook Register. LMV log books and deleted log books are not shown.
- The four counts above the table take VLB and ELB together, so "logbooks" can be more than "report rows".
- A trip is counted on the log book that has its loading time. A trip row with only an unloading time (a load taken over from the previous driver) is not counted again.
- Rows are not always in date order. Press the Date heading to sort by date. An empty cell shows —.
- "Reset table" in the Actions menu of the table also puts From back to the 1st of the current month and To back to today's date.
- You see only the sites your login is allowed to see.

## 6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.
- If the page looks old after an update, press **Ctrl + F5** once.

## 7. Review checklist

| Step | Do this |
|---|---|
| **1** | Set From and To, choose Site, and if needed choose Vehicle / equipment or Driver / operator. |
| **2** | Find the book by its Door NO or Book NO. |
| **3** | Compare OPN KMR, CLO KMR, OPN HMR and CLO HMR with the paper trip card. |
| **4** | Choose one vehicle in Vehicle / equipment and check that the OPN readings of each book are the same as the CLO readings of that vehicle's previous book. Books where they differ are also listed in Reports → Utilisation & Exceptions → Meter Reading Exceptions. |
| **5** | Check that KM, Running HRS and Trips look right for the shift, and read Remarks. |

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

## 8. Common questions

| Question | Answer |
|---|---|
| **A log book I saved is not in the list. Why?** | Check that From and To cover the Book Date of the book (not the day it was typed), set the other selectors to All and press Refresh. LMV log books, deleted log books and books of sites your login cannot see are not listed. |
| **Why is "logbooks" above the table more than the rows in the table?** | The count above the table also includes equipment log books. The table lists vehicle log books only. |
| **Why is KM not equal to CLO KMR minus OPN KMR?** | That log book was saved with a separate actual distance because the meter was replaced. The report shows that distance. |