CALIBER MINING AND LOGISTICS LIMITED · PULSE-II · TRIPS & PRODUCTIVITY

Day-wise Door Number Report

Operating manual

For site in-charges, MIS staff and reviewers · Matches the system as of 9 November 2026

1. What this report shows

This report shows, for one site and one date, the completed trips, working HMR and quantity in cubic metres (CUM) of every tipper, Shift by Shift. It is made only from saved VLB cards whose batch has been locked with Save & lock batch. A site in-charge or MIS clerk uses it to check production door number by door number.

> **One row.** One row is one tipper (door number) at the selected site on the selected date. Every active vehicle listed at that site in the Equipment master gets a row, even when no VLB card was saved for it. The last row, TOTAL (complete selection), adds up all the rows.

2. Open the report and choose what to see

In the left menu open **Reports** → **Trips & Productivity** → **Day-wise Door Number Report**. Then set the selectors described below.

Selector or button	What it does
1. Site	Choose the site. Only sites allowed for your login are listed. Changing the site clears the Shift and Applicable schedule choices.
2. Date	The card date for the report. It opens on today's date. Dates before 1 November 2026 cannot be chosen. Changing the date clears the Shift and Applicable schedule choices.
3. Report type	Shift-wise shows one Shift. Day-wise shows every Shift of that date side by side, with totals for the day.
Shift	Shown when Report type is Shift-wise. It lists only the Shifts found in the Shift Master for that site and date (Shift 1, Shift 2, Shift 3, Day shift, Night shift). One must be chosen.
Applicable schedule	Shown only when Report type is Day-wise and the Shift Master has both a three-shift schedule and a Day/Night schedule for that site and date. Choose Shift 1 / 2 / 3 or Day / Night.
Show report	Loads the report for the choices made. The button stays disabled until Site, Date and Shift (or schedule) are filled. While loading it reads Checking batches…. If any choice is changed afterwards, the result is cleared; press Show report again.

3. What is on the screen

On the screen	What it shows

Door number / Machine number	Two buttons under the heading. Door number is this report. Machine number opens the Day-wise Machine Number Report; the choices already made stay as they are.
No active, unambiguous Shift Master schedule is available for this site and date.	Shown after a site is chosen when no usable Shift is found in the Shift Master for that site and date. Show report stays disabled in that case.
Message in the red box	Shown under the selection when the report cannot be loaded, for example This location is not assigned to your login. or Too many cards or unresolved handovers for one report. Review the outstanding trip links first.
Shift status boxes	After Show report, one box for each Shift in the report. It shows the Shift name and its status, the number of saved VLB cards and the batch name (or Batch not created). The statuses are Processed, Not processed, Missing / duplicate batch, No saved VLB cards and Batch snapshot needs review. Processed means there is exactly one batch for that Shift, it is locked, and every VLB card of the Shift is in it unchanged since the lock.
Report not generated	Shown in place of the table when any check fails. Each line states the problem and the card number, batch name or door number it refers to. After the corrections, press Show report again. Print and export appear only when all checks pass.
Completed trips	Total completed trips of all tippers in the selection.
Quantity (CUM)	Total quantity of the selection: counted trips × approved capacity, added for all tippers.
Matched · Door and machine trip / quantity totals	Tells that the trip and quantity totals of the door-wise table and the machine-wise table are equal. The report is generated only when they are equal.
Source data review	Shown when some cards need a look but do not stop the report. Each line gives the card number and the remark, for example Driver / operator ID is missing.
Line under the table heading	Site, date, Shifts covered, the processed batch names with their revision number (the number goes up each time the batch is locked), and the date and time the report was generated (IST).
TOTAL (complete selection)	The last row of the table. It adds the trips, HMR and quantity columns of all rows.
Sources, capacity versions and calculation rules	Press to open. It lists the calculation rules, the capacity approvals used (site, job type, make / model, CUM/trip, effective date and approval number) and how to refresh the report after a correction.

4. The columns

Column	Meaning
Sr. No.	Running number. Rows are in door number order.
Door No.	Door number of the tipper as in the Equipment master, for example V9001. In the last row it reads TOTAL (complete selection).

Make	Make of the tipper. Taken from the saved VLB card when the card carries both make and model, otherwise from the Equipment master.
Model	Model of the tipper, from the same source as Make. Make and Model decide which approved capacity is used.
Shift 1 driver	Drivers named on the saved VLB cards of this tipper in that Shift, as name and Employee ID, for example SAMPLE DRIVER 01 (CMPL90001). More than one driver is separated by a semicolon. Unresolved driver / operator means the card has no Employee ID saved. — means no card. The same column repeats for every Shift in the report (Shift 2 driver, Shift 3 driver, Day shift driver, Night shift driver).
Shift 1 HMR	Working HMR of the tipper in that Shift, added over all its saved cards of that Shift. For each card it is the total working HMR saved on the card, or closing HMR − opening HMR when that total is not saved. — when no card gives usable readings. Repeats for every Shift in the report.
Shift 1 trips	Completed trips of the tipper counted in that Shift. A trip is counted on the card that records its loading; a row that has only an unloading time is not counted again. — means no saved card; 0 means a card is saved with no counted trips. Repeats for every Shift in the report.
Total HMR	Sum of the Shift HMR columns of the row. — when no Shift has HMR.
Capacity (CUM/trip)	Approved capacity per trip used for this tipper. It is the latest capacity approval for the site, job type, make and model with an effective date on or before the report date; if there is none for that site and job type, an older approval saved without site and job type is used. — when the tipper has no counted trips or when more than one capacity applied to its trips.
Total trips	Sum of the Shift trips columns of the row.
Quantity (CUM)	Counted trips × approved capacity per trip, added for all Shifts of the row.
Card coverage	Cards available when a VLB card is saved for every Shift in the report. Otherwise it names the Shifts without a card, for example S1: no saved VLB card (S1, S2, S3 are Shift 1, 2, 3; D is Day; N is Night).

5. Keep in mind

- Quantity (CUM) is worked out from the approved capacity per trip. It is not a weighbridge measurement.
- Trips and quantity belong to the Shift in which the tipper was loaded.
- No figures are shown until the batch of every Shift in the selection is locked. Reopening a batch, or a card changed after the lock, stops the report until the batch is locked again.
- Two cards of one tipper in the same Shift with different drivers (a relief driver) are joined in one row; their trips and HMR are added. Two cards for the same tipper, Shift and driver stop the report for review.
- The report also stops when the combined working HMR of a tipper in one Shift is more than the Shift length: 8 hours for Shift 1, 2 and 3, 12 hours for Day and Night.
- A downloaded report keeps the generation time printed on it. After a correction, lock the batch again and press Show report for fresh figures.

6. Download, print and search

- Tables on this page have a **Generate** button: **Download as PDF**, **Download as Excel** or **Smart Print**. The file contains the whole table, not only the rows visible on screen.
- Type in **Search this report** to find a door number, driver or card inside a table.
- Press a column heading to sort by that column.
- If the page looks old after an update, press **Ctrl + F5** once.

7. Review checklist

Step	Do this
1	Choose 1. Site, 2. Date and 3. Report type (and Shift or Applicable schedule), then press Show report.
2	Check that every Shift status box reads Processed. If Report not generated appears, read each line and note the card, batch or door it names.
3	In Card coverage, find the tippers that show no saved VLB card and check whether that tipper worked in that Shift.
4	Compare the Completed trips and Quantity (CUM) figures above the table with the TOTAL (complete selection) row.
5	Read each line under Source data review and open the named card to check it.
6	Open Sources, capacity versions and calculation rules and check the capacity listed for each make and model.

> **This manual shows how to read and verify the report.** What action to take on its findings is as instructed by management.

8. Common questions

Question	Answer
Why does the screen say Report not generated?	One of the checks failed. Examples: a Shift batch is not locked, a card was changed after the lock, an approved capacity is missing, the loading machine on a VLB card could not be identified, or a loading machine has no saved ELB card. The list under the heading names each problem and the card, batch or door.
What is the difference between — and 0 in a trips column?	— means no VLB card is saved for that tipper in that Shift. 0 means a card is saved but it has no counted trips.
Why is Capacity (CUM/trip) blank for a tipper that has trips?	More than one approved capacity was used for its trips, for example trips under different job types. Quantity (CUM) still uses the capacity that applies to each trip. The approvals used are listed under Sources, capacity versions and calculation rules.
A card was corrected. How do I get the new figures?	Lock the batch again with Save & lock batch, then press Show report. Until then the Shift shows Not processed or Batch snapshot needs review and the report is not generated.