Hw #2

ECE 4300 Hyosung Hm

2.1)
```
addi $t0, $s2, -5
add $s0, $s1, $t0
```

2.2)
```
f = i + (g+h);
```

2.3)
```
sub $t0, $s3, $s4
sll $t0, $t0, 2
add $t0, $s6, $t0
lw $t1, 0($t0)
add $t2, $s7, 32
sw $t1, 0($t2)
```

2.4)
```
f = A[f];
B[g] = A[f] + A[f+1];
```

2.5)

```
sll  $t0, $s0, 2
add  $t0, $s6, $t0

lw   $t1, 0($t0)
lw   $t2, 4($t0)
add  $t0, $t1, $t2
sll  $t1, $s1, 2

add  $t1, $s7, $t1
sw   $t0, 0($t1)
```

2.6.1)

```
n = 5
for (i=0  i<n-1  i++)
{
    int  min_indx
    for (j = i+1  j<n  j++) {
        if (Array[j] < Array[min_indx])
        {
            min indx = j;
        }
    }
    temp = Array[minIndx]

    Array[minIndx] = Array[i]
    Array[i] = temp;
}
```

2.7) 0x abcdef12

4 Bytes 0xab 0xcd 0xef 0x12

Little
0: 0x12
1: 0xef
2: 0xcd
3: 0xab

Big
0: 0xab
1: 0xcd
2: 0xef
3: 0x12

2.9)
```
sll $t0, $s3, 2
add $t0, $s6, $t0
lw $t0, 0($t0)

sll $t1, $s4, 2
add $t1, $s6, $t1
lw $t1, 0, $t1

add $t1, $t0, $t1

li $t3, 32
add $t3, $s7, $t3
sw $t2, 0($t3)
```

2.10) Int A[2]
Int *A

A[1] = A[0]
* = A[0] * A[1]

2.12.1) $60 = 0x5000,0000

.2) There has been no Overflow

.3) 0x8000,0000 - 0x4000,0000
= 0x8000 0000 + 0x 3000 0000
= 0x3000,0000

.4) There is no overflow

.5) 0x5000,0000 + 0x 3000 0000

0x3000,0000

.6) there is no Overflow

2.18.1) Overall size of R-Type instructions remains 32 bits with adjusted field sizes

18.2) Instruction size is 32 bits but register fields increase to 7 bits

18.3) - it could increase the size by adding registers and having wider instructions

- It could decrease due to simpler instructions and more specialized instructions

2.21) li $t0, -1

xor $t1, $t2, $t0

2.22) lw $t3, 0($s1)

sw $t1, $t3, 4

2.26) Final value of Dst = 20

26.2)
```
int i = N;
int temp = 0;
while (i >= 0) {
        temp += 2;
        i--;
}
*B = temp;
```

26.3) 5N + 1

2.29)
```
while (i < 100) {
        *result += MemArr[i];
        i++;
}
```

2.38) t1 0x1000,0000

t2 0x1000,0010

0x1000,0000 = 0x11223344

stores highest byte 0x11

2.47) 20% arith

20% branch

16 load/store

47.1) 2 x0,7 1.4

3 x0,2 0,6

6 x0.1 0,6

2,6

47,2) ~~2,6 · 1,5 = 3,25 - 1,2~~

~~0,75~~

~~2,05 = 1,025~~

~~2~~

1,025

47,2) 2.6 · 0,75 = 1,95

-1,2

0,75

0,375

47,3) ~~2,6 · 1,5 =~~

2,6 · 0,5 = 1,3

0,1

0,05 cycles