# 3GPP TS 38.306 V15.8.0 (2019-12)

Technical Specification

3rd Generation Partnership Project; Technical Specification Group Radio Access Network; NR; User Equipment (UE) radio access capabilities (Release 15)





#### 3GPP

#### Postal address

3GPP support office address

650 Route des Lucioles - Sophia Antipolis Valbonne - FRANCE Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Internet

http://www.3gpp.org

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© 2019, 3GPP Organizational Partners (ARIB, ATIS, CCSA, ETSI, TSDSI, TTA, TTC). All rights reserved.

UMTS<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its members 3GPP<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners LTE<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners GSM® and the GSM logo are registered and owned by the GSM Association

## Contents

Forev	word	5
1	Scope	6
2	References	6
3	Definitions, symbols and abbreviations	7
3.1	Definitions	
3.2	Symbols	
3.3	Abbreviations	7
4	UE radio access capability parameters	8
4.1	Supported max data rate	
4.1.1	General	8
4.1.2	~ Tr · · · · · · · · · · · · · · · · · ·	
4.1.3	· · · · · · · · · · · · · · · · · · ·	
4.1.4	- · · · · J · · · · · · · · · · · · · ·	
4.2	UE Capability Parameters	
4.2.1	Introduction	
4.2.2	r	
4.2.3		
4.2.4		
4.2.5	- r	
4.2.6	- F	
4.2.7	J F	
4.2.7.	1	
4.2.7.		
4.2.7.		
4.2.7.		
4.2.7.	1	
4.2.7.		
4.2.7.		
4.2.7.	1 1	
4.2.7.		
4.2.7.	· · · · · · · · · · · · · · · · · · ·	
4.2.7.		
4.2.7.		
4.2.8		
4.2.9		
4.2.10		
4.2.10		
4.2.10		
4.2.11		
4.2.12		
4.2.13		
4.2.14	4 RRC buffer size	53

5	Option	al features without UE radio access capability parameters	53
6	Conditi	onally mandatory features without UE radio access capability parameters	53
7	Void		54
8	UE Ca <sub>j</sub>	pability Constraints	54
Anne	ex A (no	rmative): Differentiation of capabilities	55
Anne	x A.1:	TDD/FDD differentiation of capabilities in TDD-FDD CA	55
Anne	x A.2:	FR1/FR2 differentiation of capabilities in FR1-FR2 CA	56

## Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

#### where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

The present document defines the NR UE Radio Access Capability Parameters.

### 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
   [2] 3GPP TS 38.101-1: "NR; User Equipment (UE) radio transmission and reception Part 1: Range 1 Standalone".
- [3] 3GPP TS 38.101-2: "NR; User Equipment (UE) radio transmission and reception Part 2: Range 2 Standalone".
- [4] 3GPP TS 38.101-3: "NR; User Equipment (UE) radio transmission and reception Part 3: Range 1 and Range 2 Interworking operation with other radios".
- [5] 3GPP TS 38.133: "NR; Requirements for support of radio resource management".
- [6] 3GPP TS 38.211: "NR; Physical channels and modulation".
- [7] 3GPP TS 37.340: "Evolved Universal Terrestrial Radio Access (E-UTRA) and NR Multi-connectivity".
- [8] 3GPP TS 38.321: "NR; Medium Access Control (MAC) protocol specification".
- [9] 3GPP TS 38.331: "NR; Radio Resource Control (RRC) protocol specification".
- [10] 3GPP TS 38.212: "NR; Multiplexing and channel coding".
- [11] 3GPP TS 38.213: "NR; Physical layer procedures for control".
- [12] 3GPP TS 38.214: "NR; Physical layer procedures for data".
- [13] 3GPP TS 38.215: "NR; Physical layer measurements".
- [14] 3GPP TS 36.101: "Evolved Universal Terrestrial Radio Access (E-UTRA) radio transmission and reception".
- [15] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE) radio access capabilities".
- [16] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification".
- [17] 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource Control (RRC); Protocol Specification".
- [18] 3GPP TS 38.101-4: "NR; User Equipment (UE) radio transmission and reception Part 4: Performance requirements".
- [19] 3GPP TS 36.213: "Evolved Universal Terrestrial Radio Access (E-UTRA); Physical layer procedures".

## 3 Definitions, symbols and abbreviations

#### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

**Fallback band combination:** A band combination that would result from another band combination by releasing at least one SCell or uplink configuration of SCell, or SCG. An intra-band non-contiguous band combination is not considered to be a fallback band combination of an intra-band contiguous band combination.

**Fallback per band feature set:** A feature set per band that has same or lower values than the reported values from the reported feature set per band for a given band.

**Fallback per CC feature set:** A feature set per CC that has lower value of UE supported MIMO layers and BW while keeping the numerology and other parameters the same from the reported feature set per CC for a given carrier per band.

### 3.2 Symbols

For the purposes of the present document, the following symbols apply:

MaxDLDataRate: Maximum DL data rate

MaxDLDataRate\_MN: Maximum DL data rate in the MN MaxDLDataRate\_SN: Maximum DL data rate in the SN

MaxULDataRate: Maximum UL data rate

#### 3.3 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

BC Band Combination

DL Downlink FS Feature Set

FSPC Feature Set Per Component-carrier

MAC Medium Access Control MCG Master Cell Group MN Master Node

MR-DC Multi-RAT Dual Connectivity
PDCP Packet Data Convergence Protocol

RLC Radio Link Control
RTT Round Trip Time
SCG Secondary Cell Group

SDAP Service Data Adaptation Protocol

SN Secondary Node

UL Uplink

## 4 UE radio access capability parameters

### 4.1 Supported max data rate

#### 4.1.1 General

The DL and UL max data rate supported by the UE is calculated by band or band combinations supported by the UE. A UE supporting NR (NR SA, MR-DC) shall support the calculated DL and UL max data rate defined in 4.1.2.

#### 4.1.2 Supported max data rate

For NR, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

data rate (in Mbps) = 
$$10^{-6} \cdot \sum_{j=1}^{J} \left( v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)} \cdot R_{max} \cdot \frac{N_{PRB}^{BW(j),\mu} \cdot 12}{T_s^{\mu}} \cdot (1 - OH^{(j)}) \right)$$

wherein

J is the number of aggregated component carriers in a band or band combination

 $R_{max} = 948/1024$ 

For the j-th CC,

 $v_{\scriptscriptstyle Layers}^{(j)}$  is the maximum number of supported layers given by higher layer parameter  ${\it maxNumberMIMO}$ -

LayersPDSCH for downlink and maximum of higher layer parameters maxNumberMIMO-LayersCB-PUSCH and maxNumberMIMO-LayersNonCB-PUSCH for uplink.

 $Q_m^{(j)}$  is the maximum supported modulation order given by higher layer parameter supportedModulationOrderDL for downlink and higher layer parameter supportedModulationOrderUL for uplink.

 $f^{(j)}$  is the scaling factor given by higher layer parameter *scalingFactor* and can take the values 1, 0.8, 0.75, and 0.4

 $^{\mu}$  is the numerology (as defined in TS 38.211 [6])

 $T_s^{\mu}$  is the average OFDM symbol duration in a subframe for numerology  $T_s^{\mu} = \frac{10^{-3}}{14 \cdot 2^{\mu}}$ . Note that normal cyclic prefix is assumed.

 $N_{PRB}^{BW(j),\mu}$  is the maximum RB allocation in bandwidth  $BW^{(j)}$  with numerology  $\mu$ , as defined in 5.3 TS 38.101-1 [2] and 5.3 TS 38.101-2 [3], where  $BW^{(j)}$  is the UE supported maximum bandwidth in the given band or band combination.

 $OH^{(j)}$  is the overhead and takes the following values

0.14, for frequency range FR1 for DL

0.18, for frequency range FR2 for DL

0.08, for frequency range FR1 for UL

0.10, for frequency range FR2 for UL

NOTE: Only one of the UL or SUL carriers (the one with the higher data rate) is counted for a cell operating SUI

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For EUTRA in case of MR-DC, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

Data rate (in Mbps) = 
$$10^{-3} \cdot \sum_{j=1}^{J} TBS_j$$

wherein

J is the number of aggregated EUTRA component carriers in MR-DC band combination

 $TBS_j$  is the total maximum number of DL-SCH transport block bits received within a 1ms TTI for j-th CC, as derived from TS36.213 [19] based on the UE supported maximum MIMO layers for the j-th CC, and based on the maximum modulation order for the j-th CC and number of PRBs based on the bandwidth of the j-th CC according to indicated UE capabilities.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For MR-DC, the approximate maximum data rate is computed as the sum of the approximate maximum data rates from NR and EUTRA.

#### 4.1.3 Void

### 4.1.4 Total layer 2 buffer size

The total layer 2 buffer size is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reordering windows and also in PDCP reordering windows for all radio bearers.

The required total layer 2 buffer size in MR-DC and NR-DC is the maximum value of the calculated values based on the following equations:

- MaxULDataRate\_MN \* RLCRTT\_MN + MaxULDataRate\_SN \* RLCRTT\_SN + MaxDLDataRate\_SN \* RLCRTT\_SN + MaxDLDataRate\_MN \* (RLCRTT\_SN + X2/Xn delay + Queuing in SN)
- MaxULDataRate\_MN \* RLCRTT\_MN + MaxULDataRate\_SN \* RLCRTT\_SN + MaxDLDataRate\_MN \* RLCRTT\_MN + MaxDLDataRate\_SN \* (RLCRTT\_MN + X2/Xn delay + Queuing in MN)

Otherwise it is calculated by MaxDLDataRate \* RLC RTT + MaxULDataRate \* RLC RTT.

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported MR-DC or NR band combinations. The RLC RTT for NR cell group corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

wherein

X2/Xn delay + Queuing in SN = 25ms if SCG is NR, and 55ms if SCG is EUTRA

X2/Xn delay + Queuing in MN = 25ms if MCG is NR, and 55ms if MCG is EUTRA

RLC RTT for EUTRA cell group = 75ms

RLC RTT for NR cell group is defined in Table 4.1.4-1

Table 4.1.4-1: RLC RTT for NR cell group per SCS

SCS (KHz)	RLC RTT (ms)
15KHz	50
30KHz	40
60KHz	30
120KHz	20

### 4.2 UE Capability Parameters

#### 4.2.1 Introduction

The following clauses define the UE radio access capability parameters. Only parameters for which there is the possibility for UEs to signal different values are considered as UE radio access capability parameters. Therefore, mandatory features without capability parameters that are the same for all UEs are not listed here.

The network needs to respect the signalled UE radio access capability parameters when configuring the UE and when scheduling the UE.

The UE may support different functionalities between FDD and TDD, and/or between FR1 and FR2. The UE shall indicate the UE capabilities as follows. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "FDD-TDD DIFF" and "FR1-FR2 DIFF" indicates the UE capability field can have a different value for between FDD and TDD or between FR1 and FR2 and "No" indicates if it cannot. "FD" in the column indicates to refer the associated field description. "FR1 only" or "FR2 only" in the column indicates the associated feature is only supported in FR1 or FR2 and "TDD only" indicates the associated feature is only supported in TDD.

- 1> set all fields of UE-NR/MRDC-Capability except fdd-Add-UE-NR/MRDC-Capabilities, tdd-Add-UE-NR/MRDC-Capabilities, fr1-Add-UE-NR/MRDC-Capabilities and fr2-Add-UE-NR/MRDC-Capabilities, to include the values applicable for all duplex mode(s) and frequency range(s) that the UE supports;
- 1> if UE supports both FDD and TDD and if (some of) the UE capability fields have a different value for FDD and TDD
  - 2> if for FDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
    - 3> include field fdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FDD;
  - 2> if for TDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
    - 3> include field tdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for TDD;
- 1> if UE supports both FR1 and FR2 and if (some of) the UE capability fields have a different value for FR1 and FR2:
  - 2> if for FR1, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
    - 3> include field fr1-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR1;
  - 2> if for FR2, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
    - 3> include field fr2-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR2;

NOTE: The fields which indicate "shall be set to 1" or "shall be set to *supported*" in the following tables means these features are purely mandatory and are assumed they are the same as mandatory without capability signaling.

For optional features, the UE radio access capability parameter indicates whether the feature has been implemented and successfully tested. For mandatory features with the UE radio access capability parameter, the parameter indicates whether the feature has been successfully tested. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "M" indicates the associated feature is mandatory and "No" indicates the associated feature is optional. "CY" in the column indicates the associated feature is conditional mandatory and the condition is described in the field description. "FD" in the column indicates to refer the associated field description. Some parameters in subsequent clauses are not related to UE features and in the case, "N/A" is indicated in the column.

UE capability parameters have hierarchical structure. In the table of UE capability parameter in subsequent clauses, "Per" indicates the level the associated parameter is included. "UE" in the column indicates the associated parameter is signalled per UE, "Band" indicates it is signalled per band, "BC" indicates it is signalled per band combination, "FS" indicates it is signalled per feature set (per band per band combination), "FSPC" indicates it is signalled per feature set per component carrier (per CC per band per band combination), and "FD" in the column indicates to refer the associated field description.

### 4.2.2 General parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
accessStratumRelease	UE	Yes	No	No
Indicates the access stratum release the UE supports as specified in TS 38.331 [9].				
delayBudgetReporting Indicates whether the UE supports delay budget reporting as specified in TS 38.331 [9].	UE	No	No	No
inactiveState	UE	Yes	No	No
Indicates whether the UE supports RRC_inactive as specified in TS 38.331 [9].				
overheatingInd Indicates whether the UE supports overheating assistance information.	UE	No	No	No
reducedCP-Latency Indicates whether the UE supports reduced control plane latency as defined in TS 38.331 [9]	UE	No	No	No
splitSRB-WithOneUL-Path Indicates whether the UE supports UL transmission via MCG path and DL reception via either MCG path or SCG path, as specified for the split SRB in TS 37.340 [7]. The UE shall only set the bit in UE-MRDC-Capability -> generalParametersMRDC. It shall not set the FDD/TDD specific fields.	UE	No	No	No
splitDRB-withUL-Both-MCG-SCG Indicates whether the UE supports UL transmission via both MCG path and SCG path for the split DRB as specified in TS 37.340 [7]. The UE shall only set the bit in UE-MRDC-Capability -> generalParametersMRDC. It shall not set the FDD/TDD specific fields.	UE	Yes	No	No
srb3 Indicates whether the UE supports direct SRB between the SN and the UE as specified in TS 37.340 [7]. The UE shall only set the bit in UE-MRDC-Capability -> generalParametersMRDC. It shall not set the FDD/TDD specific fields. This field is not applied to NE-DC.	UE	Yes	No	No
v2x-EUTRA Indicates whether the UE supports EUTRA V2X according to UE-EUTRA-Capability as defined in TS 36.331 [17], independent of the configured EN-DC band combination. This field is only applied to EN-DC. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No

## 4.2.3 SDAP Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
as-ReflectiveQoS	UE	No	No
Indicates whether the UE supports AS reflective QoS.			

## 4.2.4 PDCP Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
continueROHC-Context Defines whether the UE supports ROHC context continuation operation where the UE does not reset the current ROHC context upon PDCP re-establishment, as specified in TS 38.323 [16].	UE	No	No
maxNumberROHC-ContextSessions  Defines the maximum number of header compression context sessions supported by the UE, excluding context sessions that leave all headers uncompressed.	UE	No	No
outOfOrderDelivery Indicates whether UE supports out of order delivery of data to upper layers by PDCP.	UE	No	No
pdcp-DuplicationMCG-OrSCG-DRB Indicates whether the UE supports CA-based PDCP duplication over MCG or SCG DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitDRB Indicates whether the UE supports PDCP duplication over split DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitSRB Indicates whether the UE supports PDCP duplication over split SRB1/2 as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSRB Indicates whether the UE supports CA-based PDCP duplication over SRB1/2 and/or, if EN-DC is supported, SRB3 as specified in TS 38.323 [16].	UE	No	No
shortSN Indicates whether the UE supports 12 bit length of PDCP sequence number.	UE	Yes	No
supportedROHC-Profiles  Defines which ROHC profiles from the list below are supported by the UE:  - 0x0000 ROHC No compression (RFC 5795)  - 0x0001 ROHC RTP/UDP/IP (RFC 3095, RFC 4815)  - 0x0002 ROHC UDP/IP (RFC 3095, RFC 4815)  - 0x0003 ROHC ESP/IP (RFC 3095, RFC 4815)  - 0x0004 ROHC IP (RFC 3843, RFC 4815)  - 0x0006 ROHC TCP/IP (RFC 6846)  - 0x0101 ROHC RTP/UDP/IP (RFC 5225)  - 0x0102 ROHC UDP/IP (RFC 5225)  - 0x0103 ROHC ESP/IP (RFC 5225)  - 0x0104 ROHC IP (RFC 5225)  A UE that supports one or more of the listed ROHC profiles shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).	UE	No	No
<ul> <li>uplinkOnlyROHC-Profiles</li> <li>Indicates which ROHC profile(s) from the list below are supported in uplink-only ROHC operation by the UE.</li> <li>0x0006 ROHC TCP (RFC 6846)</li> <li>A UE that supports uplink-only ROHC profile(s) shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).</li> </ul>	UE	No	No

## 4.2.5 RLC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
am-WithShortSN	UE	Yes	No
Indicates whether the UE supports AM DRB with 12 bit length of RLC sequence number.			
um-WlthLongSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number.			
um-WithShortSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 6 bit length of RLC sequence number.			

## 4.2.6 MAC parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
Ich-ToSCellRestriction Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of serving cells (see allowedServingCells in LogicalChannelConfig). A UE supporting pdcp-DuplicationMCG-OrSCG-DRB or pdcp-DuplicationSRB (see PDCP-Config) shall also support Ich-ToSCellRestriction.	UE	No	No	No
Icp-Restriction Indicates whether UE supports the selection of logical channels for each UL grant based on RRC configured restriction.	UE	No	No	No
IogicalChannelSR-DelayTimer Indicates whether the UE supports the logicalChannelSR-DelayTimer as specified in TS 38.321 [8].	UE	No	Yes	No
IongDRX-Cycle Indicates whether UE supports long DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
multipleConfiguredGrants Indicates whether UE supports more than one configured grant configurations (including both Type 1 and Type 2) in a cell group. For each cell, the UE supports at most one configured grant per BWP and the maximum number of configured grant configurations per cell group is 2. If absent, for each configured cell group, the UE only supports one configured grant configuration on one serving cell.	UE	No	Yes	No
multipleSR-Configurations Indicates whether the UE supports 8 SR configurations per PUCCH cell group as specified in TS 38.321 [8].	UE	No	Yes	No
recommendedBitRate Indicates whether the UE supports the bit rate recommendation message from the gNB to the UE as specified in TS 38.321 [8].	UE	No	No	No
recommendedBitRateQuery Indicates whether the UE supports the bit rate recommendation query message from the UE to the gNB as specified in TS 38.321 [8]. This field is only applicable if the UE supports recommendedBitRate.	UE	No	No	No
shortDRX-Cycle Indicates whether UE supports short DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
skipUplinkTxDynamic Indicates whether the UE supports skipping of UL transmission for an uplink grant indicated on PDCCH if no data is available for transmission as specified in TS 38.321 [8].	UE	No	Yes	No

- 4.2.7 Physical layer parameters
- 4.2.7.1 BandCombinationList parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101.	Band	Yes	No	No
bandList  Each entry of the list should include at least one bandwidth class for UL or DL.	ВС	Yes	No	No
bandNR  Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	No	No
ca-BandwidthClassDL-EUTRA  Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	No	No
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	No	No
ca-BandwidthClassUL-EUTRA  Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	No	No
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	No	No
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given EN-DC band combination.	BC	No	No	No
ca-ParametersNR  Contains the NR band combination parameters for a given EN-DC and/or NR CA band combination.	ВС	No	No	No
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG.	ВС	No	No	No
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	ВС	N/A	No	No
mrdc-Parameters Contains the band combination parameters for a given EN-DC band combination.	ВС	No	No	No
ne-DC-BC Indicates whether the UE supports NE-DC for the band combination.	BC	No	No	No
powerClass Indicates power class the UE supports when operating according to this band combination. If the field is absent, the UE supports the default power class. If this power class is higher than the power class that the UE supports on the individual bands of this band combination (ue-PowerClass in BandNR), the latter determines maximum TX power available in each band. The UE sets the power class parameter only in band combinations with two FR1 uplink serving cells.	BC	No	No	FR1 only
srs-SwitchingTimeNR Indicates the interruption time on DL/UL reception within a NR band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. switchingTimeDL/ switchingTimeUL: n0 represents 0 us, n30us represents 30us, and so on. switchingTimeDL/ switchingTimeDL is mandatory present if switching between the NR band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	No	No

indicates the interruption time on DL/UL reception within a EUTRA band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. switchingTimeDL/switchingTimeUL: n0 represents 0 OFDM symbols, n0dot5 represents 0.5 OFDM symbols, n1 represents 1 OFDM symbol and so on. switchingTimeDL/switchingTimeUL is mandatory present if switching between the EUTRA band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	No	No
SRS-TxSwitch Defines whether UE supports SRS for DL CSI acquisition as defined in clause	ВС	Yes	No	No
6.2.1.2 of TS 38.214 [12]. The capability signalling comprises of the following				
parameters:				
<ul> <li>supportedSRS-TxPortSwitch indicates SRS Tx port switching pattern supported by the UE. The indicated UE antenna switching capability of 'xTyR' corresponds to a UE, capable of SRS transmission on 'x' antenna ports over total of 'y' antennas, where 'y' corresponds to all or subset of UE receive antennas, where 2T4R is two pairs of antennas;</li> </ul>				
<ul> <li>txSwitchImpactToRx indicates the entry number of the first-listed band with UL in the band combination that affects this DL;</li> </ul>				
<ul> <li>txSwitchWithAnotherBand indicates the entry number of the first-listed band with UL in the band combination that switches together with this UL.</li> </ul>				
For txSwitchImpactToRx and txSwitchWithAnotherBand, value 1 means first entry, value 2 means second entry and so on. All DL and UL that switch together indicate the same entry number.				
The UE is restricted not to include fallback band combinations for the purpose of				
indicating different SRS antenna switching capabilities.				
supportedBandwidthCombinationSet	BC	CY	No	No
Defines the supported bandwidth combination for the band combination set as				
defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N				
for this band combination as defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS				
38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth				
Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1				
and so on. It is mandatory if the band combination has more than one NR carrier (at				
least one SCell in an NR cell group) or is an intra-band EN-DC combination or both.				

## 4.2.7.2 BandNR parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalActiveTCI-StatePDCCH Indicates whether the UE supports one additional active TCI-State for control in addition to the supported number of active TCI-States for PDSCH. The UE can include this field only if maxNumberActiveTCI-PerBWP in tci-StatePDSCH is set to n1. Otherwise, the UE does not include this field.	Band	Yes	No	No
aperiodicBeamReport Indicates whether the UE supports aperiodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH. The UE provides the capability for the band number for which the report is provided (where the measurement is performed).	Band	Yes	No	No
aperiodicTRS Indicates whether the UE supports DCI triggering aperiodic TRS associated with periodic TRS.	Band	No	No	Yes
bandNR  Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	No	No
beamCorrespondenceWithoutUL-BeamSweeping Indicates how UE supports FR2 beam correspondence as specified in TS 38.101-2 [3], clause 6.6. The UE that fulfils the beam correspondence requirement without the uplink beam sweeping (as specified inTS 38.101-2 [3], clause 6.6) shall set the bit to 1. The UE that fulfils the beam correspondence requirement with the uplink beam sweeping (as specified inTS 38.101-2 [3], clause 6.6) shall set the bit to 0.	Band	Yes	No	FR2 only
<ul> <li>beamManagementSSB-CSI-RS</li> <li>Defines support of SS/PBCH and CSI-RS based RSRP measurements. The capability comprises signalling of         <ul> <li>maxNumberSSB-CSI-RS-ResourceOneTx indicates maximum total number of configured one port NZP CSI-RS resources and SS/PBCH blocks that are supported by the UE for 'CRI/RSRP' and 'SSBRI/RSRP' reporting within a slot and across all serving cells (see NOTE). On FR2, it is mandatory to report &gt;=8; On FR1, it is mandatory with capability signalling to report &gt;=8.</li> <li>maxNumberCSI-RS-Resource indicates maximum total number of configured NZP-CSI-RS resources that are supported by the UE for 'CRI/RSRP' reporting across all serving cells (see NOTE). It is mandated to report at least n8 for FR1.</li> <li>maxNumberCSI-RS-ResourceTwoTx indicates maximum total number of two ports NZP CSI-RS resources that are supported by the UE for 'CRI/RSRP' reporting within a slot and across all serving cells (see NOTE).</li> <li>supportedCSI-RS-Density indicates density of one RE per PRB for one port NZP CSI-RS resource for RSRP reporting, if supported. On FR2, it is mandatory to report either "three" or "oneAndThree"; On FR1, it is mandatory with capability signalling to report either "three" or "oneAndThree".</li> <li>maxNumberAperiodicCSI-RS-Resource indicates maximum number of configured aperiodic CSI-RS resources across all serving cells (see NOTE). For FR1 and FR2, the UE is mandated to report at least n4.</li> </ul> </li> <li>NOTE: If the UE sets a value other than n0 in an FR1 band, it shall set that same value in all FR1 bands. If the UE sets a value other than n0 in an FR2 band, it shall set that same value in all FR1 bands. If the UE sets a value other than n0 in an FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells.</li> </ul>	Band	Yes	No	Yes
beamReportTiming Indicates the number of OFDM symbols between the last symbol of SSB/CSI-RS and the first symbol of the transmission channel containing beam report. The UE provides the capability for the band number for which the report is provided (where the measurement is performed). The UE includes this field for each supported subcarrier spacing.	Band	Yes	No	No

beamSwitchTiming Indicates the minimum number of OFDM symbols between the DCI triggering of aperiodic CSI-RS and aperiodic CSI-RS transmission. The number of OFDM symbols is measured from the last symbol containing the indication to the first symbol of CSI-RS. The UE includes this field for each supported sub-carrier spacing.	Band	No	No	FR2 only
bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is SSB on SCell(s).	Band	No	No	No
bwp-SameNumerology Defines type A/B BWP adaptation (up to 2/4 BWPs) with the same numerology, via DCI and timer. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is SSB on SCell(s).	Band	No	No	No
bwp-WithoutRestriction Indicates support of BWP operation without bandwidth restriction. The Bandwidth restriction in terms of DL BWP for PCell and PSCell means that the bandwidth of a UE-specific RRC configured DL BWP may not include the bandwidth of CORESET #0 (if configured) and SSB. For SCell(s), it means that the bandwidth of DL BWP may not include SSB.	Band	No	No	No
ChannelBWs-DL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-DL for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.  NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingDL and the scs-60kHz.  To determine whether the UE supports a channel bandwidth of 90 MHz, the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-DL, the supportedBandwidthCombinationSet and supportedBandwidthDL.	Band	Yes	No	No
<i>channelBWs-UL</i> Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the <i>channelBWs-UL</i> for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.	Band	Yes	No	No
NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz.  To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombiantionSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet and supportedBandwidthUL.				

codebookParameters	Band	FD	No	No
Indicates the codebooks and the corresponding parameters supported by the UE.				
Parameters for type I single panel codebook (type1 singlePanel) supported by the UE, which is mandatory to report:  - supportedCSI-RS-ResourceList;  - modes indicates supported codebook modes (mode 1, both mode 1 and mode 2);  - maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI-RS resource in a resource set.  Parameters for type I multi-panel codebook (type1 multiPanel) supported by the UE, which is optional:  - supportedCSI-RS-ResourceList;				
<ul> <li>modes indicates supported codebook modes (mode 1, mode 2, or both mode 1 and mode 2);</li> <li>maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI-RS resource in a resource set;</li> <li>nrofPanels indicates supported number of panels.</li> </ul>				
Parameters for type II codebook (type2) supported by the UE, which is optional:  - supportedCSI-RS-ResourceList;  - parameterLx indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by maxNumberTxPortsPerResource;  - amplitudeScalingType indicates the amplitude scaling type supported by the UE (wideband or both wideband and sub-band);  - amplitudeSubsetRestriction indicates whether amplitude subset restriction is supported for the UE.				
Parameters for type II codebook with port selection (type2-PortSelection) supported by the UE, which is optional:  - supportedCSI-RS-ResourceList;  - parameterLx indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by maxNumberTxPortsPerResource;  - amplitudeScalingType indicates the amplitude scaling type supported by the UE (wideband or both wideband and sub-band).				
<ul> <li>supportedCSI-RS-ResourceList includes list of the following parameters:         <ul> <li>maxNumberTxPortsPerResource indicates the maximum number of Tx ports in a resource;</li> <li>maxNumberResourcesPerBand indicates the maximum number of resources across all CCs within a band simultaneously;</li> <li>totalNumberTxPortsPerBand indicates the total number of Tx ports across all CCs within a band simultaneously.</li> </ul> </li> </ul>				
crossCarrierScheduling-SameSCS Indicates whether the UE supports cross carrier scheduling for the same numerology with carrier indicator field (CIF) in carrier aggregation where numerologies for the scheduling cell and scheduled cell are same.	Band	No	No	No

	Band or UE	Yes	No	No
number of periodic Correport setting per DVVP for Correport,				
<ul> <li>maxNumberPeriodicCSI-PerBWP-ForBeamReport indicates the maximum number of periodic CSI report setting per BWP for beam report.</li> </ul>				
<ul> <li>maxNumberAperiodicCSI-PerBWP-ForCSI-Report indicates the maximum number of aperiodic CSI report setting per BWP for CSI report;</li> </ul>				
<ul> <li>maxNumberAperiodicCSI-PerBWP-ForBeamReport indicates the maximum number of aperiodic CSI report setting per BWP for beam report;</li> </ul>				
<ul> <li>maxNumberAperiodicCSI-triggeringStatePerCC indicates the maximum number of aperiodic CSI triggering states in CSI-AperiodicTriggerStateList per CC;</li> </ul>				
<ul> <li>maxNumberSemiPersistentCSI-PerBWP-ForCSI-Report indicates the maximum number of semi-persistent CSI report setting per BWP for CSI report;</li> </ul>				
<ul> <li>maxNumberSemiPersistentCSI-PerBWP-ForBeamReport indicates the maximum number of semi-persistent CSI report setting per BWP for beam report;</li> </ul>				
<ul> <li>simultaneousCSI-ReportsPerCC indicates the number of CSI report(s) for which the UE can measure and process reference signals simultaneously in a CC of the band for which this capability is provided. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in simultaneousCSI- ReportsPerCC includes the beam report and CSI report.</li> </ul>				
	Band	Yes	No	No
Indicates support of CSI-RS for tracking (i.e. TRS). This capability signalling				
comprises the following parameters:  - maxBurstLength indicates the TRS burst length. Value 1 indicates 1 slot and value 2 indicates both of 1 slot and 2 slots. In this release UE is mandated to report value 2;				
<ul> <li>maxSimultaneousResourceSetsPerCC indicates the maximum number of TRS resource sets per CC which the UE can track simultaneously;</li> </ul>				
<ul> <li>maxConfiguredResourceSetsPerCC indicates the maximum number of TRS resource sets configured to UE per CC. It is mandated to report at least 8 for FR1 and 16 for FR2;</li> </ul>				
- maxConfiguredResourceSetsAllCC indicates the maximum number of TRS resource sets configured to UE across CCs. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. The UE is mandated to report at least 16 for FR1 and 32 for FR2.				

csi-RS-IM-ReceptionForFeedback Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters:  - maxConfigNumberNZP-CSI-RS-PerCC indicates the maximum number of configured NZP-CSI-RS resources per CC;	Band or UE	Yes	No	No
<ul> <li>maxConfigNumberPortsAcrossNZP-CSI-RS-PerCC indicates the maximum number of ports across all configured NZP-CSI-RS resources per CC;</li> </ul>				
<ul> <li>maxConfigNumberCSI-IM-PerCC indicates the maximum number of configured CSI-IM resources per CC;</li> </ul>				
<ul> <li>maxNumberSimultaneousNZP-CSI-RS-PerCC indicates the maximum number of simultaneous CSI-RS-resources per CC;</li> </ul>				
<ul> <li>totalNumberPortsSimultaneousNZP-CSI-RS-PerCC indicates the total number of CSI-RS ports in simultaneous CSI-RS resources per CC.</li> </ul>				
csi-RS-ProcFrameworkForSRS	Band	No	No	No
Indicates support of CSI-RS processing framework for SRS. This capability signalling comprises the following parameters:	or UE	110	110	
<ul> <li>maxNumberPeriodicSRS-AssocCSI-RS-PerBWP indicates the maximum number of periodic SRS resources associated with CSI-RS per BWP;</li> </ul>				
<ul> <li>maxNumberAperiodicSRS-AssocCSI-RS-PerBWP indicates the maximum number of aperiodic SRS resources associated with CSI-RS per BWP;</li> </ul>				
<ul> <li>maxNumberSP-SRS-AssocCSI-RS-PerBWP indicates the maximum number of semi-persistent SRS resources associated with CSI-RS per BWP;</li> </ul>				
<ul> <li>simultaneousSRS-AssocCSI-RS-PerCC indicates the number of SRS resources that the UE can process simultaneously in a CC, including periodic, aperiodic and semi-persistent SRS.</li> </ul>				
extendedCP	Band	No	No	No
Indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for reception of PDCCH, and PDSCH, and transmission of PUCCH, PUSCH, and SRS.	Ballu	INO	INO	NO
groupBeamReporting Indicates whether UE supports RSRP reporting for the group of two reference signals.	Band	No	No	No
maxNumberCSI-RS-BFD	Band	CY	No	No
Indicates maximal number of CSI-RS resources across all CCs, and across MCG and SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the maximum value that can be signalled is 16. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1.	Dana			
maxNumberCSI-RS-SSB-CBD  Defines maximal number of different CSI-RS [and/or SSB] resources across all CCs, and across MCG and SCG in case of NR-DC, for new beam identifications. In this release, the maximum value that can be signalled is 128. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1. The UE is mandated to report at least 32 for FR2.	Band	CY	No	No
maxNumberNonGroupBeamReporting Defines support of non-group based RSRP reporting using N_max RSRP values reported.	Band	Yes	No	No

maxNumberRxBeam	Band	CY	No	No
Defines whether UE supports receive beamforming switching using NZP CSI-RS				
resource. UE shall indicate a single value for the preferred number of NZP CSI-RS				
resource repetitions per CSI-RS resource set. Support of Rx beam switching is				
mandatory for FR2.	ļ			
maxNumberRxTxBeamSwitchDL	Band	No	No	FR2
Defines the number of Tx and Rx beam changes UE can perform on this band				only
within a slot. UE shall report one value per each subcarrier spacing supported by				
the UE. In this release, the number of Tx and Rx beam changes for scs-15kHz and				
scs-30kHz are not included.	D	0)/	NI.	NI.
maxNumberSSB-BFD	Band	CY	No	No
Defines maximal number of different SSBs across all CCs, and across MCG and				
SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the				
maximum value that can be signalled is 16. If the UE includes the field in an FR1				
band, it shall set the same value in all FR1 bands. If the UE includes the field in an				
FR2 band, it shall set the same value in all FR2 bands. The UE supports a total				
number of resources equal to the maximum of the FR1 and FR2 value, but no more				
than the FR1 value across all FR1 serving cells and no more than the FR2 value				
across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1.				
maxUplinkDutyCycle-PC2-FR1	Band	No	No	FR1
Indicates the maximum percentage of symbols during a certain evaluation period	Daliu	INO	INO	only
that can be scheduled for uplink transmission so as to ensure compliance with				Offity
applicable electromagnetic energy absorption requirements provided by regulatory				
bodies. This field is only applicable for FR1 power class 2 UE as specified in clause				
6.2.1 of TS 38.101-1 [2]. If the field is absent, 50% shall be applied. Value n60				
corresponds to 60%, value n70 corresponds to 70% and so on.				
maxUplinkDutyCycle-FR2	Band	No	No	FR2
	Danu	INO	INO	
Indicates the maximum percentage of symbols during 1s that can be scheduled for uplink transmission so as to ensure compliance with applicable electromagnetic				only
power density exposure requirements provided by regulatory bodies. This field is				
applicable for all power classes UE in FR2 as specified in TS 38.101-2 [3]. Value				
n15 corresponds to 15%, value n20 corresponds to 20% and so on. If the field is				
absent or the percentage of uplink symbols transmitted within any 1s evaluation				
period is larger than <i>maxUplinkDutyCycle-FR2</i> , the UE behaviour is specified in TS				
38.101-2 [3].				
modifiedMPR-Behaviour	Band	No	No	No
Indicates whether UE supports modified MPR behaviour defined in TS 38.101-1 [2]	Dana	110	110	140
and TS 38.101-2 [3].				
multipleTCI	Band	Yes	No	No
Indicates whether UE supports more than one TCI state configurations per	Dania	. 55	'10	'10
CORESET. UE is only required to track one active TCI state per CORESET. UE is				
required to support minimum between 64 and number of configured TCI states				
indicated by <i>tci-StatePDSCH</i> . This field shall be set to <i>supported</i> .				
pdsch-256QAM-FR2	Band	No	No	FR2
Indicates whether the UE supports 256QAM modulation scheme for PDSCH for	Dana			only
FR2 as defined in 7.3.1.2 of TS 38.211 [6].				51119
periodicBeamReport	Band	Yes	No	No
Indicates whether UE supports periodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting	Dana	. 55		
using PUCCH formats 2, 3 and 4 in one slot.				
powerBoosting-pi2BPSK	Band	No	TDD	FR1
Indicates whether UE supports power boosting for pi/2 BPSK, when applicable as	Dana		only	only
defined in 6.2 of TS 38.101-1 [2].			Oilly	Oilly
ptrs-DensityRecommendationSetDL	Band	CY	No	No
For each supported sub-carrier spacing, indicates preferred threshold sets for	Dana		10	.
determining DL PTRS density. It is mandated for FR2. For each supported sub-				
carrier spacing, this field comprises:				
- two values of <i>frequencyDensity</i> ;				
the values of hogaeney benout,				
- three values of timeDensity.				
•				

ptrs-DensityRecommendationSetUL For each supported sub-carrier spacing, indicates preferred threshold sets for determining UL PTRS density. For each supported sub-carrier spacing, this field comprises:	Band	No	No	No
- two values of <i>frequencyDensity</i> ;				
- three values of <i>timeDensity</i> ;				
- five values of sampleDensity.				
pucch-SpatialRelInfoMAC-CE Indicates whether the UE supports indication of PUCCH-spatialrelationinfo by a MAC CE per PUCCH resource. It is mandatory for FR2 and optional for FR1.	Band	CY	No	No
pusch-256QAM Indicates whether the UE supports 256QAM modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6].	Band	No	No	No
pusch-TransCoherence Defines support of the uplink codebook subset by the UE for UL precoding for PUSCH transmission as described in clause 6.1.1.1 of TS 38.214 [12]. UE indicated support of partial coherent codebook subset shall also support non-coherent codebook subset. UE indicated support of full coherent codebook subset shall also support partial and non-coherent codebook subset.	Band	No	No	No
rateMatchingLTE-CRS Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs determined by the higher layer configuration LTE-carrier configuring common RS, as specified in TS 38.214 [12].	Band	Yes	No	No
<ul> <li>spatialRelations</li> <li>Indicates whether the UE supports spatial relations. The capability signalling comprises the following parameters.         <ul> <li>maxNumberConfiguredSpatialRelations indicates the maximum number of configures spatial relations per CC for PUCCH and SRS. It is not applicable to FR1 and applicable to FR2 only. The UE is mandated to report 16 or higher values;</li> </ul> </li> </ul>	Band	FD	No	FD
<ul> <li>maxNumberActiveSpatialRelations indicates the maximum number of active spatial relations with regarding to PUCCH and SRS for PUSCH, per BWP per CC. It is not applicable to FR1 and applicable and mandatory to report for FR2 only;</li> </ul>				
<ul> <li>additionalActiveSpatialRelationPUCCH indicates support of one additional active spatial relations for PUCCH. It is mandatory with capability signalling if maxNumberActiveSpatialRelations is set to 1;</li> </ul>				
<ul> <li>maxNumberDL-RS-QCL-TypeD indicates the maximum number of downlink RS resources used for QCL type D in the active TCl states and active spatial relation information, which is optional.</li> </ul>				
sp-BeamReportPUCCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot.	Band	No	No	Yes
sp-BeamReportPUSCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH.	Band	No	No	Yes
Srs-AssocCSI-RS  Parameters for the calculation of the precoder for SRS transmission based on channel measurements using associated NZP CSI-RS resource (srs-AssocCSI-RS) as described in clause 6.1.1.2 of TS 38.214 [12]. UE supporting this feature shall also indicate support of non-codebook based PUSCH transmission.  This capability signalling includes list of the following parameters:  - maxNumberTxPortsPerResource indicates the maximum number of Tx ports in a resource;  - maxNumberResourcesPerBand indicates the maximum number of resources	Band	No	No	No
across all CCs within a band simultaneously;				
<ul> <li>totalNumberTxPortsPerBand indicates the total number of Tx ports across all CCs within a band simultaneously.</li> </ul>				

following parameters:	CH. The capability signalling comprises the	Band	Yes	No	No
configured TCI-states per CC f	esPerCC indicates the maximum number of or PDSCH. For FR2, the UE is mandated to be UE is mandated to set these values to the SBs in the supported band;				
TCI-states per BWP per CC, in active TCI state(s), it is not exp assumption(s) for any PDSCH	P indicates the maximum number of activated cluding control and data. If a UE reports X ected that more than X active QCL type D and any CORESETs for a given BWP of a he UE. The UE shall include this field.				
Note the UE is required to track only the	ne active TCI states.				
twoPortsPTRS-UL	with 2 antenna ports for UL transmission.	Band	No	No	No
ue-PowerClass	at LIC never close them the defects LIC never	Band	Yes	No	No
class as defined in clause 6.2 of TS 38	nt UE power class than the default UE power 3.101-1 [2], the UE shall report the supported UE shall report the supported UE power class 101-2 [3] in this field				
uplinkBeamManagement Defines support of beam managemen	t for UL. The capability include indication of	Band	No	No	FR2 only
the - Maximum number of SRS resour beam management, supported	ces per SRS resource set configurable for by the UE.				
Maximum number of SRS resour supported by the UE.	ce sets configurable for beam management,				
	dithoutUL-BeamSweeping to 0, the UE shall hal for the UE supports beam correspondence hed in clause 6.6, TS 38.101-2 [3].				
maximum number of SRS r	berSRS-ResourceSet to determine on the esource sets that can be configured to the UE aperiodic configurations as below:				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-	Additional constraint on the maximum number of SRS resource sets configured to the UE for each supported time domain behaviour				
persistent/aperiodic) reported in maxNumberSRS-ResourceSet	(periodic/semi-persistent/aperiodic)				
1 2	1				
3	1				
4	2				
5	2				
6	2				
7	4				
8	4				

### 4.2.7.3 CA-ParametersEUTRA

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalRx-Tx-PerformanceReq additionalRx-Tx-PerformanceReq defined in 4.3.5.22, TS 36.306 [15].	BC	No	No	No
dI-1024QAM-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned EN-DC band combination the UE can process for 1024QAM, as described in TS 36.306 [15] equation 4.3.5.31-1. Actual value = (10 + indicated value x 2), i.e. value 0 indicates 10 layers, value 1 indicates 12 layers and so on. For an EN-DC band combination for which this field is not included, dI-1024QAM-TotalWeightedLayers-r15 as described in TS 36.331 [17] applies, if included.	BC	No	No	No
multipleTimingAdvance multipleTimingAdvance defined in 4.3.5.3, TS 36.306 [15].	ВС	No	No	No
simultaneousRx-Tx simultaneousRx-Tx defined in 4.3.5.4, TS 36.306 [15].	ВС	No	No	No
supportedBandwidthCombinationSetEUTRA Indicates the set of supported bandwidth combinations for the LTE part for interband EN-DC. The field is encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. The UE shall neither include the field for a EN-DC combination which has only one LTE carrier, nor for a EN-DC combination which has more than one LTE carrier for which the UE only supports Bandwidth Combination Set 0 for the LTE part. If the inter-band EN-DC has more than one LTE carrier, the UE shall support at least one bandwidth combination for the supported LTE part.	BC	CY	No	No
supportedNAICS-2CRS-AP supportedNAICS-2CRS-AP defined in 4.3.5.8, TS 36.306 [15].	BC	No	No	No
fd-MIMO-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned EN-DC band combination the UE can process for FD-MIMO, as described in TS 36.306 [15] equation 4.3.28.13-1 and TS 36.331 [17] clause 6.3.6, NOTE 8 in UE-EUTRA-Capability field descriptions. For an EN-DC band combination for which this field is not included, totalWeightedLayers-r13 as described in TS 36.331 [17] applies, if included.	BC	No	No	No
ue-CA-PowerClass-N defined in 4.3.5.1.3, TS 36.306 [15].	ВС	No	No	No

### 4.2.7.4 *CA-ParametersNR*

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
csi-RS-IM-ReceptionForFeedbackPerBandComb Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters:  - maxNumberSimultaneousNZP-CSI-RS-ActBWP-AllCC indicates the maximum number of simultaneous CSI-RS resources in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. This parameter limits the total number of NZP-CSI-RS resources that the NW may configure across all CCs, and across MCG and SCG in case of NR-DC (irrespective of the associated codebook type). The network applies this limit in addition to the limits signalled in MIMO-ParametersPerBand-> maxNumberSimultaneousNZP-CSI-RS-PerCC and in Phy-ParametersFRX-Diff-> maxNumberSimultaneousNZP-CSI-RS-PerCC;	BC	Yes	No	No
- totalNumberPortsSimultaneousNZP-CSI-RS-ActBWP-AllCC indicates the total number of CSI-RS ports in simultaneous CSI-RS resources in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. This parameter limits the total number of ports that the NW may configure across all NZP-CSI-RS resources across all CCs, and across MCG and SCG in case of NR-DC (irrespective of the associated codebook type). The network applies this limit in addition to the limits signalled in MIMO-ParametersPerBand-> totalNumberPortsSimultaneousNZP-CSI-RS-PerCC and in Phy-ParametersFRX-Diff-> totalNumberPortsSimultaneousNZP-CSI-RS-PerCC.				
diffNumerologyAcrossPUCCH-Group Indicates whether different numerology across two NR PUCCH groups for data and control channel at a given time in NR CA and EN-DC is supported by the UE.	ВС	No	No	No
diffNumerologyWithinPUCCH-GroupLargerSCS Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, EN-DC/NE-DC and NR-DC. In case of NR CA and EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with larger SCS for data and control channel at a given time. In case of EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with larger SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time.  In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with larger SCS for data/control channel at a given time; and same numerology across NR carriers in SCG (in FR2).	BC	No	No	No
diffNumerologyWithinPUCCH-GroupSmallerSCS Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, EN-DC/NE-DC and NR-DC. In case of NR CA and EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with smaller SCS for data and control channel at a given time. In case of EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with smaller SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with smaller SCS for data/control channel at a given time; and same numerology across NR carriers in SCG (in FR2).	BC	No	No	No

dualPA-Architecture  For band combinations with single-band with UL CA, this field indicates the support of dual PA. If absent in such band combinations, the UE supports single PA for all the ULs. For other band combinations, this field is not applicable.	ВС	No	No	No
parallelTxSRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of SRS and PUCCH/ PUSCH across CCs in an inter-band CA band combination.	ВС	No	No	No
parallelTxPRACH-SRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of PRACH and SRS/PUCCH/PUSCH across CCs in an inter-band CA band combination.	ВС	No	No	No
simultaneousCSI-ReportsAIICC Indicates whether the UE supports CSI report framework and the number of CSI report(s) which the UE can simultaneously process across all CCs, and across MCG and SCG in case of NR-DC. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in simultaneousCSI-ReportsAIICC includes the beam report and CSI report. This parameter may further limit simultaneousCSI-ReportsPerCC in MIMO-ParametersPerBand and Phy-ParametersFRX-Diff for each band in a given band combination.	BC	Yes	No	No
simultaneousRxTxInterBandCA Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band NR CA. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4].	ВС	CY	No	No
simultaneousRxTxSUL Indicates whether the UE supports simultaneous reception and transmission for a NR band combination including SUL. Mandatory/Optional support depends on band combination and captured in TS 38.101-1 [2].	BC	CY	No	No
simultaneousSRS-AssocCSI-RS-AIICC Indicates support of CSI-RS processing framework for SRS and the number of SRS resources that the UE can process simultaneously across all CCs, and across MCG and SCG in case of NR-DC, including periodic, aperiodic and semi-persistent SRS. This parameter may further limit simultaneousSRS-AssocCSI-RS-PerCC in MIMO-ParametersPerBand and Phy-ParametersFRX-Diff for each band in a given band combination.	BC	No	No	No
supportedNumberTAG  Defines the number of timing advance groups supported by the UE. It is applied to NR CA, NR-DC and EN-DC/NE-DC. For EN-DC/NE-DC, it indicates number of TAGs only for NR CG. The number of TAGs for the LTE MCG is signalled by existing LTE TAG capability signalling. For NR CA/NR-DC band combination, if the band combination comprised of more than one band entry (i.e., inter-band or intraband non-contiguous band combination), it indicates that different timing advances on different band entries are supported. If absent, the UE supports only one TAG for the NR part. It is mandatory for the UE to support more than one TAG for NR-DC.	ВС	CY	No	No

## 4.2.7.5 *FeatureSetDownlink* parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalDMRS-DL-Alt Indicates whether the UE supports the alternative additional DMRS position for co- existence with LTE CRS. It is applied to 15kHz SCS and one additional DMRS case	FS	No	No	FR1 only
only.  crossCarrierScheduling-OtherSCS Indicates whether the UE supports cross carrier scheduling for the different	FS	No	No	No
numerologies with carrier indicator field (CIF) in DL carrier aggregation where numerologies for the scheduling cell and scheduled cell are different.  NOTE: Cross-carrier scheduling with different numerologies is not supported in this release of specification.				
csi-RS-MeasSCellWithoutSSB  Defines whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that does not transmit SS/PBCH block. A UE that supports this feature shall also support scellWithoutSSB.	FS	No	No	No
dl-MCS-TableAlt-DynamicIndication Indicates whether the UE supports dynamic indication of MCS table for PDSCH.	FS	No	No	No
featureSetListPerDownlinkCC Indicates which features the UE supports on the individual DL carriers of the feature set (and hence of a band entry that refer to the feature set) by FeatureSetDownlinkPerCC-Id. The UE shall hence include as many FeatureSetDownlinkPerCC-Id in this list as the number of carriers it supports according to the ca-bandwidthClassDL. The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the FeatureSetDownlinkPerCC-Id in this list. A fallback per CC feature set resulting from the reported feature set per DL CC is not signalled but the UE shall support it.	FS	N/A	No	No
intraBandFreqSeparationDL Indicates DL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetDownlink of each band entry within a band. The values c1, c2 and c3 corresponds to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports DL intra-band non-contiguous CA in FR2.	FS	СҮ	No	FR2 only
oneFL-DMRS-ThreeAdditionalDMRS-DL Defines whether the UE supports DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with three additional DM-RS symbols.	FS	No	No	Yes
oneFL-DMRS-TwoAdditionalDMRS-DL Defines support of DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.	FS	Yes	No	Yes
pdcch-MonitoringAnyOccasions  Defines the supported PDCCH search space monitoring occasions. withoutDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively. withDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation of two OFDM symbols for 15 kHz, four OFDM symbols for 30 kHz, seven OFDM symbols for 60 kHz with NCP, and 14OFDM symbols for 120kHz between two consecutive transmissions of PDCCH scrambled with C-RNTI, MCS-C-RNTI, or CS-RNTI for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space, with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively.	FS	No	No	No

pdcch-MonitoringAnyOccasionsWithSpanGap Indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH with span up to two OFDM symbols for two OFDM symbols or span up to three OFDM symbols for four and seven OFDM symbols. Value set1 indicates the supported value set (X,Y) is (7,3), value set2 indicates the supported value set (X,Y) is (4,3) and (7,3) and value set 3 indicates the supported value set (X,Y) is (2,2), (4,3) and (7,3).	FS	No	No	No
pdsch-ProcessingType1-DifferentTB-PerSlot  Defines whether the UE capable of processing time capability 1 supports reception of up to two, four or seven unicast PDSCHs for several transport blocks with PDSCH scrambled using C-RNTI, TC-RNTI, or CS-RNTI in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	No	No
Note PDSCH(s) for Msg.4 is included.  pdsch-ProcessingType2 Indicates whether the UE supports PDSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each subcarrier spacing supported by the UE.  - fallback indicates whether the UE supports PDSCH processing capability 2 when the number of configured carriers is larger than numberOfCarriers for a reported value of differentTB-PerSlot. If fallback = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if fallback = 'cap1-only', UE supports only capability 1, in the band where the value is reported;  - differentTB-PerSlot indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PDSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PDSCHs for different TBs. The UE shall include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per slot in this field if pdsch-ProcessingType2 is indicated.	FS	No	No	FR1 only
<ul> <li>pdsch-Processing Type2-Limited</li> <li>Indicates whether the UE supports PDSCH processing capability 2 with scheduling limitation for SCS 30kHz. This capability signalling comprises the following parameter.         <ul> <li>different TB-PerSlot-SCS-30kHz indicates the number of different TBs per slot.</li> </ul> </li> <li>The UE supports this limited processing capability 2 only if:         <ul> <li>One carrier is configured in the band, independent of the number of carriers configured in the other bands;</li> </ul> </li> <li>The maximum bandwidth of PDSCH is 136 PRBs;</li> <li>N1 based on Table 5.3-2 of TS 38.214 [12] for SCS 30 kHz.</li> </ul>	FS	No	No	FR1 only
pdsch-SeparationWithGap Indicates whether the UE supports separation of two unicast PDSCHs with a gap, applicable to Sub-carrier spacings of 30 KHz and 60 KHz only. For any two consecutive slots n and n+1, if there are more than 1 unicast PDSCH in either slot, the minimum time separation between starting time of any two unicast PDSCHs within the duration of these slots is 4 OFDM symbol for 30kHz and 7 OFDM symbol for 60kHz.	FS	No	No	No
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	No	No
scellWithoutSSB  Defines whether the UE supports configuration of SCell that does not transmit SS/PBCH block. This is conditionally mandatory with capability signalling for intraband CA but not supported for inter-band CA.	FS	CY	No	No
searchSpaceSharingCA-DL Defines whether the UE supports DL PDCCH search space sharing for carrier aggregation operation.	FS	No	No	No

timeDurationForQCL Defines minimum number of OFDM symbols required by the UE to perform PDCCH reception and applying spatial QCL information received in DCI for PDSCH processing as described in TS 38.214 [12] clause 5.1.5. UE shall indicate one value of the minimum number of OFDM symbols per each subcarrier spacing of 60kHz and 120kHz.	FS	Yes	No	FR2 only
twoFL-DMRS-TwoAdditionalDMRS-DL Defines whether the UE supports DM-RS pattern for DL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.	FS	No	No	Yes
type1-3-CSS  Defines whether the UE is able to receive PDCCH in FR2 in a Type1-PDCCH common search space configured by dedicated RRC signaling, in a Type3-PDCCH common search space or a UE-specific search space if those are associated with a CORESET with a duration of 3 symbols.	FS	Yes	No	FR2 only
ue-SpecificUL-DL-Assignment Indicates whether the UE supports dynamic determination of UL and DL link direction and slot format based on Layer 1 scheduling DCI and higher layer configured parameter UL-DL-configuration-dedicated as specified in TS 38.213 [11].	FS	No	No	No

## 4.2.7.6 FeatureSetDownlinkPerCC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
channelBW-90mhz Indicates whether the UE supports the channel bandwidth of 90 MHz.	FSPC	No	No	FR1 only
maxNumberMIMO-LayersPDSCH  Defines the maximum number of spatial multiplexing layer(s) supported by the UE for DL reception. For single CC standalone NR, it is mandatory with capability signaling to support at least 4 MIMO layers in the bands where 4Rx is specified as mandatory for the given UE and at least 2 MIMO layers in FR2. If absent, the UE does not support MIMO on this carrier.	FSPC	CY	No	No
supportedBandwidthDL Indicates maximum DL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS 38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3].  NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz, the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-DL, the supportedBandwidthCombinationSet and supportedBandwidthDL.	FSPC	CY	No	No
<ul> <li>supportedModulationOrderDL</li> <li>Indicates the maximum supported modulation order to be applied for downlink in the carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for downlink. If not included:         <ul> <li>for FR1, the network uses the modulation order signalled in pdsch-256QAM-FR1.</li> <li>for FR2, the network uses the modulation order signalled per band i.e. pdsch-256QAM-FR2 if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM.</li> </ul> </li> <li>In all the cases, it shall be ensured that the data rate does not exceed the max data rate (DataRate) and max data rate per CC (DataRateCC) according to TS 38.214 [12].</li> </ul>	FSPC	No	No	No
supportedSubCarrierSpacingDL  Defines the supported sub-carrier spacing for DL by the UE, as defined in clause 4.2-1 of TS 38.211 [6], indicating the UE supports simultaneous reception with same or different numerologies in CA. Support of simultaneous reception with same numerology for intra-band NR CA including both contiguous and non-contiguous is mandatory with capability in both FR1 and FR2. Support of simultaneous reception with two different numerologies between FR1 band(s) and FR2 band(s) in DL is mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Optional for other cases. Support of simultaneous reception of with different numerologies in CA for other cases is optional.	FSPC	CY	No	No

## 4.2.7.7 FeatureSetUplink parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	Tbd	No	No
crossCarrierScheduling-OtherSCS Indicates whether the UE supports cross carrier scheduling for the different numerologies with carrier indicator field (CIF) in UL carrier aggregation where numerologies for the scheduling cell and scheduled cell are different. The UE shall set this field to the same value as crossCarrierScheduling-OtherSCS in the associated FeatureSetDownlink (if present).  NOTE: Cross-carrier scheduling with different numerologies is not supported in this release of specification.	FS	No	No	No
dynamicSwitchSUL Indicates whether the UE supports supplemental uplink with dynamic switch (DCI based selection of PUSCH carrier).	FS	No	No	No
featureSetListPerUplinkCC Indicates which features the UE supports on the individual UL carriers of the feature set (and hence of a band entry that refer to the feature set) by FeatureSetUplinkPerCC-Id. The UE shall hence include as many FeatureSetUplinkPerCC-Id in this list as the number of carriers it supports according to the ca-bandwidthClassUL. The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the FeatureSetUplinkPerCC-Id in this list. A fallback per CC feature set resulting from the reported feature set per UL CC is not signalled but the UE shall support it.	FS	N/A	No	No
intraBandFreqSeparationUL Indicates UL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetUplink of each band entry within a band. The values c1, c2 and c3 corresponds to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports UL non-contiguous CA in FR2.	FS	CY	No	FR2 only
pa-PhaseDiscontinuityImpacts Indicates incapability motivated by impacts of PA phase discontinuity with overlapping transmissions with non-aligned starting or ending times or hop boundaries across carriers for intra-band EN-DC, intra-band CA and FDM based ULSUP.	FS	No	No	No
pusch-ProcessingType1-DifferentTB-PerSlot Indicates whether the UE capable of processing time capability 1 supports transmission of up to two, four or seven unicast PUSCHs for several transport blocks in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	No	No
<ul> <li>pusch-ProcessingType2</li> <li>Indicates whether the UE supports PUSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each subcarrier spacing supported by the UE.         <ul> <li>fallback indicates whether the UE supports PUSCH processing capability 2 when the number of configured carriers is larger than numberOfCarriers for a reported value of differentTB-PerSlot. If fallback = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if fallback = 'cap1-only', UE supports only capability 1, in the band where the value is reported;</li> <li>differentTB-PerSlot indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PUSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PUSCHs for different TBs. The UE shall include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per slot in this field if pusch-ProcessingType2 is indicated.</li> </ul> </li> </ul>	FS	No	No	FR1 only

		l NI.	NI.	NI.
pusch-SeparationWithGap Indicates whether the UE supports separation of two unicast PUSCHs with a gap, applicable to Sub-carrier spacings of 15 KHz, 30 KHz and 60 KHz only. For any two consecutive slots n and n+1, if there are more than 1 unicast PUSCH in either slot, the minimum time separation between starting time of any two unicast PUSCHs within the duration of these slots is 2 OFDM symbols for 15kHz, 4 OFDM symbols for 30kHz and 7 OFDM symbols for 60kHz.	FS	No	No	No
searchSpaceSharingCA-UL Defines whether the UE supports UL PDCCH search space sharing for carrier aggregation operation.	FS	No	No	No
simultaneousTxSUL-NonSUL Indicates whether the UE supports simultaneous transmission of SRS on an SUL/non-SUL carrier and PUSCH/PUCCH/SRS on the other UL carrier in the same cell.	FS	No	No	No
Defines supported SRS-Resources Defines support of SRS resources. The capability signalling comprising indication of:  - maxNumberAperiodicSRS-PerBWP indicates supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP  - maxNumberAperiodicSRS-PerBWP-PerSlot indicates supported maximum number of aperiodic SRS resources per slot in the BWP  - maxNumberPeriodicSRS-PerBWP indicates supported maximum number of periodic SRS resources per BWP  - maxNumberPeriodicSRS-PerBWP-PerSlot indicates supported maximum number of periodic SRS resources per slot in the BWP  - maxNumberSemiPersitentSRS-PerBWP indicate supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP  - maxNumberSP-SRS-PerBWP-PerSlot indicates supported maximum number of semi-persistent SRS resources per slot in the BWP  - maxNumberSRS-Ports-PerResource indicates supported maximum number of SRS antenna port per each SRS resource	FS	Yes	No	No
twoPUCCH-Group Indicates whether two PUCCH group in CA with a same numerology across CCs for data and control channel [at a given time] is supported by the UE. For NR CA, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time. For EN-DC, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time, wherein an NR PUCCH group is configured in FR1 and another NR PUCCH group is configured in FR2.  ul-MCS-TableAlt-DynamicIndication	FS	No	No	No
Indicates whether the UE supports dynamic indication of MCS table using MCS-C-RNTI for PUSCH. <b>zeroSlotOffsetAperiodicSRS</b> Indicates whether the UE supports 0 slot offset between aperiodic SRS triggering and transmission, for SRS for CB PUSCH and antenna switching on FR1.	FS	No	No	No

### 4.2.7.8 FeatureSetUplinkPerCC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
channelBW-90mhz Indicates whether the UE supports the channel bandwidth of 90 MHz.	FSPC	No	No	FR1 only
maxNumberMIMO-LayersCB-PUSCH  Defines supported maximum number of MIMO layers at the UE for PUSCH transmission with codebook precoding. UE indicating support of this feature shall also indicate support of PUSCH codebook coherency subset. This feature is not supported for SUL.	FSPC	No	No	No
maxNumberMIMO-LayersNonCB-PUSCH  Defines supported maximum number of MIMO layers at the UE for PUSCH transmission using non-codebook precoding. This feature is not supported for SUL. UE supporting non-codebook based PUSCH transmission shall indicate support of maxNumberMIMO-LayersNonCB-PUSCH, maxNumberSRS-ResourcePerSet and maxNumberSimultaneousSRS-ResourceTx together.	FSPC	No	No	No
maxNumberSimultaneousSRS-ResourceTx  Defines the maximum number of simultaneous transmitted SRS resources at one symbol for non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	No	No
maxNumberSRS-ResourcePerSet  Defines the maximum number of SRS resources per SRS resource set configured for codebook or non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	No	No
supportedBandwidthUL Indicates maximum UL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3].  NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet and supportedBandwidthUL.	FSPC	CY	No	No
<ul> <li>supportedModulationOrderUL</li> <li>Indicates the maximum supported modulation order to be applied for uplink in the carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for uplink. If not included,         <ul> <li>for FR1 and FR2, the network uses the modulation order signalled per band i.e. pusch-256QAM if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM.</li> </ul> </li> <li>In all the cases, it shall be ensured that the data rate does not exceed the max data rate (DataRate) and max data rate per CC (DataRateCC) according to TS 38.214 [12].</li> </ul>	FSPC	No	No	No
supportedSubCarrierSpacingUL  Defines the supported sub-carrier spacing for UL by the UE, as defined in 4.2-1 of TS 38.211 [6], indicating the UE supports simultaneous transmission with same or different numerologies in CA, or indicating the UE supports different numerologies on NR UL and SUL within one cell. Support of simultaneous transmissions with same numerology for intra-band NR CA including both contiguous and non-contiguous is mandatory with capability in both FR1 and FR2. Support of simultaneous transmission with two different numerologies between FR1 band(s) and FR2 band(s) in UL is mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Support of simultaneous transmission with different numerologies in CA for other cases is optional.	FSPC	CY	No	No

#### 4.2.7.9 MRDC-Parameters

Definitions for parameters	Per	М	FDD- TDD	FR1- FR2
and the Band Fund	D0	NI.	DIFF	DIFF
asyncIntraBandENDC Indicates whether the UE supports asynchronous FDD-FDD intra-band EN-DC with MRTD and MTTD as specified in clause 7.5 and 7.6 of TS 38.133 [5]. If it is not supported for FDD-FDD intra-band EN-DC, the UE supports only synchronous FDD-FDD intra-band EN-DC.	BC	No	FDD only	FR1 only
dualPA-Architecture  For an intra-band band combination, this field indicates the support of dual PAs. If absent in an intra-band band combination, the UE supports single PA for all the ULs in the intra-band band combination. For other band combinations, this field is not applicable.	BC	No	No	No
dynamicPowerSharingENDC Indicates whether the UE supports dynamic (NG)EN-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability the UE supports the dynamic power sharing behaviour as specified in clause 7 of TS 38.213 [11].	ВС	Yes	No	FR1 only
dynamicPowerSharingNEDC Indicates whether the UE supports dynamic NE-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability, the UE supports the dynamic power sharing behavior as specified in clause 7 of TS 38.213 [11].	BC	Yes	No	FR1 only
intraBandENDC-Support Indicates whether the UE supports intra-band EN-DC with only non-contiguous spectrum, or with both contiguous and non-contiguous spectrum for the EN-DC combination as specified in TS 38.101-3 [4].  If the UE does not include this field for an intra-band EN-DC combination the UE only supports the contiguous spectrum for the intra-band EN-DC combination.	ВС	No	No	No
simultaneousRxTxInterBandENDC Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band EN-DC. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-3 [4].	ВС	CY	No	No
singleUL-Transmission Indicates that the UE does not support simultaneous UL transmissions as defined in TS 38.101-3 [4]. The UE may only include this field for certain band combinations defined in TS 38.101-3 [4]. If included for a particular band combination, the field applies to all fallback band combinations of this band combination that are defined in TS 38.101-3 [4] as being allowed to include this field and does not apply to any other fallback band combinations defined in TS 38.101-3 [4].	BC	No	No	No
tdm-Pattern Indicates whether the UE supports the tdm-PatternConfig for single UL-transmission associated functionality, as specified in TS 36.331 [17]. Support is conditionally mandatory in (NG)EN-DC for UEs that do not support dynamicPowerSharingENDC and for UEs that indicate single UL transmission for any (NG)EN-DC BC. Support is conditionally mandatory in NE-DC for UEs that do not support dynamicPowerSharingNEDC and for UEs that indicate single UL transmission for any NE-DC BC. The feature is optional otherwise.	ВС	СҮ	Yes	Yes
ul-SharingEUTRA-NR Indicates whether the UE supports EN-DC with EUTRA-NR coexistence in UL sharing via TDM only, FDM only, or both TDM and FDM from UE perspective as specified in TS 38.101-3 [4].	BC	No	No	FR1 only
ul-SwitchingTimeEUTRA-NR Indicates support of switching type between LTE UL and NR UL for EN-DC with LTE-NR coexistence in UL sharing from UE perspective as defined in clause 6.3B of TS 38.101-3 [4]. It is mandatory to report switching time type 1 or type 2 if UE reports ul-SharingEUTRA-NR is tdm or both.	ВС	CY	No	FR1 only
ul-TimingAlignmentEUTRA-NR Indicates whether to apply the same UL timing between NR and LTE for dynamic power sharing capable UE operating in a synchronous intra-band contiguous (NG)EN-DC. If this field is absent, UE shall be capable of handling a timing difference up to applicable MTTD requirements when operating in a synchronous intra-band contiguous (NG)EN-DC network, as specified in TS 38.133 [5]. If this capability is included in an inter-band (NG)EN-DC BC with an intra-band (NG)EN-DC BC part, this capability is used to indicate the restriction to the intra-band (NG)EN-DC BC part.	ВС	No	No	No

4.2.7.10 Phy-Parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
absoluteTPC-Command Indicates whether the UE supports absolute TPC command mode.	UE	No	No	Yes
almostContiguousCP-OFDM-UL Indicates whether the UE supports almost contiguous UL CP-OFDM transmissions as defined in clause 6.2 of TS 38.101-1 [2].	UE	No	No	Yes
bwp-SwitchingDelay Defines whether the UE supports DCI and timer based active BWP switching delay type1 or type2 specified in clause 8.6.2 of TS 38.133 [5]. It is mandatory to report type 1 or type 2.	UE	Yes	No	No
cbg-FlushIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG flushing out information (CBGFI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-UL Indicates whether the UE supports CBG-based (re)transmission for UL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
configuredUL-GrantType1 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
configuredUL-GrantType2 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
cqi-TableAlt Indicates whether UE supports the CQI table with target BLER of 10^-5.	UE	No	No	Yes
csi-ReportFramework See csi-ReportFramework in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	Band or UE	Yes	No	No
csi-ReportWithoutCQI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
csi-ReportWithoutPMI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/CQI' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
csi-RS-CFRA-ForHO Indicates whether the UE can perform reconfiguration with sync using a contention free random access on PRACH resources that are associated with CSI-RS resources of the target cell.	UE	No	No	No
csi-RS-IM-ReceptionForFeedback See csi-RS-IM-ReceptionForFeedback in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	Band or UE	Yes	No	No
csi-RS-ProcFrameworkForSRS See csi-RS-ProcFrameworkForSRS in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	Band or UE	No	No	No
di-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PDSCH.	UE	No	No	Yes
dl-SchedulingOffset-PDSCH-TypeA Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type A.	UE	Yes	Yes	Yes
dl-SchedulingOffset-PDSCH-TypeB Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type B.	UE	Yes	Yes	Yes
downlinkSPS Indicates whether the UE supports PDSCH reception based on semi-persistent scheduling.	UE	No	No	No
dynamicBetaOffsetInd-HARQ-ACK-CSI Indicates whether the UE supports indicating beta-offset (UCI repetition factor onto PUSCH) for HARQ-ACK and/or CSI via DCI among the RRC configured beta-offsets.	UE	No	No	No

dynamicHARQ-ACK-Codebook Indicates whether the UE supports HARQ-ACK codebook dynamically constructed	UE	Yes	No	No
by DCI(s). This field shall be set to supported.				
dynamicHARQ-ACK-CodeB-CBG-Retx-DL	UE	No	No	No
Indicates whether the UE supports HARQ-ACK codebook size for CBG-based		140	140	'10
(re)transmission based on the DAI-based solution as specified in TS 38.213 [11].				
dynamicPRB-BundlingDL	UE	No	No	No
	UE	INO	INO	INO
Indicates whether UE supports DCI-based indication of the PRG size for PDSCH				
reception.		NI-	\/	V
dynamicSFI	UE	No	Yes	Yes
Indicates whether the UE supports monitoring for DCI format 2_0 and determination				
of slot formats via DCI format 2_0.				
dynamicSwitchRA-Type0-1-PDSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation				
Types 0 and 1 for PDSCH as specified in TS 38.212 [10].				
dynamicSwitchRA-Type0-1-PUSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation	_			
Types 0 and 1 for PUSCH as specified in TS 38.212 [10].				
pucch-F0-2WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 0 or 2 without	J.	163	140	'68
frequency hopping. When included, the UE does not support PUCCH formats 0 and				
2 without frequency hopping. When not included, the UE supports the PUCCH				
formats 0 and 2 without frequency hopping.				
pucch-F1-3-4WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 1, 3 or 4				
without frequency hopping. When included, the UE does not support PUCCH				
formats 1, 3 and 4 without frequency hopping. When not included, the UE supports				
the PUCCH formats 1, 3 and 4 without frequency hopping.				
interleavingVRB-ToPRB-PDSCH	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH with interleaved VRB-to-PRB				
mapping as specified in TS 38.211 [6].				
interSlotFreqHopping-PUSCH	UE	No	No	No
Indicates whether the UE supports inter-slot frequency hopping for PUSCH		140	110	110
transmissions.				
		V	NI.	
intraSlotFreqHopping-PUSCH	UE	Yes	No	Yes
Indicates whether the UE supports intra-slot frequency hopping for PUSCH				
transmission, except for PUSCH scheduled by PDCCH in the Type1-PDCCH				
common search space before RRC connection establishment.				
maxLayersMIMO-Indication	UE	Yes	No	No
Indicates whether the UE supports the network configuration of maxMIMO-Layers				
as specified in TS 38.331 [9].				
maxNumberSearchSpaces	UE	No	No	No
Indicates whether the UE supports up to 10 search spaces in a SCell per BWP.				
multipleCORESET	UE	CY	No	Yes
Indicates whether the UE supports configuration of more than one PDCCH	UL.	''	INU	' =:
CORESET per BWP in addition to the CORESET with CORESET-ID 0 in the BWP.				
It is mandatory with capability signaling for FR2 and optional for FR1.				
mux-HARQ-ACK-PUSCH-DiffSymbol	UE	Yes	No	Yes
Indicates whether the UE supports HARQ-ACK piggyback on a PUSCH with/without				
aperiodic CSI once per slot when the starting OFDM symbol of the PUSCH is				
different from the starting OFDM symbols of the PUCCH resource that HARQ-ACK				
would have been transmitted on.				
mux-MultipleGroupCtrlCH-Overlap	UE	No	No	Yes
Indicates whether the UE supports more than one group of overlapping PUCCHs	5_		0	'~
and PUSCHs per slot per PUCCH cell group for control multiplexing.				
		N/-	NI-	W.
mux-SR-HARQ-ACK-CSI-PUCCH-MultiPerSlot	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR, HARQ-ACK and CSI on a				
PUCCH or piggybacking on a PUSCH more than once per slot when SR, HARQ-				
ACK and CSI are supposed to be sent with the same or different starting symbol in				
a slot.		1		1

mux-SR-HARQ-ACK-CSI-PUCCH-OncePerSlot sameSymbol indicates the UE supports multiplexing SR, HARQ-ACK and CSI on a	UE	FD	No	Yes
PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-ACK and CSI				
are supposed to be sent with the same starting symbols on the PUCCH resources				
in a slot. diffSymbol indicates the UE supports multiplexing SR, HARQ-ACK and				
CSI on a PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-				
ACK and CSI are supposed to be sent with the different starting symbols in a slot.				
The UE is mandated to support the multiplexing and piggybacking features				
indicated by sameSymbol while the UE is optional to support the multiplexing and				
piggybacking features indicated by <i>diffSymbol</i> .				
If the UE indicates sameSymbol in this field and does not support mux-HARQ-ACK-				
PUSCH-DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once				
per slot, when the starting OFDM symbol of the PUSCH is the same as the starting				
OFDM symbols of the PUCCH resource(s) that would have been transmitted on.				
If the UE indicates sameSymbol in this field and supports mux-HARQ-ACK-PUSCH-				
DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once per slot				
for which case the starting OFDM symbol of the PUSCH is the different from the				
starting OFDM symbols of the PUCCH resource(s) that would have been				
transmitted on.				
mux-SR-HARQ-ACK-PUCCH	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR and HARQ-ACK on a PUCCH				
or piggybacking on a PUSCH once per slot, when SR and HARQ-ACK are				
supposed to be sent with the different starting symbols in a slot.				
nzp-CSI-RS-IntefMgmt	UE	No	No	No
Indicates whether the UE supports interference measurements using NZP CSI-RS.	0_	''		''
oneFL-DMRS-ThreeAdditionalDMRS-UL	UE	No	No	Yes
Defines whether the UE supports DM-RS pattern for UL transmission with 1 symbol	~-	'''		
front-loaded DM-RS with three additional DM-RS symbols.				
oneFL-DMRS-TwoAdditionalDMRS-UL	UE	Yes	No	Yes
Defines support of DM-RS pattern for UL transmission with 1 symbol front-loaded	-			
DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.				
onePortsPTRS	UE	CY	No	Yes
Defines whether UE supports PT-RS with 1 antenna port in DL reception and/or UL				
transmission. It is mandatory with UE capability signalling for FR2 and optional for				
FR1. The left most in the bitmap corresponds to DL reception and the right most bit				
in the bitmap corresponds to UL transmission.				
onePUCCH-LongAndShortFormat	UE	No	No	Yes
Indicates whether the UE supports transmission of one long PUCCH format and				
one short PUCCH format in TDM in the same slot.				
pCell-FR2	UE	Yes	No	FR2
Indicates whether the UE supports PCell operation on FR2.				only
pdcch-MonitoringSingleOccasion	UE	No	No	FR1
Indicates whether the UE supports receiving PDCCH scrambled with C-RNTI or CS-				only
RNTI in a search space configured to be monitored within a single span of any three				
contiguous OFDM symbols in a slot with the capability of supporting at least 44				
blind decodes in a slot for 15 kHz subcarrier spacing.				
pdcch-BlindDetectionCA	UE	No	No	No
Indicates PDCCH blind decoding capabilities supported by the UE for CA with more				
than 4 CCs as specified in TS 38.213 [11]. The field value is from 4 to 16.				
NOTE: FR1-FR2 differentiation is not allowed in this release, although the				
capability signalling is supported for FR1-FR2 differentiation.				
pdcch-BlindDetectionMCG-UE	UE	No	No	Yes
Indicates PDCCH blind decoding capabilities supported for MCG when in NR DC.				
The field value is from 1 to 15. The UE sets the value in accordance with the				
constraints specified in TS 38.213 [11].				
Additionally, if the UE does not report <i>pdcch-BlindDetectionCA</i> , and if X is the				
maximum number of CCs supported by the UE across all NR-DC band				
combinations then there is at least one parameter pair (X1, X2) such that X1 + X2 =				
X and the UE supports at least one NR-DC band combination with X1 CCs in MCG				
and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <=				
pdcch-BlindDetectionSCG-UE.				

pdcch-BlindDetectionSCG-UE Indicates PDCCH blind decoding capabilities supported for SCG when in NR DC. The field value is from 1 to 15. The UE sets the value in accordance with the constraints specified in TS 38.213 [11]. Additionally, if the UE does not report pdcch-BlindDetectionCA, and if X is the	UE	No	No	Yes
maximum number of CCs supported by the UE across all NR-DC band combinations then there is at least one parameter pair (X1, X2) such that X1 + X2 = X and the UE supports at least one NR-DC band combination with X1 CCs in MCG and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <= pdcch-BlindDetectionSCG-UE.				
pdsch-256QAM-FR1 Indicates whether the UE supports 256QAM modulation scheme for PDSCH for FR1 as defined in 7.3.1.2 of TS 38.211 [6].	UE	Yes	No	FR1 only
pdsch-MappingTypeA Indicates whether the UE supports receiving PDSCH using PDSCH mapping type A with less than seven symbols. This field shall be set to supported.	UE	Yes	No	No
pdsch-MappingTypeB Indicates whether the UE supports receiving PDSCH using PDSCH mapping type B.	UE	Yes	No	No
pdsch-RepetitionMultiSlots Indicates whether the UE supports receiving PDSCH scheduled by DCI format 1_1 when configured with higher layer parameter pdsch-AggregationFactor > 1, as defined in 5.1.2.1 of TS 38.214 [12].	UE	No	No	No
pdsch-RE-MappingFR1-PerSymbol/pdsch-RE-MappingFR1-PerSlot Indicates the maximum number of supported PDSCH Resource Element (RE) mapping patterns for FR1, each described as a resource (including NZP/ZP CSI-RS, CRS, CORESET and SSB) or bitmap. The number of patterns coinciding in a symbol in a CC and in a slot in a CCare limited by the respective capability parameters. Value n10 means 10 RE mapping patterns and n16 means 16 RE mapping patterns, and so on.	UE	Yes	No	FR1 only
pdsch-RE-MappingFR2-PerSymbol/pdsch-RE-MappingFR2-PerSlot Indicates the maximum number of supported PDSCH Resource Element (RE) mapping patterns for FR2, each described as a resource (including NZP/ZP CSI- RS, CORESET and SSB) or bitmap. The number of patterns coinciding in a symbol in a CC and in a slot in a CC are limited by the respective capability parameters. Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns, and so on.	UE	Yes	No	FR2 only
precoderGranularityCORESET Indicates whether the UE supports receiving PDCCH in CORESETs configured with CORESET-precoder-granularity equal to the size of the CORESET in the frequency domain as specified in TS 38.211 [6].	UE	No	No	No
pre-EmptIndication-DL Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11].	UE	No	No	No
pucch-F2-WithFH Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to supported.	UE	Yes	No	Yes
pucch-F3-WithFH Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot. This field shall be set to supported.	UE	Yes	No	Yes
pucch-F3-4-HalfPi-BPSK Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in 6.3.2.6 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability signalling for FR2.	UE	CY	No	Yes
pucch-F4-WithFH Indicates whether the UE supports transmission of a PUCCH format 4 (4~14 OFDM symbols in total) with frequency hopping in a slot.	UE	Yes	No	Yes
pusch-RepetitionMultiSlots Indicates whether the UE supports transmitting PUSCH scheduled by DCI format 0_1 when configured with higher layer parameter pusch-AggregationFactor > 1, as defined in clause 6.1.2.1 of TS 38.214 [12].	UE	Yes	No	No
pucch-Repetition-F1-3-4 Indicates whether the UE supports transmission of a PUCCH format 1 or 3 or 4 over multiple slots with the repetition factor 2, 4 or 8.	UE	Yes	No	No

pusch-HalfPi-BPSK Indicates whether the UE supports pi/2-BPSK modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6]. It is optional for FR1 and mandatory with	UE	CY	No	Yes
capability signalling for FR2.				
<b>pusch-LBRM</b> Indicates whether the UE supports limited buffer rate matching in UL as specified in TS 38.212 [10].	UE	No	No	Yes
ra-Type0-PUSCH	UE	No	No	No
Indicates whether the UE supports resource allocation Type 0 for PUSCH as specified in TS 38.214 [12].			110	110
rateMatchingCtrlResrcSetDynamic	UE	Yes	No	No
Indicates whether the UE supports dynamic rate matching for DL control resource set.				
rateMatchingResrcSetDynamic	UE	No	No	No
Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity based on dynamic indication in the scheduling DCI as specified in TS 38.214 [12].				
rateMatchingResrcSetSemi-Static	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity following the semi-static configuration as specified in TS 38.214 [12].				
scs-60kHz	UE	No	No	FR1
Indicates whether the UE supports 60kHz subcarrier spacing for data channel in FR1 as defined in clause 4.2-1 of TS 38.211 [6].				only
semiOpenLoopCSI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1/CQI ' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
<b>semiStaticHARQ-ACK-Codebook</b> Indicates whether the UE supports HARQ-ACK codebook constructed by semistatic configuration.	UE	Yes	No	No
spatialBundlingHARQ-ACK Indicates whether the UE supports spatial bundling of HARQ-ACK bits carried on PUCCH or PUSCH per PUCCH group. With spatial bundling, two HARQ-ACK bits for a DL MIMO data is bundled into a single bit by logical "AND" operation.	UE	Yes	No	No
sp-CSI-IM Indicates whether the UE supports semi-persistent CSI-IM.	UE	No	No	Yes
sp-CSI-ReportPUCCH	UE	No	No	No
Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4.			-	
sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH.	UE	No	No	No
sp-CSI-RS	UE	Yes	No	Yes
Indicates whether the UE supports semi-persistent CSI-RS.				
<b>supportedDMRS-TypeDL</b> Defines supported DM-RS configuration types at the UE for DL reception. Type 1 is mandatory with capability signaling. Type 2 is optional.	UE	CY	No	Yes
supportedDMRS-TypeUL  Defines supported DM-RS configuration types at the UE for UL transmission.  Support both type 1 and type 2 are mandatory with capability signalling.	UE	Yes	No	Yes
tdd-MultiDL-UL-SwitchPerSlot Indicates whether the UE supports more than one switch points in a slot for actual	UE	No	TDD only	Yes
DL/UL transmission(s).			<b>.</b>	
tpc-PUCCH-RNTI Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNTI for TPC commands for PUCCH.	UE	No	No	Yes
tpc-PUSCH-RNTI Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNTI for TPC commands for PUSCH.	UE	No	No	Yes
tpc-SRS-RNTI Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI	UE	No	No	Yes
for TPC commands for SRS.				
twoDifferentTPC-Loop-PUCCH Indicates whether the UE supports two different TPC loops for PUCCH closed loop	UE	Yes	Yes	Yes

twoDifferentTPC-Loop-PUSCH	UE	Yes	Yes	Yes
Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control.				
twoFL-DMRS	UE	Yes	No	Yes
Defines whether the UE supports DM-RS pattern for DL reception and/or UL				
transmission with 2 symbols front-loaded DM-RS without additional DM-RS				
symbols.				
The left most in the bitmap corresponds to DL reception and the right most bit in the				
bitmap corresponds to UL transmission.				
twoFL-DMRS-TwoAdditionalDMRS-UL	UE	Yes	No	Yes
Defines whether the UE supports DM-RS pattern for UL transmission with 2				
symbols front-loaded DM-RS with one additional 2 symbols DM-RS.				
twoPUCCH-AnyOthersInSlot	UE	No	No	Yes
Indicates whether the UE supports transmission of two PUCCH formats in TDM in				
the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and				
onePUCCH-LongAndShortFormat.				
twoPUCCH-F0-2-ConsecSymbols	UE	No	Yes	Yes
Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in				
consecutive symbols in a slot.				
type1-PUSCH-RepetitionMultiSlots	UE	No	No	No
Indicates whether the UE supports Type 1 PUSCH transmissions with configured				
grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8				
with a single repetition of the transport block within each slot, and redundancy				
version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall				
also support Type 1 PUSCH transmissions with configured grant as specified in TS				
38.214 [12] with UL-TWG-repK value of one.				
type2-PUSCH-RepetitionMultiSlots	UE	No	No	No
Indicates whether the UE supports Type 2 PUSCH transmissions with configured				
grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8				
with a single repetition of the transport block within each slot, and redundancy				
version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall				
also support Type 2 PUSCH transmissions with configured grant as specified in TS				
38.214 [12] with UL-TWG-repK value of one.				
type2-SP-CSI-Feedback-LongPUCCH	UE	No	No	No
Indicates whether UE supports Type II CSI semi-persistent CSI reporting over				
PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].				
uci-CodeBlockSegmentation	UE	Yes	No	Yes
Indicates whether the UE supports segmenting UCI into multiple code blocks				
depending on the payload size.				
ul-64QAM-MCS-TableAlt	UE	No	No	Yes
Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH				
with and without transform precoding respectively.				
ul-SchedulingOffset	UE	Yes	Yes	Yes
Indicates whether the UE supports UL scheduling slot offset (K2) greater than 12.				

### 4.2.7.11 Other PHY parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
appliedFreqBandListFilter Mirrors the FreqBandList that the NW provided in the capability enquiry, if any. The UE filtered the band combinations in the supportedBandCombinationList in accordance with this appliedFreqBandListFilter.	UE	No	No	No
appliedFilters Contains all filters requested with UE-CapabilityRequestFilterNR from version 15.6.0 onwards.	UE	No	No	No
downlinkSetEUTRA Indicates the features that the UE supports on the DL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-DownlinkId. The FeatureSetEUTRA-DownlinkId = 0 means that the UE does not support a EUTRA DL carrier in this band of a band combination.	Band	N/A	No	No
downlinkSetNR Indicates the features that the UE supports on the DL carriers corresponding to one NR band entry in a band combination by FeatureSetDownlinkId. The FeatureSetDownlinkId = 0 means that the UE does not support a DL carrier in this band of a band combination. A fallback per band feature set resulting from the reported DL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	No	No
<b>featureSetCombinations</b> Pools of feature sets that the UE supports on the NR or MR-DC band combinations.	UE	N/A	No	No
featureSets  Pools of downlink and uplink features sets as well as a pool of FeatureSetCombination elements. A FeatureSetCombination refers to the IDs of the feature set(s) that the UE supports in that FeatureSetCombination. The BandCombination entries in the BandCombinationList then indicate the ID of the FeatureSetCombination that the UE supports fot that band combination.	UE	N/A	No	No
naics-Capability-List Indicates that UE in MR-DC supports NAICS as defined in defined in TS 36.331 [17].	UE	No	No	No
supportedBandCombinationList  Defines the supported NR and/or MR-DC band combinations by the UE. For each band combination the UE identifies the associated feature set combination by featureSetCombinations index referring to featureSetCombination. A fallback band combination resulting from the reported CA and MR-DC band combination is not signalled but the UE shall support it. For intra-band non-contiguous CA band combinations, the UE only includes one band combination, and exclude the others for which the presence of uplink CA bandwidth class in the band combination entry is different. One band combination entry can also indicate support of any other possible permutations in the presence of uplink CA bandwidth class where a paired downlink CA bandwidth class is the same or where the number of UL CCs is smaller than the one of paired DL CCs expressed by the CA bandwidth class, as specified in TS 36.306 [15]. For these band combinations not included in the capability, the supported feature set is the same as the ones for the band combination included in the UE capability.	UE	Yes	No	No
supportedBandCombinationListNEDC-Only Defines the supported NE-DC only type of band combinations by the UE.	UE	Yes	No	No
supportedBandListNR Includes the supported NR bands as defined in TS 38.101-1 [2] and TS 38.101-2 [3].	UE	Yes	No	No
uplinkSetEUTRA Indicates the features that the UE supports on the UL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-UplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination.	Band	N/A	No	No
uplinkSetNR Indicates the features that the UE supports on the UL carriers corresponding to one NR band entry in a band combination by FeatureSetUplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination. A fallback per band feature set resulting from the reported UL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	No	No

#### 4.2.7.12 NRDC-Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
sfn-SyncNRDC Indicates the UE supports NR-DC only with SFN and frame synchronization between PCell and PSCell. If not included by the UE supporting NR-DC, the UE supports NR-DC with slot-level synchronization without condition on SFN and frame synchronization.	UE	No	No	No

### 4.2.8 Void

### 4.2.9 *MeasAndMobParameters*

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
csi-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. This parameter needs FR1 and FR2 differentiation. If the UE supports this feature, the UE needs to report maxNumberResource-CSI-RS-RLM.	UE	Yes	No	Yes
csi-RSRP-AndRSRQ-MeasWithSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes
csi-RSRP-AndRSRQ-MeasWithoutSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes
csi-SINR-Meas Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponding to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes
eutra-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the ENDC is not configured.	UE	Yes	No	No
eventA-MeasAndReport Indicates whether the UE supports NR measurements and events A triggered reporting as specified in TS 38.331 [9]. This field only applies to SN configured measurement when EN-DC is configured. For NR SA, this feature is mandatory supported.	UE	Yes	Yes	No
eventB-MeasAndReport Indicates whether the UE supports EUTRA measurement and event B triggered reporting as specified in TS 38.331 [9]. It is mandated if the UE supports EUTRA.	UE	Yes	No	No
handoverLTE-5GC Indicates whether the UE supports HO to EUTRA connected to 5GC. It is mandated if the UE supports EUTRA connected to 5GC.	UE	Yes	Yes	Yes
handoverFDD-TDD Indicates whether the UE supports HO between FDD and TDD. It is mandated if the UE supports both FDD and TDD. This field only applies to NR SA (e.g. PCell handover). For PSCell change when EN-DC is configured, this feature is mandatory supported.	UE	Yes	No	No
handoverFR1-FR2 Indicates whether the UE supports HO between FR1 and FR2. Support is mandatory for the UE supporting both FR1 and FR2. This field only applies to NR SA(e.g. PCell handover). For PSCell change when EN-DC is configured, this feature is mandatory supported.	UE	Yes	No	No
handoverInterF Indicates whether the UE supports inter-frequency HO. It indicates the support for inter-frequency HO from the corresponding duplex mode if this capability is included in fdd-Add-UE-NR-Capabilities or tdd-Add-UE-NR-Capabilities. It indicates the support for of inter-frequency HO from the corresponding frequency range if this capability is included in fr1-Add-UE-NR-Capabilities or fr2-Add-UE-NR-Capabilities. This field only applies to NR SA (e.g. PCell handover). For PSCell change when EN-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	Yes
handoverLTE-EPC Indicates whether the UE supports HO to EUTRA connected to EPC. It is mandated if the UE supports EUTRA connected to EPC.	UE	Yes	Yes	Yes

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF	
independentGapConfig This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 specified in clause 9.1.2 of TS 38.133 [5]. The field also indicates whether the UE supports the FR2 inter-RAT measurement without gaps when EN-DC is not configured.	UE	No	No	No	
intraAndInterF-MeasAndReport Indicates whether the UE supports NR intra-frequency and inter-frequency measurements and at least periodical reporting. This field only applies to SN configured measurement when EN-DC is configured. For NR SA, this feature is mandatory supported.	UE	Yes	Yes	No	
periodicEUTRA-MeasAndReport Indicates whether the UE supports periodic EUTRA measurement and reporting. It is mandatory if the UE supports EUTRA, otherwise optional.	UE	CY	No	No	
maxNumberCSI-RS-RRM-RS-SINR  Defines the maximum number of CSI-RS resources for RRM and RS-SINR measurement across all measurement frequencies per slot. If UE supports any of csi-RSRP-AndRSRQ-MeasWithSSB, csi-RSRP-AndRSRQ-MeasWithoutSSB, and csi-SINR-Meas, UE shall report this capability.	UE	CY	No	No	
maxNumberResource-CSI-RS-RLM  Defines the maximum number of CSI-RS resources within a slot per spCell for CSI-RS based RLM. If UE supports any of csi-RS-RLM and ssb-AndCSI-RS-RLM, UE shall report this capability.	UE	CY	No	Yes	
nr-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when EN-DC is not configured.	UE	Yes	No	No	
nr-CGI-Reporting-ENDC  Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC is configured.	UE	Yes	No	No	
simultaneousRxDataSSB-DiffNumerology Indicates whether the UE supports concurrent intra-frequency measurement on serving cell or neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology as defined in clause 8 and 9 of TS 38.133 [5].	UE	No	No	Yes	
sftd-MeasPSCell Indicates whether the UE supports SFTD measurements between the PCell and a configured PSCell. If this capability is included in UE-MRDC-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in (NG)EN-DC. If this capability is included in UE-NR-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in NR-DC.	UE	No	Yes	No	
sftd-MeasPSCell-NEDC Indicates whether the UE supports SFTD measurement between the NR PCell and a configured E-UTRA PSCell in NE-DC.	UE	No	Yes	No	
sftd-MeasNR-Cell Indicates whether the SFTD measurement with and without measurement gaps between the EUTRA PCell and the NR cells is supported by the UE which is capable of EN-DC/NGEN-DC when EN-DC/NGEN-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one EN-DC band combination consisting of the set of the current E-UTRA serving frequencies and the NR frequency where SFTD measurement is configured. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No	
sftd-MeasNR-Neigh Indicates whether the inter-frequency SFTD measurement with and without measurement gaps between the NR PCell and inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one DC or CA band combination consisting of the set of the current NR serving frequencies and the NR frequency where SFTD measurement is configured.	UE	No	Yes	No	
sftd-MeasNR-Neigh-DRX Indicates whether the inter-frequency SFTD measurement using DRX off period between the NR PCell and the inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured.	UE	No	Yes	No	

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
ssb-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block as specified in TS 38.213 [11] and TS 38.133 [5]. This field shall be set to supported.	UE	Yes	No	No
ssb-AndCSI-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. If the UE supports this feature, the UE needs to report maxNumberResource-CSI-RS-RLM.	UE	No	No	No
ss-SINR-Meas Indicates whether the UE can perform SS-SINR measurement as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes
supportedGapPattern Indicates measurement gap pattern(s) optionally supported by the UE for NR SA, for NR-DC, for NE-DC and for independent measurement gap configuration on FR2 in (NG)EN-DC. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3, as specified in TS 38.133 [5] and so on. The UE shall set the bits corresponding to the measurement gap pattern 13 and 14 to 1 if the UE is an NR standalone capable UE that supports a band in FR2 or if the UE is an (NG)EN-DC capable UE that supports independentGapConfig and supports a band in FR2.	UE	CY	No	No

### 4.2.10 Inter-RAT parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
mfbi-EUTRA	UE	Yes	No
Indicates whether the UE supports the mechanisms defined for cells broadcasting multi band information i.e. comprehending <i>multiBandInfoList</i> defined in TS 36.331 [17].			
modifiedMPR-BehaviorEUTRA	UE	No	No
modifiedMPR-Behavior in 4.3.5.10, TS 36.306 [15].			
multiNS-Pmax-EUTRA	UE	No	No
multiNS-Pmax defined in 4.3.5.16, TS 36.306 [15].			
ne-DC	UE	No	No
Indicates whether the UE supports NE-DC as specified in TS 37.340 [7].			
rs-SINR-MeasEUTRA	UE	No	No
rs-SINR-Meas in 4.3.6.13, TS 36.306 [15].			
rsrqMeasWidebandEUTRA	UE	No	Yes
rsrqMeasWideband in 4.3.6.2, TS 36.306 [15]			
supportedBandListEUTRA	UE	No	No
supportedBandListEUTRA defined in 4.3.5.1. TS 36.306 [15].			

4.2.10.1 Void

4.2.10.2 Void

4.2.11 Void

4.2.12 Void

#### 4.2.13 IMS Parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
voiceOverEUTRA-5GC Indicates whether the UE supports IMS voice over E-UTRA via 5GC. It is mandated to the UE if the UE is capable of IMS voice over E-UTRA via 5GC. Otherwise, the UE	UE	No	No	No
does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.				
voiceOverNR Indicates whether the UE supports IMS voice over NR. It is mandated to the UE if the UE is capable of IMS voice over NR. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	Yes
voiceOverSCG-BearerEUTRA-5GC Indicates whether the UE supports IMS voice over SCG bearer of NE-DC.	UE	No	No	N/A

#### 4.2.14 RRC buffer size

The RRC buffer size is defined as the maximum overall RRC configuration size that the UE is required to store. The RRC buffer size is 45Kbytes.

## 5 Optional features without UE radio access capability parameters

#### **Definitions for feature**

SU-MIMO Interference Mitigation advanced receiver

- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2 with 2 RX antennas
- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2, 3, and 4 with 4 RX antennas

UE supporting the feature is required to meet the Enhanced Receiver Type requirements in TS 38.101-4 [18].

## 6 Conditionally mandatory features without UE radio access capability parameters

Features	Condition
Skipping UL configured grant if no data to transmit.	Either configuredUL-GrantType1 or configuredUL-GrantType2 is supported.
Downlink SDAP header	Either NAS reflective QoS or as-Reflective QoS is supported.

## 7 Void

## 8 UE Capability Constraints

The following table lists constraints indicating the minimum UE capabilities that the UE shall support.

Parameter	Description	Value
#DRBs	The number of DRBs that a UE shall support.	16 per UE.  NOTE: 8 per MAC entity  with duplication.
#minCellperMeasObj ectNR	The minimum number of neighbour cells (excluding black list cells) that a UE shall be able to store associated with a MeasObjectNR.	32
#minBlackCellRange sperMeasObjectNR	The minimum number of blacklist cell PCI ranges that a UE shall be able to store associated with a MeasObjectNR.	8
#minCellperMeasObj ectEUTRA	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32
#minCellTotal	The minimum number of neighbour cells (excluding black list cells) that UE shall be able to store in total from all measurement objects configured.	256 with counting CSI-RS and SSB as 2.
#cell for CGI reporting	the limit regarding the cells NR can configure includes the cell for which the UE is requested to report CGI.	(# minCellperMeasObjectRAT - 1), where RAT represents NR and EUTRA.

## Annex A (normative): Differentiation of capabilities

## Annex A.1: TDD/FDD differentiation of capabilities in TDD-FDD CA

Annex A.1 specifies for which TDD and FDD serving cells a UE supporting TDD/FDD CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for TDD/FDD CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FDD and TDD, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.1-1 in accordance to the following rules:
  - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell duplex mode;
  - PSCell: the UE shall support the feature for the PSCell, if the UE indicates support of the feature for the PSCell duplex mode;
  - Per serving cell: the UE shall support the feature for a serving cell if the UE indicates support of the feature for the serving cell's duplex mode;
  - All serving cells: UE shall support the feature for all serving cells in a CG if the UE indicates support of the feature for both TDD and FDD duplex modes;
  - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for all associated serving cells's duplex modes;
- For the fields where the UE is not allowed to indicate different support for FDD and TDD, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.1-1: Rel-15 UE capabilities for which FDD/TDD differentiation is allowed

UE-NR-Capability or	Classification							
UE-MRDC-Capability								
eventA-MeasAndReport	PSCell							
dl-SchedulingOffset-PDSCH-TypeA (Note3)	Associated serving cells							
dl-SchedulingOffset-PDSCH-TypeB (Note3)	Associated serving cells							
dynamicSFI (Note3)	Associated serving cells							
handoverInterF	PCell							
handoverLTE-EPC	PCell							
handoverLTE-5GC	PCell							
intraAndInterF-MeasAndReport	PSCell							
logicalChannelSR-DelayTimer(Note2)	Associated serving cells							
longDRX-Cycle	All serving cells							
multipleConfiguredGrants(Note1)	Associated serving cells							
multipleSR-Configurations	Per serving cell							
sftd-MeasNR-Cell	PCell							
sftd-MeasNR-Neigh	PCell							
sftd-MeasNR-Neigh-DRX	PCell							
sftd-MeasPSCell	PCell							
sftd-MeasPSCell-NEDC	PCell							
shortDRX-Cycle	All serving cells							
skipUplinkTxDynamic	Per serving cell							
twoDifferentTPC-Loop-PUCCH (Note3)	Associated serving cells							
twoDifferentTPC-Loop-PUSCH (Note3)	Associated serving cells							
ul-SchedulingOffset (Note3)	Associated serving cells							
NOTE 1: The associated serving cells including	ng the serving cell(s) configured							
with configured grant.								
NOTE 2: For a given logical channel, the asso								
PUCCH cell(s) associated with this le	ogical channel (via							
schedulingRequestID).								
NOTE 3: The associated serving cells includir								
command and the cell applying the command.								

## Annex A.2: FR1/FR2 differentiation of capabilities in FR1-FR2 CA

Annex A.2 specifies for which FR1 and FR2 serving cells a UE supporting FR1/FR2 CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for FR1/FR2 CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FR1 and FR2, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.2-1 in accordance to the following rules:
  - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell FR mode;
  - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for associated serving cells's FR modes;
- For the fields where the UE is not allowed to indicate different support for FR1 and FR2, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.2-1: Rel-15 UE capabilities for which FR1/FR2 differentiation is allowed

UE-NR-Capability	Classification
absoluteTPC-Command (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeA (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeB (Note2)	Associated serving cells
dynamicSFI (Note2)	Associated serving cells
handoverInterF	PCell
handoverLTE-EPC	PCell
handoverLTE-5GC	PCell
tpc-PUCCH-RNTI (Note2)	Associated serving cells
tpc-PUSCH-RNTI (Note2)	Associated serving cells
tpc-SRS-RNTI (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUCCH (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUSCH (Note2)	Associated serving cells
ul-SchedulingOffset (Note2)	Associated serving cells
voiceOverNR (Note1)	Associated serving cells.

- NOTE 1: For a UE that does not support Ich-ToSCellRestriction capability, the associated serving cells includes all serving cells in the CG; for a UE that supports *lch-ToSCellRestriction* capability, the associated serving cells includes the serving cells indicated by allowedServingCells for the LCH.

  NOTE 2: The associated serving cells including both the cell sending the command and the cell applying the command.

# Annex B (informative): Change history

						Change history	
Date	Meetin g		CR	Rev	Cat	Subject/Comment	New version
06/2017	RAN2# 98	R2-1704810				First version	0.0.1
06/2017	RAN2# NR2	R2-1707386					0.0.2
08/2017	RAN2# 99	R2-1708750					0.0.3
12/2017	RAN2# 100	R2-1712587					0.0.4
12/2017		R2-1714141					0.0.5
12/2017		R2-1714271					0.1.0
12/2017	RP-78	RP-172521				Submitted to RAN#78 for approval	1.0.0
12/2017	RP-78					Upgraded to Rel-15	15.0.0
03/2018	RP-79	RP-180440	0003	3	F	Updates on UE capabilities	15.1.0
06/2018	RP-80	RP-181216	0009	2	В	Introduce ANR in NR	15.2.0
	RP-80	RP-181216	0012	1	F	Miscellaneous corrections	15.2.0
		RP-181216	0013	-	В	Delay budget report and MAC CE adaptation for NR for TS 38.306	15.2.0
09/2018	RP-81	RP-181940	8000	4	F	Correction on total layer2 buffer size	15.3.0
	RP-81	RP-181942	0024	1	F	Introduction of UE capability constraints	15.3.0
10/00 : -	RP-81	RP-181942	0030	-	F	38.306 corrections and cleanup	15.3.0
12/2018	RP-82	RP-182651	0016	4	F	Clarification for Interruption-based and gap-based SFTD measurement	
		RP-182653	0033	1	F	Timer based BWP switching	15.4.0
	RP-82 RP-82	RP-182652 RP-182651	0035 0037	2	F	Additional UE capabilities for NR standalone Clarification to UE capability of independentGapConfig for inter-RAT	15.4.0 15.4.0
	KF-02	KF-102031	0037	'	Г	NR measurement not yet configured with EN-DC	15.4.0
	RP-82	RP-182661	0038	2	F	Update of L2 capability parameters	15.4.0
		RP-182660	0030	2	F	Clarification on physical layer parameters of UE capability	15.4.0
		RP-182666	0050	3	F	Introduce RRC buffer size in NR	15.4.0
		RP-182664	0051	2	F	Clarification of multipleConfiguredGrants	15.4.0
		RP-182664	0051	2	F	CR to 38.306 for PDCP CA duplication for SRB	15.4.0
	RP-82	RP-182661	0054	1	F	UE capability handling for FDD/TDD and FR1/FR2	15.4.0
		RP-182663	0057	1	F	Clarify for per CC UL/DL modulation order capabilities	15.4.0
		RP-182664	0058	1	F.	Inter-frequency handover capability	15.4.0
	RP-82	RP-182665	0060	3	F	UE capability on PA architecture	15.4.0
		RP-182661	0062	1	F	CR on signaling contiguous and non-contiguous EN-DC capability	15.4.0
		RP-182813	0063	6	F	Update of UE capabilities	15.4.0
		RP-182662	0065	2	F	Introduction of SRS switching capability	15.4.0
		RP-182667	0068	2	В	CR on introduction of UE overheating support in NR SA scenario	15.4.0
	RP-82	RP-182664	0071	-	F	Introduction of SRS switching capability	15.4.0
03/2019	RP-83	RP-190634	0073	1	F	Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS	15.5.0
	RP-83	RP-190542	0074	1	F	Layer-1 capability update	15.5.0
	RP-83	RP-190545	0075	2	F	CR to 38.306 on introducing nr-CGI-Reporting-ENDC	15.5.0
	RP-83	RP-190545	0086	2	F	CR to clarify intra-NR handover capabilities	15.5.0
	RP-83	RP-190546	0088	3	F	Clarification for PDSCHs and PUSCHs per slot for different TBs for UE	
						capable of processing time capability 1	
	RP-83	RP-190542	0092	2	F	Correction to mandatory supported capability signaling	15.5.0
	RP-83	RP-190542	0097	2	F	Miscellaneous corrections	15.5.0
	RP-83	RP-190545	0098	2	F	Correction on supportedBandwidthCombinationSetEUTRA-v1530 usage	15.5.0
	RP-83	RP-190543	0099	-	F	Clarification on signaling the bandwidth class	15.5.0
	RP-83	RP-190545	0100	1	F	Clarification on Frequency Separation Class	15.5.0
	RP-83	RP-190544	0101	-	F	CR on Processing delay requirements for RRC Resume procedures in TS 38.306	15.5.0
06/2019	RP-84	RP-191375	0094	1	F	CR to clarify ul-TimingAlignmentEUTRA-NR	15.6.0
	RP-84	RP-191373	0108	-	F	Layer-1, RF and RRM capability updates	15.6.0
	RP-84	RP-191373	0109	-	F	Clarification on UE capability of Ich-ToSCellRestriction	15.6.0
	RP-84	RP-191379	0110	2	F	Correction on description of additional Active Spatial Relation PUCCH	15.6.0
	RP-84	RP-191378	0111	1	F	Clarification on csi-RS-CFRA-ForHO	15.6.0
	RP-84	RP-191379	0114	2	F	CR on capability of maxUplinkDutyCycle for FR2	15.6.0
	RP-84	RP-191380	0115	2	F	38.306 miscellaneous corrections	15.6.0
	RP-84	RP-191378	0116	1	В	38.306 CR for late drop	15.6.0
	RP-84	RP-191381	0118	4	F	Clarification on supported modulation order capability	15.6.0
	RP-84	RP-191374	0119	-	F	Correction to PDCP parameters	15.6.0
	RP-84	RP-191381	0121	3	F	Corrections to UE Capability definitions	15.6.0
	RP-84	RP-191378	0122	1	F	38.306 Clarification on multiple TA capabilities	15.6.0
	RP-84	RP-191379	0123	2	F	CR to clarify non-codebook based PUSCH transmission	15.6.0
	RP-84	RP-191380	0124	3	F	Clarification on pdsch-ProcessingType2	15.6.0

	RP-84	RP-191378	0125	1	IF	Clarification on present of tci-StatePDSCH	15.6.0
	RP-84	RP-191378	0126	1	F	Clarification on SA fallback BC support	15.6.0
	RP-84	RP-191375	0128	-	F	Correction to Beam Correspondence for CA	15.6.0
	RP-84	RP-191379	0130	2	F	Correction on the number of DRB in UE Capability Constraints	15.6.0
	RP-84	RP-191379	0132	1	F	CR to capture UE supported DL/UL bandwidths	15.6.0
	RP-84	RP-191376	0133	-	F	UE capability signalling for FD-MIMO processing capabilities for EN-DC	15.6.0
	RP-84	RP-191376	0134	-	F	Modified UE capability on different numerologies within the same PUCCH group	15.6.0
	RP-84	RP-191554	0135	-	F	Removal of "Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS"	15.6.0
09/2019	RP-85	RP-192196	0136	1	С	Additional capability signalling for 1024QAM support	15.7.0
	RP-85	RP-192191	0142	1	В	Introduction of SFTD measurement to neighbour cells for NR SA	15.7.0
	RP-85	RP-192193	0146	1	F	MR-DC measurement gap pattern capability	15.7.0
F	RP-85	RP-192194	0151	3	F	Clarifying UE capability freqHoppingPUCCH-F0-2 and freqHoppingPUCCH-F1-3-4	15.7.0
	RP-85	RP-192190	0152	-	F	Clarification to dynamic power sharing capability	15.7.0
	RP-85	RP-192192	0153	2	F	Miscellaneous corrections	15.7.0
	RP-85	RP-192190	0154	-	F	Capability of measurement gap patterns	15.7.0
	RP-85	RP-192193	0155	2	F	Correction to IMS capability	15.7.0
	RP-85	RP-192194	0156	3	F	UE Capabilities covering across all serving cells	15.7.0
	RP-85	RP-192190	0167	-	F	Clarification on UE capability on different numerologies within the same PUCCH group	15.7.0
	RP-85	RP-192193	0168	1	F	Correction on CA parameters in NR-DC	15.7.0
	RP-85	RP-192346	0169	-	С	Introduction of UE capability for NR-DC with SFN synchronization between PCell and PSCell	15.7.0
12/2019	RP-86	RP-192934	0185	1	F	Clarification on the restriction of maximum SRS resource sets configuration for uplink beam management.	15.8.0
	RP-86	RP-192936	0186	3	F	Miscellaneous corrections on UE capability fields	15.8.0
	RP-86	RP-192935	0191	1	F	Corrections on PDCCH blind decoding in NR-DC	15.8.0
	RP-86	RP-192937	0200	1	F	Clarification on ne-DC capability	15.8.0
	RP-86	RP-192935	0202	1	F	Correction to channelBWs	15.8.0
	RP-86	RP-192936	0204	1	F	Use of splitSRB-WithOneUL-Path capability (38.306)	15.8.0
	RP-86	RP-192935	0205	-	F	Correction to pdsch-RepetitionMultiSlots and pusch-RepetitionMultiSlots	15.8.0
	RP-86	RP-192937	0215	1	F	Correction on initial BWP bandwidth capabilities	15.8.0
	RP-86	RP-192937	0216	1	F	NE-DC dynamic power sharing capability	15.8.0
	RP-86	RP-192935	0219	-	F	Clarification on crossCarrierScheduling-OtherSCS in R15	15.8.0
	RP-86	RP-192937	0220	-	F	Correction on ambiguity of UE FDD/TDD FR1/FR2 capabilities	15.8.0