
1. Connection



Connect to FMU PWM (AUX) out



Use channel 5



2. Testing

Use Analyze Tools > MAVLink Console in QGroundControl.

Use pwm_input start to turn on PWM input signal test.

Use pwm_input test to get signal input.

Use pwm_input for more information.

