
ISO EC C4L STD LAYOUT (56 BUTTONS)

ISOMORPHIC ENGLISH CONCERTINA C4 on Left (Standard full layout)



Buttons Dimensions


Drawing to scale (when printed)

Button diameter 5mm


Hole diameter 6mm

Clearance button to hole 0.5mm from button perimeter.


Button Intervals (semi-tones)




Buttons Distance (mm)




ISO EC C4L STD - MAJOR SCALES




ISO EC C4L STD - MINOR SCALES




ISO EC C4L STD - BLUES SCALES




ISO EC C4L STD - PENTATONIC SCALES




ISO EC C4L STD - MAJOR CHORDS




ISO EC C4L STD - MINOR CHORDS




ISO EC C4L STD - AUGMENTED CHORDS




ISO EC C4L STD - DIMINISHED CHORDS



ISO EC C4L STD - FLAT 5 CHORDS



ISO EC C4L STD - SUS 4 CHORDS



ISO EC C4R STD LAYOUT (56 BUTTONS)

ISOMORPHIC ENGLISH CONCERTINA C4 on Right (Standard full layout)

RHS (28 buttons) LHS (28 buttons) (GRAY) D#6 (G5)Db5 (F5) C#6 Bb4 **D**5 G#5 **E**5 C5 Ab4 (Gb4) (F#5) Eb4 **G**4 **B**4 D#5 C#5 (A4) (F4) Bb3 (C4) **E**4 G#4 (A#4) (D4) THUMB C#4 **B**3 Cb3 **(F3) (**A3) E#4 **G**3 **D**3 (A#3) G#3 **(**E3) (C3) (Ab2) Gb2 (Bb2) (F#3) 110 mm 110 mm

Buttons Dimensions


Drawing to scale (when printed)

Button diameter 5mm


Hole diameter 6mm

Clearance button to hole 0.5mm from button perimeter.


Button Intervals (semi-tones)




Buttons Distance (mm)




ISO EC C4R STD - MAJOR SCALES




ISO EC C4R STD - MINOR SCALES




ISO EC C4R STD - BLUES SCALES




ISO EC C4R STD - PENTATONIC SCALES




ISO EC C4R STD - MAJOR CHORDS




ISO EC C4R STD - MINOR CHORDS




ISO EC C4R STD - AUGMENTED CHORDS



ISO EC C4R STD - DIMINISHED CHORDS



ISO EC C4R STD - FLAT 5 CHORDS



ISO EC C4R STD - SUS 4 CHORDS

