## ISO EC C4R STD LAYOUT (56 BUTTONS)

ISOMORPHIC ENGLISH CONCERTINA C4 on Right (Standard full layout)

RHS (28 buttons) LHS (28 buttons) (GRAY) D#6 (G5)Db5 (F5) C#6 Bb4 **D**5 G#5 **E**5 C5 Ab4 (Gb4) (F#5) Eb4 **G**4 **B**4 D#5 C#5 (A4) (F4) Bb3 (C4) **E**4 G#4 (A#4) (D4) THUMB C#4 **B**3 Cb3 **(F3) (**A3) E#4 **G**3 (D3) (A#3) G#3 **(**E3) (C3) Ab2 Gb2 (Bb2) (F#3) 110 mm 110 mm

# **Buttons Dimensions**


Drawing to scale (when printed)

Button diameter 5mm


Hole diameter 6mm

Clearance button to hole 0.5mm from button perimeter.


#### Button Intervals (semi-tones)




#### Buttons Distance (mm)




## ISO EC C4R STD - MAJOR SCALES




### ISO EC C4R STD - MINOR SCALES




#### ISO EC C4R STD - BLUES SCALES




### ISO EC C4R STD - PENTATONIC SCALES




# ISO EC C4R STD - MAJOR CHORDS




## ISO EC C4R STD - MINOR CHORDS




#### ISO EC C4R STD - AUGMENTED CHORDS



#### ISO EC C4R STD - DIMINISHED CHORDS



### ISO EC C4R STD - FLAT 5 CHORDS



### ISO EC C4R STD - SUS 4 CHORDS

